


# Web/SNMP Management Card

v1.x

User's  
Guide



## Limited Warranty

American Power Conversion (APC) warrants its products to be free from defects in materials and workmanship for a period of two years from the date of purchase. Its obligation under this warranty is limited to repairing or replacing, at its own sole option, any such defective products. To obtain service under warranty you must obtain a Returned Material Authorization (RMA) number from APC or an APC service center. Products must be returned to APC or an APC service center with transportation charges prepaid and must be accompanied by a brief description of the problem encountered and proof of date and place of purchase. This warranty does not apply to equipment which has been damaged by accident, negligence, or misapplication or has been altered or modified in any way. This warranty applies only to the original purchaser who must have properly registered the product within 10 days of purchase.

EXCEPT AS PROVIDED HEREIN, AMERICAN POWER CONVERSION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Some states do not permit limitation or exclusion of implied warranties; therefore, the aforesaid limitation(s) or exclusion(s) may not apply to the purchaser.

EXCEPT AS PROVIDED ABOVE, IN NO EVENT WILL APC BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF THIS PRODUCT, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE. Specifically, APC is not liable for any costs, such as lost profits or revenue, loss of equipment, loss of use of equipment, loss of software, loss of data, costs of substitutes, claims by third parties, or otherwise. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

## Governing Law

This statement shall be construed, interpreted and governed by the laws of the State of Rhode Island.

## Life Support Policy

As a general policy, American Power Conversion (APC) does not recommend the use of any of its products in life support applications where failure or malfunction of the APC product can be reasonably expected to cause failure of the life support device or to significantly affect its safety or effectiveness. APC does not recommend the use of any of its products in direct patient care. APC will not knowingly sell its products for use in such applications unless it receives in writing assurances satisfactory to APC that (a) the risks of injury or damage have been minimized, (b) the customer assumes all such risks, and (c) the liability of American Power Conversion is adequately protected under the circumstances.

Examples of devices considered to be life support devices are neonatal oxygen analyzers, nerve stimulators (whether used for anesthesia, pain relief, or other purposes), autotransfusion devices, blood pumps, defibrillators, arrhythmia detectors and alarms, pacemakers, hemodialysis systems, peritoneal dialysis systems, neonatal ventilator incubators, ventilators for both adults and infants, anesthesia ventilators, and infusion pumps as well as any other devices designated as "critical" by the U.S. FDA.

© American Power Conversion Corporation, 1997, 1998. All Rights Reserved; reproduction in whole or in part, without permission, is prohibited.

## Licenses & Trademarks

The following are product and corporate names used in this guide that are trademarks or registered trademarks of American Power Conversion Corporation: APC, Back-UPS, Matrix-UPS, Measure-UPS, *Power Array*, PowerChute, PowerNet, SNMP Adapter, SNMP Agent, Smart-UPS, v/s, SmartBoost, SmartSlot and Symmetra. All other trademarks, product and corporate names are the property of their respective owners and used here for informational purposes only.

## FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions in this user's guide, may cause harmful interference to radio communications.

## Canadian Department of Communications Compliance Statement

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le présent appareil numérique n'emet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la Class B prescrites dans le Règlement sur le brouillage radioélectrique édicté par le ministère des Communications du Canada.

## American Power Conversion Corporation

### APC Corporate

P.O. Box 278  
132 Fairgrounds Road  
West Kingston, RI 02892  
United States of America  
Toll Free: 1 800 800 4272  
Telephone: 1 401 789 5735  
Fax: 401 788 2743

### APC Europe

4 Rue St. Claire Deville  
Lognes F-77185  
France  
Toll Free: 0 800 906 483  
Telephone: 01 64 62 59 00  
Fax: 33 1 60 17 80 29

### APC Ireland

Ballybrit Industrial Estates  
Galway  
Ireland  
Toll Free: 1 800 702000  
Telephone: 353 91 702000  
Fax: 353 91 755275

### APC Japan

BR Gotanda 7th Floor  
2-30-4 Nishi-gotanda  
Shinagawa-ku  
Tokyo 141 Japan  
Free Dial: 0120-80-6090  
Telephone: (81) (3) 5434-2021  
Fax: (81) (3) 5434-2021

# Contents

<b>About This Guide</b>	<b>8</b>
How to Register Your Management Card .....	8
This Guide's Purpose .....	8
This Guide's Structure .....	8
Associated Documents .....	9
This Guide's Conventions .....	10
<b>Chapter 1:</b>	
<b>What You Can Use to Manage a Management Card</b>	<b>11</b>
Overview .....	11
Remote Management .....	11
Local Management .....	12
<b>Chapter 2:</b>	
<b>User-Interface Components</b>	<b>13</b>
AP9606 Web/SNMP Management Card .....	13
Status LED .....	13
Link-RX/TX LED .....	13
<b>Chapter 3:</b>	
<b>How to Define Basic Configuration Requirements</b>	<b>14</b>
Overview .....	14
How to Use a BOOTP Server .....	14
How to Use a Terminal .....	14
How to Use the Web/SNMP Management Card Wizard .....	14
<b>Chapter 4:</b>	
<b>How to Use a Management Card with PowerChute® plus</b>	<b>15</b>
Overview .....	15
What PowerChute plus Can Do .....	15
What PowerChute plus Cannot Do .....	15
How to Connect with PowerChute plus .....	16
<b>Chapter 5:</b>	
<b>How to Use SNMP</b>	<b>17</b>
Overview .....	17
How to Affect SNMP Access .....	17
How to Use MIB-II System OIDs .....	18
How to Use The PowerNet SNMP MIB .....	18
The PowerNet MIB and Network Communication .....	19
The PowerNet MIB OIDs .....	19
What PowerNet MIB OIDs Can Do .....	19
What PowerNet MIB OIDs Cannot Do .....	21
PowerNet MIB Traps .....	22

**Chapter 6:****How to Use a PowerNet SNMP Manager****23**

Overview .....	23
What PowerNet SNMP Manager Can Do .....	23
What PowerNet SNMP Manager Cannot Do .....	23

**Chapter 7:****How to use the Web Interface****24**

Overview .....	24
How Do I Access the Management Card Using a Web Browser? .....	24
What is Assistant Online? .....	25
What Purpose Do the User-Definable Links Serve? .....	25
Does the Management Card Have Local Help Pages? .....	25
How to Access the Web Interface .....	25
How to Log In .....	25
How to use the Web Interface .....	26
Device Status Summary Screen .....	26
The Smart-UPS Status Screen .....	27
The Measure-UPS Status Screen .....	28
The Network Screen .....	29
The System Screen .....	30
How to Manage a Smart-UPS or Matrix-UPS .....	31
The Smart-UPS Status Screen .....	31
The Smart-UPS Diagnostics Screen .....	33
How to Control a UPS .....	35
How to Configure a UPS .....	37
Configuration .....	38
Shutdown Parameters .....	39
General Settings .....	40
How to Manage a Symmetra Power Array .....	40
Detailed Status Screen .....	44
Diagnostics Screen .....	45
Symmetra Module Status .....	47
Symmetra Module Dump .....	49
How To Control a Symmetra Power Array .....	50
How To Configure a Symmetra Power Array .....	52
Configuration .....	53
Alarm Thresholds .....	53
Shutdown Parameters .....	54
General Settings .....	54
How to Manage a Measure-UPS .....	55
How to Monitor a Measure-UPS .....	55
Measure-UPS Menu Screen's Status Information .....	56
How to Configure a Measure-UPS .....	57
How To Define the Management Card's Basic Network Values .....	58
How To Control File Transfers .....	59
How To Use the Telnet/Web Menu .....	60
How to Use the SNMP Menu .....	61
How to Control SNMP Channel Access .....	62
How to Define Trap Receivers .....	62
How to Manage the Management Card's System (Internal) Operation .....	63

How to Control Access to the Control Console .....	63
How to Define System Identification Values .....	65
How to Set Date and Time Values .....	65
How to Manage File Transfers .....	66
How to Affect the Management Card's SNMP Agent .....	67
How To Define Links .....	68
How To View the Management Card's Identification Values .....	69

## Chapter 8:

### The AP9606 Management Card Control Console

70

Overview .....	70
Control Console Structure .....	70
How to Access the Control Console .....	71
How to Use Telnet with the Control Console .....	71
How to Use a Terminal with the Control Console .....	71
How to Log In .....	72
The Control Console's Main Screen .....	72
Management Card Information .....	73
How to use the Control Console Menu .....	73
Device Manager Menu .....	74
Network Menu .....	74
System Menu .....	75
How to Manage A UPS .....	75
How to Manage A Smart-UPS or Matrix-UPS .....	76
How to Monitor a Smart-UPS or Matrix-UPS .....	77
UPS Menu Screen Status Information .....	77
UPS Menu Status Options .....	78
How to Control a UPS .....	79
How to Configure a Smart-UPS or Matrix-UPS .....	81
Battery Screen .....	83
Line Transfer Screen .....	84
Shutdown Parameters Screen .....	85
General Screen .....	86
How to Manage A Symmetra Power Array .....	86
How to Monitor a Symmetra Power Array .....	87
Symmetra Screen Status Display .....	88
Detailed Status Screen .....	89
Scheduled Tests Screen .....	91
Module Diagnostics & Information Screen .....	92
Faults & Alarms Screen .....	95
How to Control a Symmetra Power Array .....	96
How to Configure a Symmetra Power Array .....	98
Utility Line Screen .....	99
Alarm Thresholds Screen .....	100
Shutdown Parameters Screen .....	101
General Screen .....	102
Reset UPS to Defaults Screen .....	102
How to Manage a Measure-UPS .....	103
How to Monitor a Measure-UPS .....	103
Measure-UPS Menu Screen's Status Information .....	103
Measure-UPS Menu Status Options .....	104
How to Configure a Measure-UPS .....	106

How to Manage the Management Card's Network Connection .....	108
How to Define the Management Card's Basic Network Values .....	109
How to Control File Transfers .....	110
TFTP Client .....	110
FTP Client .....	111
FTP Server .....	111
How to Use the Telnet Menu .....	112
How to Use the Web Menu .....	112
How to Use the SNMP Menu .....	113
How to Control SNMP Channel Access .....	115
How to Define Trap Receivers .....	115
How to Manage the Management Card's System (Internal) Operation .....	117
How to Determine Access to the Control Console .....	117
How to Define System Identification Values .....	118
How to Set Date and Time Values .....	119
How to Manage File Transfers .....	119
How to Control File Transfer Settings .....	120
How to Affect the Management Card's Operation .....	120
How to View the Management Card's Identification Values .....	121

## Chapter 9:

### File Transfers (Firmware and Configuration Files)

122

Overview .....	122
Upgrading the Management Card's Firmware .....	122
What is Firmware? .....	122
What are the Benefits of Upgrading the Firmware? .....	122
Where Do I Get the Latest Firmware? .....	122
How Much Does New Firmware Cost? .....	123
What Should I Know Before I Start the Firmware Upgrade? .....	123
How to Upgrade the Firmware .....	124
Upgrading Using the Web/SNMP Management Card Wizard .....	124
Upgrading Multiple Management Cards That are Available on the Network .....	124
Upgrading a Management Card That is Not Available on the Network. ....	124
Upgrading Using a Command Prompt FTP Client .....	125
Upgrading a Single Management Card That is Available on the Network .....	125
Upgrading Multiple Management Cards That are Available on the Network .....	127
Upgrading Using XMODEM .....	127
How Do I Know That the Firmware Upgrade Was Successful? .....	128
Updating the Management Card's Configuration Settings .....	129
What are the Management Card's Configuration Settings? .....	129
What is a Configuration File? .....	129
How Do I Create a Configuration File? .....	129
How Do I Transfer a Configuration File to a Management Card? .....	129
Updating the Configuration Settings using a BOOTP Bootup Filename .....	129
Updating the Configuration Settings of One or More Management Cards Using the Web/SNMP Management Card Wizard .....	130
Updating the Configuration Settings by Using an FTP Client .....	131
Updating the Configuration Settings by Initiating a TFTP Download .....	133
Updating the Configuration Settings by Initiating a FTP Download .....	134
How Do I Know That the Configuration File Transfer Was Successful? .....	135

## Chapter 10:

### Web/SNMP Management Card Wizard

136

Overview .....	136
What Are the System Requirements for Running the Wizard? .....	136
Where Can I Get an Updated Version of the Wizard? .....	136
What Management Card Settings Does the Wizard Allow Me to Configure? .....	136
Does the v1.0.1 Version of the Wizard Have Any Limitations? .....	136
How Do I Install the Wizard? .....	136
How Do I Run the Wizard? .....	136
How Can I Quickly Configure Only the Required Settings? .....	137
How Can I Pre-configure Multiple Management Cards Before They are Deployed? .....	137
How Can I Reconfigure Multiple Management Cards After They are Deployed? .....	137
How Can I Upgrade Firmware? .....	137
Using the Wizard to Configure Only the Required Settings .....	138
Using the Wizard to Pre-configure the Management Card Locally .....	140
Using the Wizard to Create a Configuration File for BOOTP .....	147
Using the Wizard to Reconfigure Deployed Management Cards .....	151
Using the Wizard to Create a Configuration File .....	158
Using the Wizard to Upgrade Firmware .....	162
<b>Chapter 11:</b>	
<b>Web/SNMP Management Card Security</b>	<b>165</b>
Overview .....	165
Authentication versus Encryption .....	165
User Names, Passwords and Community Names .....	165
Port Assignments .....	165
MD5 Authentication .....	166
<b>Chapter 12:</b>	
<b>How to Correct Management Card Problems</b>	<b>167</b>
Web/SNMP Management Card-Related Common Problems and Solutions .....	167
How to Correct Communication Lost Problems .....	168
APC Worldwide Product Support .....	169
<b>Appendix A</b>	
<b>Acronyms &amp; Abbreviations</b>	<b>170</b>

---

## About This Guide

---

This introduction provides information which can help you use this guide to control the operation of your Management Card, its UPS and Measure-UPS (or SmartSlot Measure-UPS II). This includes descriptions of:

- HOW TO REGISTER YOUR MANAGEMENT CARD
- THIS GUIDE'S PURPOSE
- THIS GUIDE'S STRUCTURE
- ASSOCIATED DOCUMENTS
- THIS GUIDE'S CONVENTIONS

### How to Register Your Management Card

---

Please fill out and return the enclosed warranty card. This card not only provides us with valuable feedback about how we can refine our products to serve your needs better, but it also enables us to notify you about important product updates and changes.

### This Guide's Purpose

---

This guide describes how to use an AP9606 Web/SNMP Management Card v1.x to manage (monitor, control and configure) a UPS and a Measure-UPS (or a SmartSlot Measure-UPS II) via the web interface, SNMP and Telnet.

---

**Note:** The Management Card can connect a UPS without a Measure-UPS, a UPS which has a Measure-UPS, or a Measure-UPS without a UPS, to the network for management.

---

### This Guide's Structure

---

In addition to this introduction, this guide has twelve chapters and an appendix to describing how to use the Web/SNMP Management Card:

- **Chapter 1: What You Can Use to Manage a Management Card**  
Provides an introduction to the applications you can use to manage a Management Card, its UPS and a Measure-UPS.
- **Chapter 2: User-Interface Components**  
Identifies the Management Card's light-emitting diodes (LEDs), and describes what these LEDs can tell you about the Management Card.
- **Chapter 3: How to Define Basic Configuration Requirements**  
Provides an overview of how you can use a BOOTP server, or a terminal, to define the network values a Management Card needs before it can run on the network.



- **Chapter 4: How to Use a Management Card with PowerChute *plus***  
Provides an overview of how you can use APC's PowerChute *plus* with your Management Card, including a brief description of using PowerChute *plus* for full, local management of a UPS and a Measure-UPS.
- Note: You cannot use PowerChute *plus* to manage the Management Card's operation.**
- **Chapter 5: How to Use SNMP**  
Describes how you can use an SNMP browser's **GET** (read) and **SET** (write) commands for full, remote (over the network) management of the Management Card, its UPS and a Measure-UPS.
- **Chapter 6: How to Use PowerNet SNMP Manager**  
Provides an overview of how you can use APC's PowerNet SNMP Manager for full, remote (over the network) management of the Management Card, its UPS and a Measure-UPS.
- **Chapter 7: Web Interface**  
Describes how you can manage an AP9606 Management Card, its UPS and a Measure-UPS using the Web Interface.
- **Chapter 8: The Management Card Control Console**  
Describes how you can manage an AP9606 Management Card, its UPS and a Measure-UPS using either Telnet for remote (over the network) management or a terminal, for local management.
- **Chapter 9: File Transfers**  
Describes the different options available for transferring files to the Management Card.
- **Chapter 10: Web/SNMP Management Card Wizard**  
Describes how to use the Wizard, a Windows application designed specifically for pre-configuration and reconfiguration of multiple Web/SNMP Management Cards.
- **Chapter 11: Security**  
Describes the different security options available, depending on the access interface used.
- **Chapter 12: How to Correct Management Card Problems**  
Describes how to correct problems which can occur with your Management Card. It also provides information on how to contact APC technical support anywhere in the world.
- **Appendix A: Acronyms and Abbreviations**  
Identifies the full terminology for acronyms and abbreviations used in this guide.

## Associated Documents

---

Four other documents come with the Management Card, either in printer form, or as Portable Document Format (\*.pdf) files on the same disk which contains this user's guide:

- *Web/SNMP Management Card - Installation and Quick Start Guide* (printed, 990-6008A, **insguide.pdf** on CD-ROM)  
Describes how to physically install a Management Card, and connect it to your network.
- *PowerNet™ SNMP v3.0.2 MIB - Reference Guide* (**mibguide.pdf**, on CD-ROM)  
Describes the management information base (MIB) which a network management station (NMS) can use remotely to manage and control the Management Card, UPS and Measure-UPS.
- *Network Management Station (NMS) Reference Guide* (**nms.pdf**, on CD-ROM)  
Describes how to load and compile the PowerNet™ SNMP MIB at different NMS platforms.

- *Web/SNMP Management Card - Release Notes (relnotes.txt, on CD-ROM)*  
Identifies issues that apply directly to this v1.x version of the Management Card, and are not covered in any other document.

Refer to your UPS-specific user's guide or owner's manual for information about your UPS; refer to your NMS-specific documentation for information about your NMS.

## This Guide's Conventions

This guide refers to the Management Card, and other various devices you can use with the Management Card and its UPS:

This Guide Uses	To Refer to
Management Card or Card	The AP9606 Web/SNMP Management Card
AP9600	The AP9600 SmartSlot Expansion Chassis
Measure-UPS	The standalone Measure-UPS or the SmartSlot Measure-UPS II
Server	Any server, workstation or other component which you can connect directly to your UPS
Network management station (NMS) or NMS	Any network component you can use to manage the Management Card.

**Note:** See APPENDIX A to identify the full terminology for any acronyms or abbreviation used in this guide.

Also, this guide uses the following conventions when referring to specific items within the text:

When the Following Appear in Text	This Guide Uses
A document name ( <i>PowerNet SNMP Agent - MIB Reference Guide</i> )	<i>Italics</i>
- Menu names ( <b>Console Control</b> menu) - File names ( <b>powernet.mib</b> ) - Management information base (MIB) object identifications ( <b>upsAdvControl</b> ) - Button names ( <b>Connect</b> ) - Dialog box names ( <b>Connect</b> menu)	Boldface <b>Arial</b> font
- Menu options (1- Device Manager) - Display field names or values (UPS Output : ) - Keyboard input (press <Enter>)	The <b>Courier New</b> font

## Chapter 1:

### What You Can Use to Manage a Management Card

This chapter provides an introduction to the applications you can use to manage a Management Card, its UPS and a Measure-UPS.

#### Overview

The Management Card provides the hardware and firmware needed to connect your APC UPS to a 10Mbps Ethernet network and use that network for remote (over the network) management of the Management Card, its UPS, and a Measure-UPS. The Management Card also allows you to use a terminal for local management.

**Note:** If *PowerChute plus* is installed on your system, you can use it to manage the UPS and a Measure-UPS locally. However, you cannot use *PowerChute plus* to manage the Management Card, or the Management Card's network operation. This user's guide mentions *PowerChute plus*, where appropriate, but does not describe how to use it. For that information, see your *PowerChute plus User's Guide*.

#### Remote Management

When a Management Card is running its SNMP agent on the network, you can use several methods to manage the Management Card, its UPS and a Measure-UPS:

You can use this	To Do this
An SNMP browser's <b>GET</b> and <b>SET</b> commands to access PowerNet SNMP management information base (MIB) object identifications (OIDs)	Use SNMP to manage a Management Card, its UPS and Measure-UPS (see CHAPTER 3).
APC's PowerNet SNMP Manager	Manage a Management Card, its UPS and Measure-UPS, without using an SNMP browser or the PowerNet SNMP MIB (see CHAPTER 5).
A Telnet console	Use a Management Card's Control Console to manage that Card, its UPS and Measure-UPS (see CHAPTER 8).
A bootstrap protocol (BOOTP) server	Provide the basic network values a Management Card needs to run on the network (see CHAPTER 4).
FTP Client, TFTP Client, XMODEM or FTP Server	Download new firmware and configuration files.
Web Browser	Use a web browser to manage all aspects of the Adapter's operation and any connected UPS or Measure-UPS.

---

## Local Management

---

You can connect a terminal (or terminal-emulator) to the Management Card, and use the Management Card's Control Console to manage the Management Card, its UPS and Measure-UPS. See CHAPTER 8 for information about HOW TO USE THE CONTROL CONSOLE.

---

**Note:** If the UPS connects to a server that uses APC's PowerChute *plus*, you can use PowerChute *plus* to manage the UPS and a Measure-UPS; you cannot use PowerChute *plus* to manage the Management Card in any way (see CHAPTER 4).

---

## Chapter 2:

### User-Interface Components

---

#### AP9606 Web/SNMP Management Card

---

The AP9606 has two status LEDs and a reset button. The reset button allows the user to reset the Management Card, typically when attempting to establish contact between a terminal (or terminal emulator) for Management Card configuration activity (as described in CHAPTER 3).

#### Status LED

This LED reports on the Management Card, the Management Card-to-UPS communication link, or the Management Card-to-SNMP network link, as follows:

- Off - The Management Card has no power.
- Solid green - The Management Card has valid network settings.
- Flashing green - The Management Card does not have valid network settings. See HOW TO DEFINE THE MANAGEMENT CARD'S BASIC NETWORK VALUES in CHAPTER 8.
- Flashing red slowly- The Management Card is making a BOOTP request.
- Solid red - The Management Card has detected a hardware failure.

#### Link-RX/TX LED

The Link-RX/TX LED reports on the following conditions:

- Off - The device(s) which connects the Management Card to the network, whether a router, hub or concentrator, is off or not operating correctly.
- Constant green - Management Card is connected to a functioning network.
- Flashing green - Management Card is receiving data packets from the network.

## Chapter 3:

# How to Define Basic Configuration Requirements

---

This chapter provides an overview of how you can use a BOOTP server, or a terminal, to define the network values a Management Card needs before it can run on the network.

### Overview

---

A Management Card must have three network values defined before that Management Card can function (run its SNMP agent) on a network:

- The system IP address
- The IP address of the router or gateway for the Management Card's network segment
- The subnet mask for the Management Card's network segment

These values can be defined by using a BOOTP server, when BOOTP is enabled (the default condition), or by using the Web/SNMP Management Card Wizard or a terminal (or terminal-emulator), when BOOTP is not being used.

### How to Use a BOOTP Server

---

The Management Card comes with BOOTP enabled. This allows a BOOTP server to provide the Management Card with the basic network values. If a bootup file is specified then the Management Card will attempt to get that file from an FTP or TFTP Server, which is on the same computer as the BOOTP Server. See Chapter 10, Web/SNMP Management Card Wizard, for information on how to create configuration files.

---

**Note:** See your BOOTP documentation for more information about using BOOTP.

---

### How to Use a Terminal

---

If a BOOTP server is unavailable, you will need to use a terminal (or terminal-emulator) to access the Management Card's Control Console to disable BOOTP, and then define the basic network values that allow the Management Card to run on the network. See CHAPTER 8 for information about how to use the Control Console to define the Management Card's basic network values.

### How to Use the Web/SNMP Management Card Wizard

---

If a BOOTP server is unavailable, you can use the Web/SNMP Management Card Wizard to define the basic network values that allow the Management Card to run on the network. See CHAPTER 10 for information about how to use the Wizard to define the Management Card's basic network values.

---

## Chapter 4:

### How to Use a Management Card with PowerChute<sup>®</sup> *plus*

---

How to Use a Management Card with PowerChute<sup>®</sup> *plus*

This chapter provides an overview of how you can use APC's PowerChute *plus* with your Management Card, including a brief description of using PowerChute *plus* for full, local management of a UPS and a Measure-UPS.

---

**Note:** For more information about APC's PowerChute *plus*, see your *PowerChute plus User's Guide*.

---

#### Overview

---

You use PowerChute *plus*, a graphical-user interface-based (GUI-based) UPS monitoring software application, with computer systems that require safe shutdown of applications during a power failure. Usually, PowerChute *plus* communicates with the UPS through a cable connection between the computer system and the UPS serial port. However, when the UPS is using a Management Card mounted in an AP9600, the AP9600 connects to the UPS serial port, and the computer system connects to the AP9600. In this case, the Management Card passes PowerChute *plus* communication through to the UPS without affecting the Management Card. This form of communicating is known as passthrough mode.

#### What PowerChute *plus* Can Do

---

PowerChute *plus* does not use the Management Card, nor does the Management Card use PowerChute *plus*. However, PowerChute *plus* does provide a graphical user interface (GUI) you can use to manage (monitor, control and configure) a UPS and a Measure-UPS (but not a Management Card) locally.

PowerChute *plus* provides for approximately the same level of UPS and Measure-UPS management that you can achieve when using SNMP, APC's PowerNet SNMP Manager application, or the Management Card's Control Console.

#### What PowerChute *plus* Cannot Do

---

PowerChute *plus* cannot manage the Management Card, or the Management Card's network connection: You can only manage a Management Card using SNMP, APC's PowerNet SNMP Manager application, the Management Card's Control Console or Web Interface; you can manage the Management Card's network connection only, using the Management Card's Control Console or Web Interface.

---

**Note:** You can manage the Management Card's trap receiver values using SNMP, PowerNet Manager, the Control Console or Web Interface. You can also use BOOTP to provide network communication values (see CHAPTER 3), and FTP Client, TFTP Client, XMODEM or FTP Server, to download firmware or configuration files. See THE SEPARATE DOWNLOAD.PDF FILE.

---

---

## How to Connect with PowerChute *plus*

---

To install a Management Card with a UPS that connects with a computer system using PowerChute *plus*:

- 1) If PowerChute *plus* is not installed, see the PowerChute *plus* documentation for installation directions. During this installation:
  - a) If the Management Card is already mounted in an AP9600 chassis, ensure that the AP9600 cable is disconnected from the UPS serial port.
  - b) Use the black, smart-signalling cable (940-0024C) which came with the Management Card to connect the computer system to the UPS.
- 2) Once PowerChute *plus* is installed:
  - a) Disconnect the PowerChute *plus* computer system-to-UPS cable from the UPS serial port. Do not disconnect this cable from the computer system. PowerChute *plus* should record the following message in its event log:

### Unable to Communicate with UPS

- b) Install the Management Card in the UPS SmartSlot, or, if the Management Card is going to use an AP9600:
    - 1) Install the Management Card in the AP9600.
    - 2) Connect the AP9600 cable to the UPS serial port.
  - c) See CHAPTER 8 to configure the Management Card to run on the network.
  - d) When you finish configuring the Management Card, connect the PowerChute *plus* cable to the UPS serial port (if the Management Card is installed in the UPS) or to the AP9600 serial port (if the Management Card is installed in this external chassis).
- 3) The installation is complete, and PowerChute *plus* should record this message in its event log:

### Communications established

---

**Note:** If this message does not appear, see **HOW TO CORRECT COMMUNICATION LOST PROBLEMS** in CHAPTER 12.

---



## Chapter 5:

### How to Use SNMP

---

This chapter describes how you can use an SNMP browser's **GET** (read) and **SET** (write) commands for full, remote (over the network) management of the Management Card, its UPS and a Measure-UPS.

#### Overview

---

The simple network management protocol (SNMP) provides a method of using a network to transfer data between two devices:

- Both devices use a management information base (MIB), and that MIB's object identifications (OIDs) as the shared language needed for the communication between the two devices. Two MIBs can be used with the Management Card:
  - MIB-II system OIDs
  - APC's PowerNet SNMP MIB

---

**Note:** In addition to OIDs, the PowerNet MIB has a set of messages (called traps) it can send to up to four defined NMSs when certain events occur.

---

- One device, usually a network management station, uses the MIB's OIDs, through an SNMP browser's **GET** (read) and **SET** (write) commands, to monitor and control the other device.

How much management an NMS can actually perform at a Management Card depends on the MIB used by its SNMP browser, and on the level of SNMP access the Management Card allows for that NMS.

#### How to Affect SNMP Access

---

An NMS can manage a Management Card by using the Card's four SNMP access channels.. By default, a Management Card allows any NMS to use SNMP **GETs** and **SETs** to any one of the four channels, if:

- The Management Card's IP address, along with any alias desired, has been added to the appropriate network configuration files, or to the domain-name server, and a manageable object (icon) for the Management Card's UPS has been added to the appropriate network management map. See your operating system's documentation for more information about performing these functions.
- The NMS uses one of the Management Card's default community strings (passwords) for its **GET (public and public2)** and **SET (private and private2)** commands.

This default condition allows you to use SNMP to manage the Management Card as soon as it is running on the network, but provides no network security. Any NMS can use the PowerNet MIB OIDs to make changes to the Management Card's configuration, or to affect the operation of the Management Card's UPS.

Permission to modify the Management Card's SNMP access channels is granted or denied by using the Control Console.

**Note:** If you know the password, you can use a Telnet console to connect with the Management Card over the network, or a terminal to connect directly to the Management Card to make changes in the Management Card's Control Console or Web Interface. You cannot use SNMP, BOOTP, PowerNet Manager or PowerChute *plus* to change SNMP access values.

Use	To Do this
The <b>Network-&gt;SNMP-&gt;Settings-&gt;SNMP</b> option	Disable SNMP access completely.
The <b>Network-&gt;SNMP-&gt;Access Control 1</b> through <b>Access Control 4</b> options	Change the community string (password) used by an SNMP channel.
The <b>Network-&gt;SNMP-&gt;Access Control 1</b> through <b>Access Control 4</b> options	Allow only a defined NMS access to an SNMP channels.
The <b>Network-&gt;SNMP-&gt;Access Control 1</b> through <b>Access Control 4</b> options	Allow read and write access, read-only access, or disable an SNMP channel.

## How to Use MIB-II System OIDs

An NMS does not need the PowerNet MIB to use the MIB-II system OIDs. If an NMS is allowed access to a Management Card (see the previous NMS SNMP ACCESS section), it can use its SNMP browser with MIB-II system name (**sysName**), system location (**sysLocation**) and system contact (**sysContact**) OIDs.

You cannot use the PowerNet MIB to access the MIB-II system OIDs, but you can use the Management Card's Control Console or a PowerNet SNMP Manager application to modify the MIB-II system OIDs.

## How to Use The PowerNet SNMP MIB

If you want an NMS to use SNMP to access more than MIB-II system OIDs, then the PowerNet MIB must be installed and compiled at that NMS, even when a PowerNet SNMP Manager application is used. The PowerNet Manager does need the PowerNet MIB, but an SNMP browser does.

## The PowerNet MIB and Network Communication

The PowerNet MIB provides for two different types of communications with an NMS:

- If an NMS allowed access to a Management Card (see the previous NMS SNMP ACCESS section), that NMS can use **GETs** and **SETs** to PowerNet MIB OIDs to manage a Management Card and its UPS.
- If an NMS is defined as a trap receiver, the PowerNet MIB allows that NMS to interpret traps (alert, alarm or informational messages) sent to that NMS by a Management Card.

---

**Note:** See the *Network Management Station (NMS) Reference Guide (nms.pdf)*, and your NMS documentation, for information about how to load and compile the PowerNet MIB at your NMS.

---

## The PowerNet MIB OIDs

The PowerNet MIB OIDs allow an NMS to use SNMP to monitor, control and configure most settings for a Management Card, its UPS and Measure-UPS. See Chapter 8 for information on the Control Console.

The rest of this discussion describes what you can and cannot do when using SNMP and the PowerNet MIB OIDs.

---

**Note:** For more information about the PowerNet MIB, its OIDs and traps, see the on-line version of the *PowerNet SNMP Agents - MIB Reference Guide (mibguide.pdf)* which came on a disk with your Management Card.

---

## What PowerNet MIB OIDs Can Do

When you use an SNMP browser with the PowerNet MIB:

You Can	By Using
View and use APC management values: - See if BOOTP is enabled or not. - See how many trap receivers are defined - Modify trap receiver values. - Restart, continue or load a news SNMP Agent. - Define a tftp server's IP address	<b>apcmgmt</b> configuration ( <b>mconfig</b> ) and control ( <b>mcontrol</b> ) OIDs.
Monitor an attached Measure-UPS, including: - Viewing temperature and humidity values. - Modifying contact closure values.	<b>measureUPS</b> OIDs.
Transfer files - New firmware - Configuration files - Via FTP or TFTP Client	<b>mfiletransfer</b> OIDs

You Can	By Using
View UPS identification values: <ul style="list-style-type: none"> <li>- UPS model</li> <li>- UPS name</li> <li>- Firmware revision</li> <li>- Date of manufacture</li> <li>- UPS serial number</li> </ul>	<b>upsIdent</b> (read-only) basic ( <b>upsBasicIdent</b> ) and advanced ( <b>upsAdvIdent</b> ) OIDs.
View UPS battery values: <ul style="list-style-type: none"> <li>- Battery status, temperature and capacity</li> <li>- Time on battery power and runtime remaining</li> <li>- Last replacement date</li> <li>- Number of battery packs and how many are bad</li> </ul>	<b>upsBattery</b> (read-only) basic ( <b>upsBasicBattery</b> ) and advanced ( <b>upsAdvBattery</b> ) OIDs.
View input power (utility voltage) values: <ul style="list-style-type: none"> <li>- Voltage phase, level and frequency</li> <li>- Maximum and minimum voltage sensed</li> <li>- Last cause for a transfer to battery</li> </ul>	<b>upsInput</b> (read-only) basic ( <b>upsBasicInput</b> ) and advanced ( <b>upsAdvInput</b> ) OIDs.
View the current status of the UPS, and its output power values: <ul style="list-style-type: none"> <li>- Voltage phase, level, current and frequency</li> <li>- UPS load</li> </ul>	<b>upsOutput</b> (read-only) basic ( <b>upsBasicOutput</b> ) and advanced ( <b>upsAdvOutput</b> ) OIDs.
Use UPS configuration values to: <ul style="list-style-type: none"> <li>- Select high and low transfer values.</li> <li>- Identify Volts/Amps values for the load equipment.</li> <li>- Select how the UPS alarm will work.</li> <li>- Select how long the UPS will run when a low-battery condition occurs.</li> <li>- Select power return capacity and return delay values.</li> <li>- Select how long the UPS remains on line after being told to shut down (shutdown delay).</li> <li>- Define the duration of a timed sleep by the UPS.</li> <li>- Reset the UPS EEPROM to its factory-default values.</li> <li>- Define a front-panel password.</li> <li>- Select how long before the UPS battery reaches exhaustion will the UPS wait before shutting down (low-battery duration).</li> <li>- Select the UPS output voltage.</li> <li>- Select the UPS sensitivity to input power noise.</li> </ul>	<b>upsConfig</b> basic ( <b>upsBasicConfig</b> ) and advanced ( <b>upsAdvConfig</b> ) OIDs.

You Can	By Using
Use UPS control values to: <ul style="list-style-type: none"> <li>- Turn the UPS on or off.</li> <li>- Put a UPS into sleep mode.</li> <li>- Reboot the UPS.</li> <li>- Put a UPS into bypass mode.</li> <li>- Simulate a power failure.</li> <li>- Test the UPS alarm.</li> </ul>	<b>upsControl</b> basic ( <b>upsBasicBattery</b> ) and advanced ( <b>upsAdvBattery</b> ) OIDs.
Use UPS test values to: <ul style="list-style-type: none"> <li>- Schedule UPS self-tests.</li> <li>- Cause the UPS to perform a self-test.</li> <li>- View the results of the last UPS self-test and runtime calibration.</li> <li>- Start and stop a runtime calibration.</li> </ul>	<b>upsTest</b> basic ( <b>upsBasicTest</b> ) and advanced ( <b>upsAdvTest</b> ) OIDs.
Check on the current status of the Management Card's communication with the UPS.	<b>upsCommStatus</b> , a read-only OID.

### What PowerNet MIB OIDs Cannot Do

The PowerNet MIB OIDs have the following limitations:

You cannot use the PowerNet MIB to Do this	You can only use
Define the network values a Management Card needs before it can run on the network: <ul style="list-style-type: none"> <li>- The Management Card's IP address</li> <li>- The IP address of the network segment's router or gateway.</li> <li>- The network segment's subnet mask value</li> </ul>	A BOOTP server (when BOOTP is enabled), or the Management Card's Control Console (when BOOTP is disabled). See CHAPTER 6 for information about how to use a BOOTP server; See CHAPTER 8 for information on how to use the Control Console.
Define any values for the Management Card's SNMP access channels: <ul style="list-style-type: none"> <li>- Community strings (channel passwords)</li> <li>- Type of access (read or write)</li> <li>- NMS IP addresses</li> </ul>	The Management Card's Control Console (see CHAPTER 8).
Enable or disable access to the Management Card by: <ul style="list-style-type: none"> <li>- SNMP</li> <li>- Telnet</li> <li>- BOOTP</li> <li>- HTTP (Web Interface)</li> </ul>	The Management Card's Control Console (see Chapter 8).

## PowerNet MIB Traps

A Management Card can send alarm or informational messages, known as traps, to specifically defined NMSs. Most NMSs need to use the PowerNet MIB to interpret those traps.

---

**Note:** HP OpenView systems can use the Trap Definition File, which came on the disk with PowerNet MIB, to display intuitive messages.

---

The Management Card allows you to define up to four trap receivers. Each definition includes:

- The community string (password) used for traps (default is **public**).
- The IP address for each NMS defined as a trap receiver.
- Whether the Management Card is enabled or disabled to send traps to a defined NMS.

You can use SNMP, a PowerNet SNMP manager, or the Management Card's Control Console to define trap receivers.

To Change Trap Receiver Definitions	Use
Using The Management Card's Terminal Console	The <b>Trap Receiver 1</b> through <b>Trap Receiver 4</b> options in the Control Console's SNMP menu (see CHAPTER 8).
Using PowerNet MIB OIDs	The APC management <b>mconfigTrapReceiverTable</b> OIDs (see CHAPTER 5).
Using PowerNet SNMP Manager	The options in the SNMP Agent Parameters dialog box (see your <i>PowerNet SNMP Manager User's Guide</i> ).
Using the Web Interface	The SNMP option under the Network menu on the left side of the screen (see CHAPTER 7).

## Chapter 6:

### How to Use a PowerNet SNMP Manager

---

This chapter provides an overview of how you can use APC's PowerNet SNMP Manager for remote (over the network) management of a Management Card, its UPS and a Measure-UPS. For more information about APC's PowerNet SNMP Manager, see your *PowerNet SNMP Manager User's Guide*.

#### Overview

---

PowerNet SNMP Manager provides graphs, display windows, dialog boxes and menus you can use to manage a Management Card, its UPS and a Measure-UPS through the Management Card's connection with the network.

---

**Note:** Currently, APC has PowerNet SNMP Manager applications which can operate with HP OpenView for Windows, SunNet Manager for Solaris, Novell ManageWise, and HP OpenView for UNIX (and other UNIX systems).

---

#### What PowerNet SNMP Manager Can Do

---

PowerNet Manager provides for virtually the same level of management that you can achieve when using SNMP or APC's PowerChute *plus* application.

#### What PowerNet SNMP Manager Cannot Do

---

Although PowerNet Manager can control some aspects of a Management Card's operation, it cannot manage the Management Card's network connection. You can only manage the Card's network connection using the Management Card's Control Console or Web Interface.

---

**Note:** You can also use BOOTP to provide network communication values (see CHAPTER 3), and FTP Client, TFTP Client, XMODEM or FTP Server, to download firmware or configuration files (see THE SEPARATE DOWNLOAD.PDF FILE).

---

## Chapter 7:

### How to use the Web Interface

This chapter provides details of how you can use your Internet Explorer or Netscape browser to manage your UPS or Measure-UPS.

#### Overview

The Management Card allows management of the UPS, Measure-UPS, and Management Card internal operation via an easy-to-use Web Interface. No software installation is required to access the Management Card's Web Interface, except for a standard web browser.

#### Supported Web Browsers


Internet Explorer 3.01 and later

Netscape 3.0 and later


Some features of the Management Card's Web Interface (including data verification, Assistant Online, and MD5 authentication) require that JavaScript be enabled. Additionally, MD5 authentication requires that Java be enabled.

#### How Do I Access the Management Card Using a Web Browser?

At the URL line, enter the System IP address or DNS name (requires a DNS server entry for the Management Card) of the Management Card that you want to manage. Then press <ENTER>.



If the Management Card's Web Port is set to a value other than the default of 80, enter the System IP address followed by a colon and the configured Web Port value (in this example 8000).





## What is Assistant Online?

Assistant Online brings APC Customer Service to the Web. When you click on the Assistant Online logo, the Management Card will transmit information about your UPS and Management Card to APC's Assistant Online server. The server will digest the information and tell you if a newer version of firmware is available, or if your UPS has a bad battery, and how to proceed. Assistant Online can also link you to extensive context-sensitive help. As new features are added to Assistant Online, all you need to do to take advantage of them is to click the logo.

## What Purpose Do the User-Definable Links Serve?

The user-definable links at the bottom of the navigation frame allow you to link together your Management Cards, MasterSwitches, and other Web-enabled devices, allowing more integrated management via the Web interface.

## Does the Management Card Have Local Help Pages?

Yes. The Management Card has its own internal help pages that you can access by selecting Help in the Navigation frame or by clicking the "?" at the end of select black title bars.

## How to Access the Web Interface

---

Use any of the supported Web browsers to access the Web. In the URL Location field, type in `http://` followed by your Management Card's IP address. Press <Enter>.

For example: `http://170.241.17.51`.

## How to Log In

When you enter your Management Card's IP address and press <Enter>, you will be prompted for a user name and password. When prompted:

- 1) Type your user name and press <Enter>.
- 2) Type your password and press <Enter> to access the Management Card's Web Interface main screen (see THE WEB INTERFACE'S MAIN SCREEN).

---

**Note:** Both use `apc`, all lowercase, for their default values. Use the Web Interface's System menu to change the user name, password or timeout values.

---

## How to use the Web Interface

Once you have logged in, the Device Status Summary Screen appears. The column on the left side of the screen displays options that let you access detailed information about the Management Card, its UPS, Measure-UPS and Symmetra. To select a menu option, click on it. Detailed descriptions of each option are discussed later in this chapter.

## Device Status Summary Screen

The Device Status Summary screen contains information about the Management Card, its UPS and Measure-UPS.

This Field	Describes
Smart-UPS	The name of the UPS and its status
Measure-UPS	The Measure-UPS status and whether or not any alarms exist
Web/SNMP Management Card	The Management Card status

**Note:** Use the UPS menu's Alarm Details option to get information about an existing alarm.

## The Smart-UPS Status Screen

Selecting the **Web Interface's** Smart-UPS option accesses a screen that shows Smart-UPS status information and allows you to select the Smart-UPS parameters you want to manage from the left-hand column.

**Web/SNMP Management Card**  
 Card  
 IP: 159.215.6.200

**Smart-UPS 700**  
 Status  
 Diagnostics  
 Control  
 Configuration

**Network**  
**System**  
**Logout**

**Help**

**Links**  
[Arakni\\_201](#)  
[MasterSwitch\\_12](#)  
[Athena](#)

**APC**  
 www.apcc.com

**Smart-UPS 700**

APC HOME CONTACT APC ASSISTANT ONLINE HELP

**Status of Smart-UPS 700 named**

**Describes UPS status**

**On**  
 Serial communication has been established.  
 UPS is on.

**Runtime Remaining :** 9999 Minutes  
**Reason For Last Transfer To Battery :** Due to software command or UPS's test control.  
**Internal Temperature :** 034.6 Degrees Celsius

**Describes utility power status**

**Input Voltage :** 120.2 VAC  
**Input Frequency :** 60.00 Hz  
**Maximum Line Voltage :** 121.5 VAC  
**Minimum Line Voltage :** 120.2 VAC

**Describes output power status**

**Output Voltage :** 120.2 VAC  
**Output Frequency :** 60.00 Hz  
**Load Power :** 000.0 %

**Describes battery status**

**Battery Capacity :** 100.0 %  
**Battery Voltage :** 27.87 VDC  
**Number of Battery Packs :** 255  
**Self-Test Result :** Passed  
**Self-Test Date :** 01/01/1998  
**Calibration Result :** Unknown  
**Calibration Date :** Unknown

**About UPS**

**Model :** Smart-UPS 700  
**Firmware Revision :** 50.9.0 GWD  
**Manufacture Date :** 01/13/97  
**Serial Number :** 1100700269855

For information about the Smart-UPS or Matrix-UPS screens, see [HOW TO MANAGE A SMART-UPS OR MATRIX-UPS](#).

## The Measure-UPS Status Screen

Selecting the **Web Interface's** Measure-UPS option accesses a screen that shows Measure-UPS status information and, in the left-hand column, allows you to select the Measure-UPS parameters you want to manage.

The screenshot displays the 'Measure-UPS Status' screen. On the left is a navigation menu with options: Symmetra, Measure-UPS (Status, Configuration), Network, System, Logout, Help, and Links (Arakni\_200, MasterSwitch\_12, Athena). The main content area features the APC logo, the title 'Measure-UPS', and navigation links: APC HOME, CONTACT APC, ASSISTANT ONLINE, and HELP. The status information is organized into three sections:

Current data reported from probe:	
Temperature :	26.41 Degrees Celcius
High Temperature Violation :	Disabled
Low Temperature Violation :	Disabled
Humidity :	029.6 % Relative Humidity
High Humidity Violation :	Disabled
Low Humidity Violation :	Disabled

Current status of the contacts:	
Device 1 (Contact Zone 1) Alarm :	Disabled
Device 2 (Contact Zone 2) Alarm :	Disabled
Device 3 (Contact Zone 3) Alarm :	Disabled
Device 4 (Contact Zone 4) Alarm :	Disabled

Measure-UPS firmware information:	
Firmware Revision :	4Jx

For information about the Measure-UPS screens, see [HOW TO MANAGE A MEASURE-UPS](#).

## The Network Screen

Selecting the **Web Interface's** `Network` option accesses a screen that shows Network TCP/IP control and status information and, in the left-hand column, allows you to select the Network parameters you want to manage.

The screenshot displays the 'Network' configuration page. On the left is a navigation menu with options like Symmetra, Measure-UPS, Network (selected), TCP/IP, TFTP/FTP, Telnet/Web, SNMP, System, Logout, Help, and Links. The main content area shows the APC logo and 'Assistant online' status. Below a navigation bar (APC HOME, CONTACT APC, ASSISTANT ONLINE, HELP), the 'TCP/IP' section is active. It displays current settings: System IP (159.215.6.201), Subnet Mask (255.255.255.0), Default Gateway (159.215.6.1), and MAC Address (00 C0 B7 B2 74 FD). A configuration section allows editing these values: System IP (159.215.6.201), Subnet Mask (255.255.255.0), Default Gateway (159.215.6.1), and BOOTP (Disabled). 'Apply' and 'Cancel' buttons are at the bottom.

For information about the **Network** screens, see `HOW TO DEFINE THE MANAGEMENT CARD'S BASIC NETWORK VALUES`.

## The System Screen

Selecting the **Web Interface's** *System* option accesses a screen that shows User Manager control and status information and, in the left-hand column, allows you to select the System parameters you want to manage.

The screenshot displays the 'System' configuration page of the APC Management Card. The interface includes a top navigation bar with 'APC HOME', 'CONTACT APC', 'ASSISTANT ONLINE', and 'HELP'. A left sidebar provides navigation for various system functions. The main content area is divided into three sections for configuring user access, administrator settings, and device manager user settings. Each section contains input fields for 'User Name', 'Password', and 'Authentication Phrase', and an 'Auto Logout' field in the first section. 'Apply' and 'Cancel' buttons are available for each configuration section.

For information about the **System Screens**, see **HOW TO MANAGE THE MANAGEMENT CARD'S SYSTEM (INTERNAL) OPERATION**.

## How to Manage a Smart-UPS or Matrix-UPS



When the UPS is a Smart-UPS or a Matrix-UPS and you select either of those options from the left-hand column, a screen appears (for a Smart-UPS 700, in the example below) showing UPS status information. Menu options in the left-hand column allow you to monitor (view operational parameters, identification parameters and alarm and operational status), control and configure a Smart-UPS or a Matrix-UPS.

### The Smart-UPS Status Screen

Web/SNMP  
Management  
Card

IP: 159.215.6.200

- ▼ Smart-UPS 700
  - Status
  - Diagnostics
  - Control
  - Configuration
- ▶ Network
- ▶ System
- Logout
- ▶ Help
- ▼ Links
  - [Arakni\\_201](#)
  - [MasterSwitch\\_12](#)
  - [Athena](#)


Smart-UPS 700


APC HOME
CONTACT APC
ASSISTANT ONLINE
HELP

**Status of Smart-UPS 700 named** ?

*Describes UPS status*

**On**  
Serial communication has been established.  
UPS is on.

<b>Runtime Remaining :</b>	9999 Minutes
<b>Reason For Last Transfer To Battery :</b>	Due to software command or UPS's test control.
<b>Internal Temperature :</b>	034.6 Degrees Celsius

*Describes utility power status*

<b>Input Voltage :</b>	120.2 VAC
<b>Input Frequency :</b>	60.00 Hz
<b>Maximum Line Voltage :</b>	121.5 VAC
<b>Minimum Line Voltage :</b>	120.2 VAC

*Describes output power status*

<b>Output Voltage :</b>	120.2 VAC
<b>Output Frequency :</b>	60.00 Hz
<b>Load Power :</b>	000.0 %

*Describes battery status*

<b>Battery Capacity :</b>	100.0 %
<b>Battery Voltage :</b>	27.87 VDC
<b>Number of Battery Packs :</b>	255
<b>Self-Test Result :</b>	Passed
<b>Self-Test Date :</b>	01/01/1998
<b>Calibration Result :</b>	Unknown
<b>Calibration Date :</b>	Unknown

*About UPS*

<b>Model :</b>	Smart-UPS 700
<b>Firmware Revision :</b>	50.9.D GWD
<b>Manufacture Date :</b>	01/13/97
<b>Serial Number :</b>	WS9702353855

<b>This Field</b>	<b>Describes</b>
<b>DESCRIBES UPS STATUS</b>	
On or Off:	The UPS is "On" or "Off" and whether serial communications has been established.
Runtime Remaining:	How long the UPS can use battery power to support its load equipment before the UPS must shut down.
Reason For Last Transfer To Battery:	What caused the UPS to switch to battery most recently.
Internal Temperature:	The internal temperature of the UPS.
<b>DESCRIBES UTILITY POWER STATUS</b>	
Input Voltage:	The input line (utility) voltage level.
Input Frequency:	The input line (utility) voltage's frequency, in Hertz (Hz, for cycles per second).
Maximum Line Voltage:	The maximum input voltage sensed by the UPS during the last minute of operation.
Minimum Line Voltage:	The minimum input voltage sensed by the UPS during the last minute of operation.
<b>DESCRIBES OUTPUT POWER STATUS</b>	
Output Voltage:	The UPS output voltage level.
Output Frequency:	The output line voltage's frequency, in Hertz (Hz, for cycles per second).
Load Power:	The load placed on the UPS by the attached equipment , expressed as a percentage of the total UPS load capacity.
<b>DESCRIBES BATTERY STATUS</b>	
Battery Capacity:	How much battery capacity, as a percentage of full-capacity, the UPS has available.
Battery Voltage:	The UPS battery voltage level.
Number of Battery Packs:	How many battery packs the UPS has.
Self-Test Result:	The result of the last self-test.
Self-Test Date:	The date of the last self-test.
Calibration Result:	The result of the last runtime calibration.
Calibration Date:	The date of the last runtime calibration.
<b>ABOUT UPS</b>	The model, firmware revision, manufacture date and serial number of the UPS.



## The Smart-UPS Diagnostics Screen

When you select **Diagnostics** from the Smart-UPS menu options in the left-hand column, the following screen appears:

This Field	Describes
<b>DESCRIBES UPS STATUS</b>	
On or Off:	The UPS is "On" or "Off" and whether serial communication has been established.
<b>DESCRIBES UPS DIAGNOSTICS RESULTS</b>	
Self-Test Result:	The result of the last self-test.
Self-Test Date:	The date of the last self-test.
Calibration Result:	The result of the last runtime calibration.
Calibration Date:	The date of the last runtime calibration.

The following fields have options available on pull-down menus:

<b>Use</b>	<b>To Select</b>
<b>INITIATE A UPS DIAGNOSTIC FUNCTION</b>	
Action:	Available options (via pull-down menu) <ul style="list-style-type: none"><li>- No Action</li><li>- UPS Self-Test</li><li>- Simulate Power Failure</li><li>- Start Runtime Calibration</li><li>- Test UPS Alarm</li></ul>
<b>CONFIGURE THE UPS AUTO SELF-TEST SCHEDULE</b>	
Auto Self-Test:	Available options (via pull-down menu) <ul style="list-style-type: none"><li>- Every 7 Days</li><li>- Every 14 Days</li><li>- Never</li><li>- UPS Start-up</li></ul>

## How to Control a UPS

When you select **Control** from the Smart-UPS menu options in the left-hand column, the following screen appears:

View	To
<b>DESCRIBES UPS STATUS</b>	
On or Off:	Display the status of the UPS. In this example, serial communication has been established and the UPS is On .
<b>INITIATE A UPS CONTROL ACTION</b>	
Sleep Time:	Define how long the UPS will sleep in response to either the Put UPS to Sleep, or Put UPS to Sleep Gracefully options in the Control screen menu. The time is defined in hours and in 6-minute (one tenth of an hour) increments.

The **Action** field lets you select from among the following options via a pull-down menu.

<b>Use</b>	<b>To Do This</b>
No Action	Do not initiate any action for the UPS.
Turn UPS On	To cause a UPS which was turned off to turn on again (supply power to its load equipment).
Turn UPS Off	Cause a UPS to turn off immediately (stop supplying power to its load equipment).
Turn UPS Off Gracefully	Signal all servers communicating with the UPS, that are using PowerChute <i>plus</i> , to shut down their operating systems. The UPS waits the amount of time defined by the <code>Low-Battery Duration</code> configuration value for servers to shut down before turning power off (see <code>How to Configure a Smart-UPS or Matrix-UPS</code> ).
Reboot UPS	Cause a UPS to turn off (stop supplying power to its load equipment) and then turn power back on after a specified delay.
Reboot UPS Gracefully	Signal all servers communicating with the UPS, that are using PowerChute <i>plus</i> , to shut down their operating systems. The UPS waits the amount of time defined by the <code>Low-Battery Duration</code> configuration value for servers to shut down before turning power off (see <code>How to Configure a Smart-UPS or Matrix-UPS</code> ).
Put UPS to Sleep	Turn the UPS off for a defined period of time.
Put UPS to Sleep Gracefully	The UPS waits the amount of time set as the <code>Shutdown Delay</code> configuration value for servers to shut down, then puts the UPS to sleep for the defined period of time set as the <code>Sleep Time</code> configuration value (see <code>How to Configure a Smart-UPS or Matrix-UPS</code> ).
Reset UPS to Defaults	Reset the UPS to the default values stored in the Management Card's EEPROM.

## How to Configure a UPS

When you select **Configuration** from the Smart-UPS menu options in the left-hand column, the following screen appears:

**Web/SNMP Management Card**  
IP: 159.215.6.200

**Smart-UPS 700**  
Status  
Diagnostics  
Control  
Configuration

**Network**  
**System**  
**Logout**

**Help**

**Links**  
[Arakni\\_201](#)  
[MasterSwitch\\_12](#)  
[Athena](#)

**APC Smart-UPS 700**  
www.apc.com  
APC HOME CONTACT APC ASSISTANT ONLINE HELP

**Configuration of Smart-UPS 700 named** ?  
Define the utility (line) settings for the UPS

Output Voltage : 115 VAC  
High Transfer Voltage : 129 VAC  
Low Transfer Voltage : 103 VAC  
Sensitivity : Low

Apply Cancel

**Shutdown Parameters** ?  
Define how the UPS behaves on shutdown and restart

Return Battery Capacity : 15 %  
Low-Battery Duration : 10 Minutes  
Shutdown Delay : 180 Seconds  
Return Delay : 300 Seconds  
Sleep Time : 0.0 Hours

Apply Cancel

**General Settings** ?  
Define the general characteristics for the UPS

UPS Name :  
Last Battery Replacement : 11111111  
Audible Alarm : Power Fail+30sec

Apply Cancel

**Note:** A UPS has many other operational parameters that can be modified using either SNMP (see CHAPTER 5), PowerChute *plus* (see CHAPTER 4) or PowerNet SNMP Manager (see CHAPTER 6).

## **Configuration**

The first section of the Configuration screen lets you define the utility line settings for the UPS.

<b>Use</b>	<b>To Do This</b>
Output Voltage:	Define the nominal (basic voltage range) value for UPS output voltage level.
High Transfer Voltage:	Define the maximum voltage level the UPS tolerates before switching to battery power, if the UPS does not have SmartTrim to reduce the input voltage to a level it can use for its output power.
Low Transfer Voltage:	Define the minimum voltage level the UPS tolerates before switching to battery power, if the UPS does not have SmartBoost to reduce the input voltage to a level it can use for its output power.
Sensitivity:	Define how sensitive the UPS is to the input (utility) power's line noise.

## Shutdown Parameters

This section lets you define how the UPS behaves during shutdown and restart. You define each of the following parameters by filling in values or accessing pull-down menus:

Use	To Do this
Return Battery Capacity (%):	Define the percentage of full capacity the UPS batteries must have available before the UPS can go back on line after a power failure shutdown occurs.  <i>Note: The UPS must wait until the time defined by the Return Delay value expires before it can go back on-line.</i>
Low Battery Duration	Define how long (in minutes) the UPS can continue to run on-battery once a low-battery condition occurs. Also, this value defines how long the UPS will wait for servers to shut down in response to Reboot UPS Gracefully, Turn Off UPS Gracefully, and Put UPS to Sleep Gracefully commands (see HOW TO CONTROL A SMART-UPS OR MATRIX-UPS).
Shutdown Delay	Define how long the UPS waits (in seconds) after it receives a shutdown command, before it actually shuts down.
Return Delay	Define how long a UPS that has shut down due to a power failure will wait (in seconds) before it goes back on-line, after the power failure ends.  <i>Note: The UPS must also wait until the battery capacity equals the Return Battery Capacity value.</i>
Sleep Time	Define how long the UPS will sleep in response to using either the Put UPS to Sleep or Put UPS to Sleep Gracefully options in the Control screen menu. The time is defined in hours and in 6-minute (one-tenth of an hour) increments.

## General Settings

The following section lets you define the general characteristics for the UPS:

Use	To Do This
UPS Name	Define the name used by the UPS.
Last Battery Replacement	Identify when the UPS battery was last replaced.
Audible Alarm	Define when the UPS will generate an audible alarm.

## How to Manage a Symmetra Power Array

When the UPS is a *Symmetra Power Array*, the following screen appears when you first login.

The screenshot displays the APC Web/SNMP Management Card interface. On the left is a navigation menu with options: Symmetra, Measure-UPS, Network, System, Logout, Help, and Links (with sub-links: Arakni\_200, MasterSwitch\_12, Athena). The main content area is titled "Device Status Summary" and includes the APC logo and Assistant Online logo. Below the title are navigation links: APC HOME, CONTACT APC, ASSISTANT ONLINE, and HELP. The status summary is divided into three sections:

- Symmetra named Mr\_G**: Describes the UPS status. On, No Alarms Present.
- Measure-UPS**: Describes the Measure-UPS status. Thresholds OK, Contact Alarms OK.
- Web/SNMP Management Card**: Describes the Management Card status.
 

<b>Name :</b>	MR_G Symmetra	<b>Date :</b>	10/29/1998
<b>Contact :</b>	Jim Higgins x6649	<b>Time :</b>	11:30:59
<b>Location :</b>	EP Network Lab	<b>UpTime :</b>	0 Days 0 Hours 46 Minutes
<b>Status :</b>	OK	<b>User :</b>	Administrator

*Symmetra Power Array* status information is displayed in the top half of this screen. Below that is status information for the Measure-UPS and Management Card.



By selecting the *Symmetra* option from the left-hand column, you access the following screen:

**Web/SNMP Management Card**  
IP: 159.215.6.201

**Symmetra**

APC HOME CONTACT APC ASSISTANT ONLINE HELP

**Status of Symmetra named Mr\_G** ?

*Describes UPS status*

**On, No Alarms Present**  
Serial communication has been established.  
UPS is on.

**Runtime Remaining :** 0128 Minutes  
**Reason For Last Transfer To Battery :** Due to software command or UPS's test control.  
**Internal Temperature :** 037.9 Degrees Celsius

*Describes utility power status*

**Input Voltage :** 209.6 VAC  
**Input Frequency :** 59.87 Hz  
**Maximum Line Voltage :** 209.6 VAC  
**Minimum Line Voltage :** 209.6 VAC

*Describes output power status*

**Output Voltage :** 201.3 VAC  
**Output Frequency :** 59.87 Hz  
**Load Power :** 000.0 %  
**Load Current :** 00.00 Amps

*Describes battery status*

**Battery Capacity :** 100.0 %  
**Battery Voltage :** 137.3 VDC  
**Number of Battery Packs :** 002  
**Number of Bad Battery Packs :** 000  
**Self-Test Result :** Passed  
**Self-Test Date :** 01/03/1998  
**Calibration Result :** Unknown  
**Calibration Date :** Unknown

*About UPS*

**Model :** Symmetra  
**Firmware Revision :** 220.A14.1.5Y1  
**Manufacture Date :** 08/12/97  
**Serial Number :** ED9724461315

The menu options in the left-hand column allow you to monitor, control and configure the *Symmetra Power Array*:

- Status
- Detailed Status
- Diagnostics
- Control
- Configuration
- Module Status
- Module Dump

For more information about these menu options, see [HOW TO MONITOR A SYMMETRA POWER ARRAY](#).

The status screen of the Symmetra Power Array shows the following information:

This Field	Describes
<b>DESCRIBES UPS STATUS</b>	
On or Off:	The <i>Symmetra Power Array</i> is "On" or "Off" and if serial communications has been established.
Runtime Remaining:	How long the <i>Symmetra Power Array</i> can use battery power to support its load equipment before it must shut down.
Reason For Last Transfer To Battery:	What caused the <i>Symmetra Power Array</i> to switch to battery power most recently.
Internal Temperature:	The internal temperature of the <i>Symmetra Power Array</i> .
<b>DESCRIBES UTILITY POWER STATUS</b>	
Input Voltage:	The input line (utility) voltage level.
Input Frequency:	The input line (utility) voltage's frequency, in Hertz (Hz, for cycles per second).
Maximum Line Voltage:	The maximum input voltage sensed by the <i>Symmetra Power Array</i> during the last minute of operation.
Minimum Line Voltage:	The minimum input voltage sensed by the <i>Symmetra Power Array</i> during the last minute of operation.
<b>DESCRIBES OUTPUT POWER STATUS</b>	
Output Voltage:	The <i>Symmetra Power Array</i> output voltage level.
Output Frequency:	The output line voltage's frequency, in Hertz (Hz, for cycles per second).
Load Power:	The load placed on the <i>Symmetra Power Array</i> by the attached equipment, expressed as a percentage of the total UPS load capacity.
Load Current:	The output voltage current (Amperage) being drawn (used) by the attached equipment.

This Field	Describes
<b>DESCRIBES BATTERY STATUS</b>	
Battery Capacity:	How much of the battery capacity, as a percentage of full-capacity, the <i>Symmetra Power Array</i> has available for running on battery.
Battery Voltage:	The <i>Symmetra Power Array</i> battery voltage level.
Number of Battery Packs:	How many battery packs the <i>Symmetra Power Array</i> has.
Number of Bad Battery Packs:	The number of faulty power modules.
Self-Test Result:	The result of the last self-test.
Self-Test Date:	The date of the last self-test.
Calibration Result:	The result of the last runtime calibration.
Calibration Date:	The date of the last runtime calibration.
<b>ABOUT UPS</b>	The model, firmware revision, manufacture date and serial number of the <i>Symmetra Power Array</i> .

## Detailed Status Screen

Selecting Detailed Status from the Symmetra menu options in the left-hand column accesses the following screen:

The screenshot shows the Symmetra Web/SNMP Management Card interface. On the left is a navigation menu with options: Symmetra (Status, Detailed Status, Diagnostics, Control, Configuration, Module Status, Module Dump), Measure-UPS, Network, System, Logout, Help, and Links (Arakni\_200, MasterSwitch\_12, Athena). The main content area displays the 'Detailed Status of Symmetra named Mr G' with the following parameters:

Fault tolerance parameters	
Redundancy :	2
Present kVA Capacity :	08.0 kVA
Input power parameters (single phase)	
Input Line Voltage :	209.6 VAC
Input Current :	02.7 Amps
Maximum Input Voltage :	232.2 VAC
Minimum Input Voltage :	232.2 VAC
Output power parameters (single phase)	
Output Voltage :	201.3 VAC
Output Watts in % @ n+0 :	000
Output Watts in % @ n+x :	000
Output VA in % @ n+0 :	007
Output VA in % @ n+x :	007
Battery parameters	
Nominal Battery Voltage :	120.0 VDC
Actual Battery Bus Voltage :	137.2 VDC

This Field	Identifies
<b>FAULT TOLERANCE PARAMETERS</b>	
Redundancy :	The number of Power Modules that can fail or be removed without causing the <i>Symmetra Power Array</i> to switch to bypass.
Present kVA Capacity :	The maximum kVA load of the Symmetra
<b>INPUT POWER PARAMETERS (SINGLE PHASE)</b>	
Input Line Voltage :	The input line (utility) voltage level.
Input Current :	The input line (utility) current.
Maximum Input Voltage :	The highest input voltage sensed during the last minute of operation.
Minimum Input Voltage :	The lowest input voltage sensed during the last minute of operation.
<b>BATTERY PARAMETERS</b>	
Nominal Battery Voltage :	The nominal (basic voltage range) value for the UPS output voltage.
Actual Battery Bus Voltage :	The actual UPS battery voltage level.

## Diagnosics Screen

Selecting the **Diagnosics** option from the Symmetra screen menu in the left-hand column accesses the following screen:

The screenshot shows the Symmetra Web/SNMP Management Card interface. The left sidebar contains navigation options: Symmetra (Status, Detailed Status, Diagnostics, Control, Configuration, Module Status, Module Dump), Measure-UPS, Network, System, Logout, Help, and Links (Arakni\_200, MasterSwitch\_12, Athena). The main content area displays the APC logo, Symmetra title, and Assistant online icon. Below this is a navigation bar with links for APC HOME, CONTACT APC, ASSISTANT ONLINE, and HELP. The main content area is titled "Diagnosics of Symmetra named Mr\_G" and shows "On, No Alarms Present" with a message that serial communication has been established. It also displays diagnostic results for "Number of Bad Battery Packs", "Self-Test Result", "Self-Test Date", "Calibration Result", and "Calibration Date". There are controls to "Initiate a UPS diagnostic function" and "Scheduled Tests".

This Field	Describes
<b>DESCRIBES UPS STATUS</b>	
On or Off:	The UPS as "On" or "Off" and whether serial communication has been established.
<b>DESCRIBES UPS DIAGNOSTICS RESULTS</b>	
Self-Test Result:	The result of the last self-test.
Self-Test Date:	The date of the last self-test.
Calibration Result:	The result of the last runtime calibration.
Calibration Date:	The date of the last runtime calibration.

The following fields have options available on pull-down menus:

<b>Use</b>	<b>To Select</b>
<b>INITIATE A UPS DIAGNOSTIC FUNCTION</b>	
Action:	Available options (via pull-down menu) <ul style="list-style-type: none"> <li>- No Action</li> <li>- UPS Self-Test</li> <li>- Simulate Power Failure</li> <li>- Start Runtime Calibration</li> <li>- Test UPS Alarm</li> </ul>
<b>CONFIGURE THE UPS AUTO SELF-TEST SCHEDULE</b>	
Auto Self-Test:	Available options (via pull-down menu) <ul style="list-style-type: none"> <li>- Every 7 Days</li> <li>- Every 14 Days</li> <li>- Never</li> <li>- UPS Start-up</li> </ul>




## Symmetra Module Status

When you select **Module Status** from the Symmetra menu in the left-hand column, the following screen appears:

Web/SNMP  
Management  
Card

IP: 159.215.6.201

- ▼ **Symmetra**
  - Status
  - Detailed Status
  - Diagnostics
  - Control
  - Configuration
  - Module Status
  - Module Dump
- ▶ **Measure-UPS**
- ▶ **Network**
- ▶ **System**
- Logout**
- ▶ **Help**
- ▼ **Links**
  - [Arakni\\_200](#)
  - [MasterSwitch\\_12](#)
  - [Athena](#)

---

APC HOME
CONTACT APC
ASSISTANT ONLINE
HELP

---

**Module Information of Symmetra named Mr\_G** ?

<b>Intelligence module (IM)</b>	
<b>Status :</b>	On & OK
<b>Master Firmware Revision :</b>	A14
<b>Slave Firmware Revision :</b>	C09
<b>Serial Number :</b>	ED9724461315
<b>Manufacture Date :</b>	08/12/97
<b>Hardware Revision :</b>	NA
<b>Redundant intelligence module (RIM)</b>	
<b>Status :</b>	On & OK
<b>Firmware Revision :</b>	C09
<b>Power module (PM)</b>	
<b>Number of Power Modules :</b>	03
<b>Number of Bad Power Modules :</b>	00
<b>Power Module 1 Status :</b>	On & OK
<b>Power Module 2 Status :</b>	On & OK
<b>Power Module 3 Status :</b>	On & OK
<b>Power Module 1 Firmware Revision :</b>	ABC
<b>Power Module 2 Firmware Revision :</b>	S41
<b>Power Module 3 Firmware Revision :</b>	ABC
<b>Main frame battery parameters</b>	
<b>Main Frame Battery 1 Status :</b>	OK
<b>Main Frame Battery 2 Status :</b>	OK
<b>External frame battery parameters</b>	
<b>Number External Battery Frames :</b>	0

<b>This Field</b>	<b>Identifies</b>
<b>INTELLIGENCE MODULE (IM)</b>	
Status:	The status of the IM.
Master Firmware Revision:	The version number for the IM master firmware.
Slave Firmware Revision:	The version number for the IM slave firmware.
Serial Number:	The IM serial number.
Manufacture Date:	The date the IM was completed by the manufacturer.
Hardware Revision:	The version number for the IM hardware.
<b>REDUNDANT INTELLIGENCE MODULE (RIM)</b>	
Status:	The status of the RIM.
Firmware Revision:	The version number for the RIM firmware.
<b>POWER MODULE (PM)</b>	
Number of Power Modules:	How many power modules the <i>Symmetra Power Array</i> has.
Number of Bad Power Modules:	The number of faulty battery packs.
Power Module 1 Status:	The status of power module 1.
Power Module 2 Status:	The status of power module 2.
Power Module 3 Status:	The status of power module 3.
Power Module 1 Firmware Revision:	The version number for PM 1 firmware.
Power Module 2 Firmware Revision:	The version number for PM 2 firmware.
Power Module 3 Firmware Revision:	The version number for PM 3 firmware.
<b>MAIN FRAME BATTERY PARAMETERS</b>	
Main Frame Battery 1 Status:	The status of main frame battery 1.
Main Frame Battery 2 Status:	The status of main frame battery 2.
<b>EXTERNAL FRAME BATTERY PARAMETERS</b>	
Number External Battery Frames:	How many external battery frames the <i>Symmetra Power Array</i> has.





## Symmetra Module Dump

You can access the following screen by selecting **Module Dump** from the Symmetra menu in the left-hand column. The information provided in this screen is used by APC engineers to trouble-shoot *Symmetra Power Array* hardware problems.

Web/SNMP Management Card  
IP: 159.215.6.201

- ▼ Symmetra
  - Status
  - Detailed Status
  - Diagnostics
  - Control
  - Configuration
  - Module Status
  - Module Dump
- ▶ Measure-UPS
- ▶ Network
- ▶ System
- Logout
- ▶ Help
- ▼ Links
  - [Arakni\\_200](#)
  - [MasterSwitch\\_12](#)
  - [Athena](#)

**Symmetra**

APC HOME    CONTACT APC    ASSISTANT ONLINE    HELP

---

**Module Dump of Symmetra named Mr G** ?

Current raw module dump data

<b>IM Raw Status Data :</b>	State05 Fan0;100 10 001111101;Vint239.0 00000000
<b>RIM Raw Status Data :</b>	011 0 0; ;
<b>PM 1 Raw Status Data :</b>	04 00 67 5B;00 00;87 02 09
<b>PM 2 Raw Status Data :</b>	04 00 67 5B;00 00;87 02 09
<b>PM 3 Raw Status Data :</b>	04 00 67 5B;00 00;87 02 09
<b>Main Frame Raw Status Data :</b>	00.0 00.0;00.6 00.6 1;1.00 1.00 0.00 0.00

## How To Control a Symmetra Power Array

When you select the Control option from the Symmetra menu in the left-hand column, you access the following screen:

The screenshot shows the Symmetra web management interface. On the left is a navigation menu with options like Symmetra, Measure-UPS, Network, System, Logout, Help, and Links. The main content area is titled 'Control of Symmetra named Mr\_G'. It shows the status 'On, No Alarms Present' and a message: 'Serial communication has been established. UPS is on.' Below this is a form to 'Initiate a UPS control action' with a 'Sleep Time' field set to 0.0 Hours and an 'Action' dropdown menu set to 'No Action'. There are 'Apply' and 'Cancel' buttons at the bottom of the form.

View	To
<b>DESCRIBES UPS STATUS</b>	
On or Off:	Display the status of the UPS. In this example, serial communication has been established and the UPS is On .
<b>INITIATE A UPS CONTROL ACTION</b>	
Sleep Time:	Define how long the UPS will sleep in response to either the Put UPS to Sleep, or Put UPS to Sleep Gracefully options in the Control screen menu. The time is defined in hours and in 6-minute (one tenth of an hour) increments.

The **Action** field lets you select from among the following options via a pull-down menu.



<b>Use</b>	<b>To Do This</b>
No Action	Initiate no action for the UPS.
Turn UPS On	Cause a UPS that was turned off to turn back on (supply power to its load equipment again).
Turn UPS Off	Cause a UPS to turn off immediately (stop supplying power to its load equipment).
Turn UPS Off Gracefully	Signal all servers communicating with the UPS, that are using PowerChute <i>plus</i> , to shut down their operating systems. The UPS waits the amount of time defined by the Low-Battery Duration configuration value for servers to shut down before turning power off (see <a href="#">HOW TO CONFIGURE A SMART-UPS OR MATRIX-UPS</a> ).
Reboot UPS	Cause a UPS to turn off (stop supplying power to its load equipment), and then turn power back on after a specified delay.
Reboot UPS Gracefully	Signal all servers communicating with the UPS, that are using PowerChute <i>plus</i> , to shut down their operating systems. The UPS waits the amount of time defined by the Low-Battery Duration configuration value for servers to shut down before turning power off (see <a href="#">HOW TO CONFIGURE A SMART-UPS OR MATRIX-UPS</a> ).
Put UPS to Sleep	Turn the UPS off for a defined period of time.
Put UPS to Sleep Gracefully	The UPS waits the amount of time defined by the Shutdown Delay configuration value, then puts the UPS to sleep for the period of time defined by the Sleep Time configuration value (see <a href="#">HOW TO CONFIGURE A SMART-UPS OR MATRIX-UPS</a> ).
Reset UPS to Defaults	Reset the UPS to the default values stored in the Management Card's EEPROM.
Put UPS in Bypass	Control the use of software bypass.

## How To Configure a Symmetra Power Array

When you select the **Configuration** option from the Symmetra menu in the left-hand column, the following screen appears:

Web/SNMP Management Card  
IP: 159.215.6.201

- ▼ Symmetra
  - Status
  - Detailed Status
  - Diagnostics
  - Control
  - Configuration
  - Module Status
  - Module Dump
- ▶ Measure-UPS
- ▶ Network
- ▶ System
- Logout
- ▶ Help
- ▼ Links
  - [Arakni\\_200](#)
  - [MasterSwitch\\_12](#)
  - [Athena](#)


Symmetra


APC HOME
CONTACT APC
ASSISTANT ONLINE
HELP

---

**Configuration of Symmetra named Mr\_G** ?

Define the utility line settings for the UPS.

Vout Reporting :	<input type="text" value="Auto"/>	VAC
Output Voltage :	<input type="text" value="240"/>	VAC
High Transfer Voltage :	<input type="text" value="276"/>	VAC
Low Transfer Voltage :	<input type="text" value="155"/>	VAC
Sensitivity :	<input type="text" value="Auto"/>	
Output Frequency Range :	<input type="text" value="Auto"/>	Hz
If UPS fails, and frequency or voltage is out of range : <input type="text" value="Goto Bypass"/>		

---

**Alarm Thresholds** ?

Configure the alarm threshold settings.

Alarm If Redundancy Under :	<input type="text" value="n+0"/>	
Alarm If Load Over :	<input type="text" value="00.0"/>	KVA
Alarm If Runtime Under :	<input type="text" value="000"/>	Minutes

---

**Shutdown Parameters** ?

Define how the UPS behaves on shutdown and restart.

Return Battery Capacity :	<input type="text" value="00"/>	%
Low-Battery Duration :	<input type="text" value="02"/>	Minutes
Shutdown Delay :	<input type="text" value="020"/>	Seconds
Return Delay :	<input type="text" value="060"/>	Seconds
Sleep Time :	<input type="text" value="0.0"/>	Hours

---

**General Settings** ?

Define the general characteristics for the UPS.

UPS Name :	<input type="text" value="Mr_G"/>
Last Battery Replacement :	<input type="text" value="01/01/98"/>
Audible Alarm :	<input type="text" value="Off"/>

## **Configuration**

The first section of the Configuration screen lets you define the utility line settings for the UPS.

<b>Use</b>	<b>To Do This</b>
Vout Reporting:	Define how the <i>Symmetra Power Array</i> scales its output voltage readings.
Output Voltage:	Define the nominal (basic voltage range) value for UPS output voltage level.
High Transfer Voltage:	Define the voltage level the UPS uses to determine when it should go on battery power, if the UPS does not have SmartTrim, or use SmartTrim to reduce the input voltage to a level the UPS can use for its output power.
Low Transfer Voltage:	Define the voltage level the UPS uses to determine when it should go on battery power, if the UPS does not have SmartBoost, or use SmartBoost to reduce the input voltage to a level the UPS can use for its output power.
Sensitivity:	Define how sensitive the UPS is to the input (utility) power's line noise.
Output Frequency Range:	Define the nominal value for the frequency of the <i>Symmetra Power Array</i> output frequency range.
If UPS fails, and frequency or voltage is out of range:	Define how the <i>Symmetra Power Array</i> will respond under the stated conditions.

## **Alarm Thresholds**

This section lets you configure the alarm threshold settings. Each of the following parameters is accessed by pull-down menus.

<b>Use</b>	<b>To Do this</b>
Alarm if Redundancy Under:	Define the redundancy threshold. An alarm will occur if the redundancy value drops below this threshold.
Alarm if Load Over:	Define the load threshold. An alarm will occur if the load placed on the <i>Symmetra Power Array</i> by its attached equipment exceeds this threshold.
Alarm if Runtime Under:	Define the runtime available threshold. An alarm will occur if the amount of runtime (in minutes) available drops below this threshold.

## Shutdown Parameters

This section lets you define how the UPS behaves on shutdown and restart. You define each of the following parameters by either filling in values or accessing pull-down menus.

Use	To Do this
Return Battery Capacity:	Define what percentage of full capacity the UPS batteries must have available before the UPS can go back on line once a power failure shutdown occurs.  <i>Note: The UPS must wait until the time defined by the Return Delay value expires before it can go back on-line.</i>
Low Battery Duration	Define how long (in minutes) the UPS can continue to run on-battery once a low-battery condition occurs. Also, this value defines how long the UPS will wait for servers to shut down in response to Reboot UPS Gracefully, Turn Off UPS Gracefully, and Put UPS to Sleep Gracefully commands (see HOW TO CONTROL A SMART-UPS OR MATRIX-UPS).
Shutdown Delay	Define how long you want the UPS to wait (in seconds) after it is told to shut down, before the UPS actually shuts down.
Return Delay	Define how long a UPS that has shut down due to a power failure will wait (in seconds), after the power failure ends, before it goes back on line.  <i>Note: The UPS must also wait until the battery capacity equals the Return Battery Capacity value.</i>
Sleep Time	Define how long the UPS will sleep in response to using either the Put UPS to Sleep or Put UPS to Sleep Gracefully options in the Control screen menu. The time is defined in hours and in 6-minute (one-tenth of an hour) increments.

## General Settings

The following section lets you define the general characteristics for the UPS.

Use	To Do This
UPS Name	Define the name used by the UPS.
Last Battery Replacement	Identify when the UPS battery was last replaced.
Audible Alarm	Define when the UPS will generate an audible alarm.

## How to Manage a Measure-UPS

When you select the Measure-UPS option from the menu on the left side of the main screen, you access the **Measure-UPS** menu screen. You can use this screen to:

- View information about the humidity, temperature and contact switch conditions (monitor the Measure-UPS).
- Define contact switch settings and probe trap thresholds (configure the Measure-UPS).

The screenshot shows the 'Measure-UPS' management interface. On the left is a navigation menu with options: Symmetra, Measure-UPS (Status, Configuration), Network, System, Logout, Help, and Links (Arakni\_200, MasterSwitch\_12, Athena). The main content area features the APC logo and the Assistant logo. Below the logos is a navigation bar with 'APC HOME', 'CONTACT APC', 'ASSISTANT ONLINE', and 'HELP'. The main content is divided into sections:

**Measure-UPS Status** (with a help icon ?)

Current data reported from probe 1

Temperature :	26.41 Degrees Celcius
High Temperature Violation :	Disabled
Low Temperature Violation :	Disabled
Humidity :	029.6 % Relative Humidity
High Humidity Violation :	Disabled
Low Humidity Violation :	Disabled

Current status of the contacts

Device 1 (Contact Zone 1) Alarm :	Disabled
Device 2 (Contact Zone 2) Alarm :	Disabled
Device 3 (Contact Zone 3) Alarm :	Disabled
Device 4 (Contact Zone 4) Alarm :	Disabled

Measure-UPS firmware information

Firmware Revision :	4Jx
---------------------	-----

## How to Monitor a Measure-UPS

The **Measure-UPS** menu screen provides information about the Measure-UPS, and menu options you can use to view more information about the Measure-UPS, temperature and humidity thresholds, and contacts.

### **Measure-UPS Menu Screen's Status Information**

The **Measure-UPS** menu screen reports information about the temperature and humidity values sensed by two Measure-UPS probes.

<b>This Field</b>	<b>Identifies</b>
Temperature:	The temperature (in Celsius) sensed by the Measure-UPS probes.
High Temperature Violation:	Whether the high temperature threshold is disabled, or (when enabled) if the current temperature exceeds the threshold (Yes) or not (No).
Low Temperature Violation:	Whether the low temperature threshold is disabled, or (when enabled) if the current temperature exceeds the threshold (Yes) or not (No).
Humidity:	The relative humidity (as a percentage) sensed by the Measure-UPS probes.
High Humidity Violation:	Whether the high humidity threshold is disabled, or (when enabled) if the current humidity exceeds the threshold (Yes) or not (No).
Low Humidity Violation:	Whether the low humidity threshold is disabled, or (when enabled) if the current humidity exceeds the threshold (Yes) or not (No).

The Measure-UPS status screen also reports information about the status of the four contact switches.

<b>This Field</b>	<b>Identifies</b>
Device 1 (Contact Zone 1) Alarm through Device 4 (Contact Zone 4) Alarm:	The contacts by number and name, and whether a contact alarm is Disabled or (when Enabled) if the contact senses an alarm condition (Yes) or not (No).

This screen also reports the Firmware Version of the Measure-UPS.



## How to Configure a Measure-UPS

When you select the **Configuration** option from the Measure-UPS menu on the left side of the main screen, you access the **Measure-UPS Configuration** screen.

The screenshot shows the 'Measure-UPS' configuration interface. It features a left-hand navigation menu with options like Symmetra, Measure-UPS (selected), Network, System, Logout, Help, and Links. The main content area is titled 'Measure-UPS' and includes the APC logo and 'Assistant online' branding. Below the title are navigation links: APC HOME, CONTACT APC, ASSISTANT ONLINE, and HELP. The configuration is divided into three sections:

- Measure-UPS Probe 1 Settings:** A table for configuring trap thresholds for probe 1. It includes fields for High Temperature (60), Low Temperature (0), High Humidity (90), and Low Humidity (10). Each field has a description and a 'Trap' dropdown menu set to 'Disabled'. 'Apply' and 'Cancel' buttons are at the bottom.
- Measure-UPS Probe 2 Settings:** An identical table for configuring trap thresholds for probe 2.
- Measure-UPS Contact Settings:** A table for configuring names and trap settings for four contact zones. Each zone (1-4) has a 'Name' field (e.g., 'Device 1') and a 'Trap' dropdown menu set to 'Disabled'. 'Apply' and 'Cancel' buttons are at the bottom.

This screen lets you define the Trap Thresholds for Probe 1 or Trap Thresholds for Probe 2 settings. The screen provides two sets of identical options:

Use	To Do this
The Trap Threshold options	Define the high and low temperature (in Celsius), and relative humidity (as a percentage) thresholds the Measure-UPS will use to identify a trap condition.

You can also use this screen to configure the names and trap settings of the Measure-UPS Contacts.

Use	To Do this
Contact 1 Name : through Contact 4 Name :	Define a name for each contact, with each name having up to sixteen (16) characters.
Contact Zone 1 : through Contact Zone 4 :	Enable or disable the contacts.

## How To Define the Management Card's Basic Network Values

Selecting the **Network** option from the menu on the left side of the screen accesses the TCP/IP screen:

The screenshot shows the Web/SNMP Management Card interface. On the left is a navigation menu with options: Symmetra, Measure-UPS, Network (selected), TFTP/FTP, Telnet/Web, SNMP, System, Logout, Help, and Links. The main area is titled 'Network' and features the APC logo and Assistant Online logo. Below the logos are links for APC HOME, CONTACT APC, ASSISTANT ONLINE, and HELP. The 'TCP/IP' section is active, showing a status message: 'The network service has started with the following settings'. Below this, the current settings are listed: System IP: 159.215.6.201, Subnet Mask: 255.255.255.0, Default Gateway: 159.215.6.1, and MAC Address: 00 C0 B7 B2 74 FD. A second section, 'Configure the TCP/IP settings', contains input fields for System IP (159.215.6.201), Subnet Mask (255.255.255.0), Default Gateway (159.215.6.1), and a BOOTP dropdown menu set to 'Disabled'. 'Apply' and 'Cancel' buttons are at the bottom.

The first field of the TCP/IP screen shows the settings with which the network started. The **Configure the TCP/IP Settings** field allows you to enter values for the System IP, Subnet Mask and Default Gateway. It also lets you enable or disable BOOTP.

- With BOOTP enabled (the default), the address values shown in the menu screen come from a BOOTP server, and the menu contains only one option, which you use to disable BOOTP.
- With BOOTP disabled, you must use the menu's three address options (Management Card IP, Subnet Mask and Default Gateway) to define these required network values when you first install the Management Card or whenever you need to change these values.

## How To Control File Transfers

When you select the TFTP/FTP Client option from the Network menu on the left side of the screen, the following screen appears:

The screenshot displays the 'Network' configuration page for the APC Web/SNMP Management Card. The page is divided into three main configuration sections, each with a 'Configure' link and a help icon:

- TFTP Client:** Includes a 'Remote Server IP' field with the value '0.0.0.0' and 'Apply' and 'Cancel' buttons.
- FTP Client:** Includes 'Remote Server IP' (0.0.0.0), 'User Name' (apc), and 'Password' (apc) fields, along with 'Apply' and 'Cancel' buttons.
- FTP Server:** Includes an 'Access' dropdown menu set to 'Enabled' and a 'Port' field set to '21', with 'Apply' and 'Cancel' buttons.

The left-hand navigation menu shows the 'Network' section is currently selected, with sub-options for TCP/IP, TFTP/FTP, Telnet/Web, and SNMP.

Use	To Do This
<b>TFTP CLIENT</b>	
Remote Server IP:	Define the remote server's IP address.
<b>FTP CLIENT</b>	
Remote Server IP:	Define the remote server's IP address.
User Name:	Define the user name.
Password:	Define the password.
<b>FTP SERVER</b>	
Access:	Enable or Disable FTP server access.
Port:	Define the port on which the FTP server for the Management Card resides (default port is 21).

## How To Use the Telnet/Web Menu

When you select the Telnet/Web option from the Network menu on the left side of the screen, the following screen appears:

The screenshot shows the Web/SNMP Management Card interface. On the left is a navigation menu with options: Symmetra, Measure-UPS, Network (selected), System, Help, and Links. The Network menu is expanded, showing sub-options: TCP/IP, TFTP/FTP, Telnet/Web, and SNMP. The main content area is titled 'Network' and contains two configuration sections: 'Telnet' and 'Web'. Each section has a title bar with a question mark, a subtitle 'Configure [service] server access settings', and two input fields: 'Access' (a dropdown menu set to 'Enabled') and 'Port' (a text box containing the value '23' for Telnet and '80' for Web). Below each section are 'Apply' and 'Cancel' buttons.

Use	To Do This
<b>TELNET</b>	
Access :	Enable or Disable Telnet Access.
Port :	Define the port on which the Telnet server for the Management Card resides.
<b>WEB</b>	
Access :	Enable or Disable Web Access.
Port :	Define the port on which the Web server for the Management Card resides.

## How to Use the SNMP Menu

When you select the **Network** menu's SNMP option, you access the **SNMP** screen:

The screenshot shows the Web/SNMP Management Card interface. On the left is a navigation menu with options: Symmetra, Measure-UPS, Network (selected), System, Help, and Links. The main content area is titled 'Network' and contains three configuration sections:

- SNMP**: A section with a title 'Configure SNMP access settings' and a single 'Access' dropdown menu set to 'Enabled'. Below it are 'Apply' and 'Cancel' buttons.
- Access Control**: A section with a title 'Configure SNMP access control settings'. It contains a table with columns: Community Name, NMS IP, and Access Type. There are four rows, each with a text input field for the community name and a dropdown for the access type. Below the table are 'Apply' and 'Cancel' buttons.
- Trap Receiver**: A section with a title 'Configure SNMP trap receiver settings'. It contains a table with columns: Community Name, Receiver NMS IP, Trap Generation, and Authentication Traps. There are four rows, each with text input fields for community name and NMS IP, and dropdowns for trap generation and authentication traps. Below the table are 'Apply' and 'Cancel' buttons.

Use	To Do this
Settings	Enable or disable SNMP access.
Access Control 1 through Access Control 4	Control access to each of the four SNMP channels.
Trap Receiver 1 through Trap Receiver 4	Define which, of up to four NMSs, will be sent traps.

## How to Control SNMP Channel Access

The **SNMP** menu's **Access Control** field lets you:

- Identify the current settings for all four SNMP channels.
- Change the values for a selected channel.

Use	To Do this
1- Community Name :	Define the password (up to 8 characters) the NMS (identified by the NMS IP option ) must use for SNMP access to the Management Card (with the allowed access defined by the Access Type option).
2- NMS IP :	Configure the channel to allow only one NMS (using a specific NMS IP address), or all NMSs (using 0.0.0.0 for the NMS IP value), to have access to the channel.
3- Access Type :	Define whether an NMS (identified by the NMS IP option) can use <b>GETs</b> and <b>SETs</b> (Write), just <b>GETs</b> (Read), or cannot use <b>GETs</b> and <b>SETs</b> at all (Disabled).

## How to Define Trap Receivers

The **SNMP** Trap Receiver options let you:

- Identify the current settings for all four trap receivers.
- Change the values for a selected trap receiver.

Use	To Do this
1- Community Name :	Define the password (up to 8 characters) the Management Card will use when it sends traps to the NMS identified by the Receiver NMS IP option.
2- Receiver NMS IP :	Define the specific NMS (using its IP address) that you want to receive traps sent by the Management Card (0.0.0.0 indicates no traps will be sent to any NMS for this Trap Receiver option).
3- Trap Generation :	Define whether (Enabled) or not (Disabled) the Management Card will send traps to the NMS identified by the Receiver NMS IP option.
4- Authentication Traps :	Define whether (Enabled) or not (Disabled) the Management Card will send authentication traps to the NMS identified by the Receiver NMS IP option.

## How to Manage the Management Card's System (Internal) Operation

### How to Control Access to the Control Console

Selecting the **System** option accesses the following screen:

The screenshot displays the 'System' configuration page of the APC Web/SNMP Management Card. The page is divided into three main sections for configuring user access, administrator settings, and device manager user settings. Each section includes fields for User Name, Password, and Authentication Phrase, along with an Auto Logout timer and Apply/Cancel buttons.

**Web/SNMP Management Card**  
IP: 159.215.6.201

**System**

APC HOME CONTACT APC ASSISTANT ONLINE HELP

**User Manager** ?

**Configure user access settings**

Auto Logout : 10 minute(s)

Authentication : Basic

Apply Cancel

**Configure the administrator settings**

User Name : apc

Password : \*\*\*

Authentication Phrase : <hidden auth. phrase>

Apply Cancel

**Configure device manager user settings**

User Name : apc

Password : \*\*\*

Authentication Phrase : <hidden auth. phrase>

Apply Cancel

**Navigation Menu:**

- Symmetra
- Measure-UPS
- Network
- System
  - User Manager
  - Identification
  - Date/Time
  - File Transfer
  - Tools
  - Links
  - About Card
- Logout
- Help
- Links
  - Arakni\_200
  - MasterSwitch\_12
  - Athena

The User Manager screen lets you define the following parameters:

Use	To Do this
1- Administrator	Define the Administrator user name, password, and authentication phrase. The default Administrator user name is "apc". The default Administrator password is "apc". The default Administrator authentication phrase is "admin user phrase".
2- Device Manager User	Define the Device Manager User name, password, and authentication phrase. The default Device Manager User name is "device". The default Device Manager password is "apc". The default Device Manager authentication phrase is "device user phrase".
3- Auto Logout :	Choose the time, in minutes, it takes the system to automatically logout (default time is 3 minutes).
4- Authentication :	Basic causes the Web Interface to use HTTP 1.1 login; MD5 causes the Web Interface to use an MD5-based authenticated login. See Chapter 11 SECURITY for a detailed explanation.



## How to Define System Identification Values

You use the **System** menu's **Identification** option to define the Management Card's system identification values. Each option shows its current value:

The screenshot displays the configuration interface for the Management Card's system identification. The left sidebar shows the 'System' menu expanded, with 'Identification' selected. The main content area shows the 'Identification' configuration page with the following details:

- Name:** MR\_G Symmetra
- Contact:** Jim Higgins x6649
- Location:** EP Network Lab
- Date/Time:** Date: 10/29/1998, Time: 12:15:46

Use	To Do this
1 - Name :	Define the system name used to identify the Management Card.
2 - Contact :	Define the contact person for Management Card issues.
3 - Location :	Identify the physical location of the management Card.

## How to Set Date and Time Values

You use the **System** menu's **Date/Time** option to define the Management Card's system identification values.

Use	To Do This
Date :	Set the date for the system in dd / mm / yyyy format.
Time :	Set the time for the system in hh / mm / ss format.

## How to Manage File Transfers

You use the **System** menu's **File Transfer** option to manage file transfers:

The screenshot shows the Web/SNMP Management Card interface. On the left is a navigation menu with options like Symmetra, Measure-UPS, Network, System (with sub-options like User Manager, Identification, Date/Time, File Transfer, Tools, Links, About Card), Logout, Help, and Links (with sub-links like Arakni\_200, MasterSwitch\_12, Athena). The main content area is titled 'Network' and features the APC logo and 'Assistant online' status. Below the navigation bar are links for APC HOME, CONTACT APC, ASSISTANT ONLINE, and HELP. The 'File Transfer' section is active, showing a table of current settings: Remote TFTP Server IP (0.0.0.0), Remote FTP Server IP (0.0.0.0), Remote FTP Server User Name (apc), and Remote FTP Server Password (apc). Below this is a 'Filename' field set to 'Unknown' with 'Apply' and 'Cancel' buttons. The 'Result Of Last File Transfer' is 'Successful' and 'Initiate File Transfer Via' is set to 'No Action' with 'Apply' and 'Cancel' buttons.

Use	To Do This
<b>DESCRIBE THE CURRENT TRANSFER SETTINGS</b>	
Remote TFTP Server IP:	Define the IP address of the remote TFTP server.
Remote FTP Server IP:	Define the IP address of the remote FTP server.
Remote FTP Server User Name:	Define the user name of the FTP server.
Remote FTP Server Password:	Define the password of the FTP server.
<b>CONFIGURE THE NAME OF THE FILE TO DOWNLOAD</b>	
File Name:	Enter the name of the file to be downloaded.
<b>INITIATE THE TRANSFER</b>	
Result of Last File Transfer:	View the results of the last file transfer.
Initiate File Transfer Via:	Choose whether the file will be transferred via TFTP or FTP.

## How to Affect the Management Card's SNMP Agent

You use the **System** menu's **Tools** option to affect the Management Card and its SNMP agent:

The screenshot displays the Web/SNMP Management Card interface. On the left is a navigation menu with the following items: Symmetra, Measure-UPS, Network, System (expanded), Logout, Help, and Links. The System menu is expanded to show: User Manager, Identification, Date/Time, File Transfer, Tools, Links, and About Card. The main content area shows the APC logo and the title 'System'. Below the logo are navigation links: APC HOME, CONTACT APC, ASSISTANT ONLINE, and HELP. A 'Tools' section is highlighted, containing a pull-down menu labeled 'Initiate a system action' with a question mark icon. The current selection is 'No Action'. Below the menu are 'Apply' and 'Cancel' buttons.

The following **Actions** are accessed via a pull-down menu:

Use	To Do This
No Action	Cause no action.
Reboot Card	Reinitialize the Management Card's operation.
Reset Card to Defaults	Change Control Console values back to the values currently stored in the Management Card's EEPROM.
Reset Card to Defaults Except TCP/IP	Change Control Console values back to the values currently stored in the Management Card's EEPROM, except for those values designated for TCP/IP.

## How To Define Links

You use the **System** menu's **Links** option to define the links:

The screenshot displays the Web/SNMP Management Card interface. On the left is a navigation menu with options like Symmetra, Measure-UPS, Network, System, and Help. The main area shows the 'System' configuration page with a header for 'System' and navigation links (APC HOME, CONTACT APC, ASSISTANT ONLINE, HELP). Below this are two sections: 'User Links' and 'APC Links'. Each section has a 'Configure the [User/APC] Links' header and a table with 'Name' and 'URL' columns. The 'User Links' table lists 'Arakni .200', 'MasterSwitch .12', and 'Athena' with their respective URLs. The 'APC Links' table lists 'APC Home Page', 'APC Tech Support', 'Management Card Home Page', and 'APC Assistant OnLine' with their respective URLs. Both sections include 'Apply' and 'Cancel' buttons.

Use	To Do This
<b>USER LINKS</b>	
Name :	Define the name of up to three user links.
URL :	Define the URL of each user link.
<b>APC LINKS</b>	
Name :	View the names of the APC links.
URL :	Define the URL of each APC link.

## How To View the Management Card's Identification Values

You use the **System** menu's **About Card** option to view Management Card identification values:

The screenshot displays the Web/SNMP Management Card interface. On the left is a navigation menu with options like Symmetra, Measure-UPS, Network, System, and Help. The main content area shows the 'System' page with the 'About Management Card' section expanded. This section contains three tables of information: Hardware factory information, Application module information, and Platform module information.

Hardware factory information	
Model Number :	AP9606
Serial Number :	WA96DDDDDDDD
Hardware Revision :	F8
Manufacturing Date :	10/05/1998
MAC Address :	00 C0 B7 B2 74 FD

Application module information	
Name :	appl100i.bin
Version :	v1.0.0.i
Date :	10/20/1998
Time :	13:46:09

Platform module information	
Name :	plat100i.bin
Version :	v1.0.0.i
Date :	10/20/1998
Time :	13:45:04

## Chapter 8:

# The AP9606 Management Card Control Console

---

This chapter describes how you can manage a UPS and a Measure-UPS using either Telnet, for remote (over the network) management or a terminal, for local management.

### Overview

---

The Management Card's internal Control Console provides for comprehensive remote and local management of the Management Card, UPS, and Measure-UPS:

- You can use a Telnet console for remote management (access through the network).
- You can use a terminal (or emulator) for local management (access through the Management Card's serial port).

### Control Console Structure

---

The Control Console uses a set of menus to manage the Management Card, its UPS and Measure-UPS:

- All menus list options by number and name. To use an option:
  - 1) Type the option's number.
  - 2) Press <Enter>.
  - 3) Follow any on-screen directions.
- Menus that allow you to configure any Management Card, UPS or Measure-UPS value will have an `Accept Changes` menu option. You must use the `Accept Changes` option, before you exit a menu, if you want to save the changes you made.
- While in a menu, you can also:
  - Press <Enter> to refresh that menu.
  - Press <Esc> to go back to the menu from which you accessed the current menu.
  - Type ?<Enter> to access brief menu option descriptions (if the menu has help available).
  - Use `Ctrl-D` to toggle between UPS and Measure-UPS menus.
  - Use `Ctrl-C` to return to the main (Control Console) menu.

## How to Access the Control Console

Though you can use Telnet or a terminal with the Control Console, whenever you log on, no one else will have access until you log out, or until the Control Console's timeout value expires.

## How to Use Telnet with the Control Console

You can use Telnet, when enabled (the default), to access the Control Console:

- 1) Start the Telnet session. For example, on a Windows-based system, open the Telnet console by typing `telnet` at the DOS-prompt.
- 2) Select the **Remote System...** option from the **Connect** menu.

---

**Note:** If you previously used your Telnet console to connect with a Management Card, the **Connect** menu lists the Management Card's IP address. Select the IP address, instead of **Remote System...**, then see **HOW TO LOG IN**.

---

- 3) When the **Connect** dialog box appears:
  - a) Verify that **Port** field defines `telnet`.
  - b) Make sure the **Term Type** field defines `vt100`.
  - c) Use the Management Card's IP address for the **Host Name**.
  - d) Click **Connect** to access the Control Console.
  - e) Log into the Control Console (see **HOW TO LOG IN**).

## How to Use a Terminal with the Control Console

To use a dumb terminal (or a terminal-emulation application) to access the Control Console:

- 1) Use APC's smart-signalling cable (940-0024C) to connect the terminal port to the serial port at the UPS (if the Management Card mounts in the UPS) or at the AP9600 Smart Slot™ Expansion Chassis or AP9604 Smart Slot™ Triple Chassis (if the Management Card mounts in either of these chassis).
- 2) Ensure the terminal's port uses the following communication settings:

Data Bits: 8	Stop Bits: 1	Parity: None	Handshaking: None
Local Echo: Off	Baud Rate: 2400	Terminal Type: ANSI (VT100)	

To change the communications settings when using HyperTerminal:

- a. Make the needed changes.
- b. Select **Disconnect** in the **Call** menu.
- c. Select **Connect** in the **Call** menu.

You can now connect to the Management Card with the new communication settings in effect.

- 3) Press <Enter> and log into the Control Console (see **HOW TO LOG IN**).

## How to Log In

Whether you use Telnet or a terminal, you log into the Control Console in the same way. When prompted:

- 1) Type your user name and press <Enter>.
- 2) Type your password and press <Enter> to access the Control Console's main screen (see THE CONTROL CONSOLE'S MAIN SCREEN).

---

**Note:** *apc*, all lowercase, is used for the default values of both name and password. Use the Control Console's User Manager -- Administrator and Device Manager User menus to change the Control Console's name, password or timeout values.

---

## The Control Console's Main Screen

The main screen contains information about the Management Card, its UPS and Measure-UPS, and a **Control Console** menu.

```

American Power Conversion                               Web/SNMP Management Card v1.0.0.f
www.apcc.com                                           (c) Copyright 1998 All Rights Reserved
-----
Name      : Unknown                                   Date       : 02/08/1998
Contact   : Unknown                                   Time        : 09:08:33
Location  : Unknown                                   Up Time     : 2 Days 22 Hours 17 Minutes
Status    : P+ N+ A+                                  User        : Administrator

Measure-UPS II : Thresholds OK, Contact Alarms OK
Smart-UPS 700 named UPS_IDEN : On

----- Control Console -----
      1- Device Manager
      2- Network
      3- System
      4- Logout

      ?- Help
<ENTER> Redisplay Menu
<ESC> Refresh Main Menu

> █

```



## Management Card Information

The top two lines of the screen need no explanation. The next three lines provide identification values you can modify:

To Modify	Use
The Management Card's name (Name :), contact (Contact :) and location (Location :) fields. <i>Note: All use Unknown for their default value.</i>	<ul style="list-style-type: none"> <li>- MIB II system OIDs (see CHAPTER 6)</li> <li>- PowerNet SNMP Manager (see CHAPTER 4)</li> <li>- Control Console's <b>System</b> Identification menu</li> <li>- Web Interface System page</li> </ul>
The UPS name <i>Note: The default UPS name is UPS_Iden</i>	<ul style="list-style-type: none"> <li>- PowerNet MIB (<b>upsBasicIdentName</b>) OID (see CHAPTER 6).</li> <li>- PowerNet SNMP Manager (see CHAPTER 4)</li> <li>- PowerChute <i>plus</i> (see CHAPTER 3)</li> <li>- Control Console UPS menu</li> <li>- Web Interface UPS menu</li> </ul>

The UPS name field also provides basic status information about the UPS:

- The present status of the UPS (**On** in this example)
- Whether or not any alarms currently exist

---

**Note: If an alarm exists, check the UPS menu's Detailed Status option to get information about the alarm.**

---

## How to use the Control Console Menu

This menu has an option you can use to log out of the Control Console (4 - Logout). It also has options which access additional console screens.

Use	To Manage
1- Device Manager	The Proxied UPS and Measure-UPS.
2- Network	How the Management Card operates on the Network.
3- System	System Passwords and File Transfer

## Device Manager Menu

Selecting **Device Manager** from the **Control Console** menu accesses a menu that allows you to select the device you want to manage.

**Note:** The 1 option displays the model name of the UPS. In the example below, the UPS is a Smart-UPS 700, but could also be a Matrix-UPS or *Symmetra Power Array*.

```

----- Device Manager -----
      1- Smart-UPS 700
      2- Measure-UPS II

<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

For information on the **Device Manager** menu options, see:

- HOW TO MANAGE A SMART-UPS OR MATRIX-UPS
- HOW TO MANAGE A SYMMETRA POWER ARRAY
- HOW TO MANAGE A MEASURE-UPS

## Network Menu

Selecting **Network** from the **Control Console** menu opens a menu that allows you to select other menus you can use to manage the Management Card's network operation.

```

----- Network -----

      1- TCP/IP
      2- Ping Utility

      File Transfer
      -----
      3- TFTP Client
      4- FTP Client
      5- FTP Server

      Application Protocols
      -----

      6- Telnet
      7- Web
      8- SNMP

<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

For information about the **Network** menu, see HOW TO MANAGE THE MANAGEMENT CARD'S NETWORK CONNECTION.

## System Menu

Selecting `System` from the **Control Console** menu accesses a menu with options you can use to manage the Management Card's system (internal) operation.

```
----- System -----
1- User Manager
2- Identification
3- Date/Time
4- File Transfer
5- Tools
6- About Card

?- Help
<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █
```

For information about the **System** menu, see [HOW TO MANAGE THE MANAGEMENT CARD'S SYSTEM \(INTERNAL\) OPERATION](#).

## How to Manage A UPS

When you select the 1 option in the **Device Manager** menu, you access a set of menus that allow you to do the following:

- View information about UPS operational parameters, identification parameters and alarm conditions (monitor UPS operation).
- Define how you want the UPS to operate, in general (configure UPS operational parameters).
- Control the UPS

Two different sets of menus exist:

- One set for Smart-UPS and Matrix-UPS models
- One set for a *Symmetra Power Array*

For information on how to use the Smart-UPS and Matrix-UPS menus, see [HOW TO MANAGE A SMART-UPS OR MATRIX-UPS](#); for information on how to use the *Symmetra Power Array* menus, see [HOW TO MANAGE A SYMMETRA POWER ARRAY](#).

## How to Manage A Smart-UPS or Matrix-UPS

When the UPS is a Smart-UPS or Matrix-UPS, and you select the 1 option in the **Device Manager** menu, a menu screen appears (for a Smart-UPS 700, in the example below) that allows you to monitor (view operational parameters, identification parameters, and alarm and operational status), control, and configure a Smart-UPS or Matrix-UPS.

```
----- Smart-UPS 700 -----
Status of UPS : On
Last Transfer : Due to software command or UPS's test control.
-----
Input Voltage      : 118.9 VAC      Operating Frequency : 60.00 Hz
Output Voltage     : 118.9 VAC      UPS Internal Temp   : 040.5 C
Load Power         : 003.6 %         Battery Voltage     : 28.01 VDC
Max Line Voltage   : 119.6 VAC      Battery Capacity    : 100.0 %
Min Line Voltage   : 118.3 VAC      Runtime Remaining   : 0203 min
-----
Self-Test Result  : Passed          Calibration Result  : Unknown
Self-Test Date    : 02/03/1998      Calibration Date    : Unknown

1- Control
2- Configuration
3- Detailed Status
4- About UPS

?- Help
<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █
```

## **How to Monitor a Smart-UPS or Matrix-UPS**

The **Smart-UPS** or **Matrix-UPS** menu screen provides UPS status information, and two menu options that allow you to view alarm and operational status (option 3), or identification parameter values (option 4).

### **UPS Menu Screen Status Information**

The **Smart-UPS** or **Matrix-UPS** menu screen displays UPS operational status, UPS input and output voltages, and UPS battery status.

<b>This Field</b>	<b>Identifies</b>
Status of UPS:	The current status of the UPS.
Last Transfer:	What most recently caused the UPS to switch to battery.
Input Voltage:	The utility voltage level.
Output Voltage:	The UPS output voltage level.
Load Power:	The load the attached equipment is placing on the UPS, expressed as a percentage of the total UPS load capacity.
Max Line Voltage:	The maximum input voltage sensed by the UPS during the last minute of operation.
Min Line Voltage:	The minimum input voltage sensed by the UPS during the last minute of operation.
Operating Frequency:	The input line voltage's frequency, in Hertz.
UPS Internal Temperature:	The internal temperature of the UPS.
Battery Voltage:	The UPS battery voltage level.
Battery Capacity:	How much capacity, as a percentage of full-capacity, the UPS has available.
Runtime Remaining:	How long the UPS can support its load equipment before performing a shut down.
Self-Test Result:	The result of the last self-test.
Calibration Result:	The result of the last runtime calibration.

## UPS Menu Status Options

The **UPS** menu provides two options you can use to view additional information about the UPS:

### 3- Detailed Status

This option displays information which expands on the UPS status (Status of UPS field), reports on the status of the Management Card-to-UPS serial communication, and, when an alarm is present, reports that alarm. For the following example, the UPS is on-line, and no communications problem or alarm condition exists:

---

**Note:** When the UPS switches to battery, the Detailed Status screen shows the amount of time that has elapsed since the event.

---

```

----- Detailed Status of Smart-UPS 700 named UPS_IDEN -----
Serial communication has been established.
UPS is on.

Press <ENTER> to continue...█

```

### 4- About UPS

This option accesses UPS identification parameter values. For this Smart-UPS 700 example:

```

----- About Smart-UPS 700 named UPS_IDEN -----
Serial Number      : NS9812029595   Firmware Revision : 50.9.D GWD
Manufacture Date   : 03/21/98
Press <ENTER> to continue...█

```

This Field	Identifies
Serial Number :	The serial number of the UPS.
Firmware Revision :	The version number for firmware used by the UPS.
Manufacture Date :	The date the UPS completed the manufacturing process.

## How to Control a UPS

When you select the `Control` option in a **Smart-UPS** menu, you access the following **Control** menu screen:

**Note:** When you select the `Control` option in a **Matrix-UPS** menu, the **Control** screen menu has an additional option: 12- Put UPS in/Take UPS out of Bypass.

```

----- Control -----
      Status of UPS : On

      1- Turn UPS On
      2- Turn UPS Off
      3- Turn UPS Off Gracefully
      4- Reboot UPS
      5- Reboot UPS Gracefully
      6- Put UPS To Sleep
      7- Put UPS To Sleep Gracefully
      8- Simulate Power Failure
      9- UPS Self-Test
     10- Start/Stop Runtime Calibration
     11- Test UPS Alarm

      ?- Help
<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

Use	To Do this
1- Turn UPS On	Turn the UPS on.
2- Turn UPS Off	Cause a UPS to turn off immediately (stop supplying power to its load equipment).
3- Turn UPS Off Gracefully	Signal all servers communicating with the UPS, and which use <i>PowerChute plus</i> , to shut down their operating systems. The UPS waits the amount of time defined by the <code>Low-Battery Duration</code> configuration value for servers to shut down before turning power off (see <code>HOW TO CONFIGURE A SMART-UPS OR MATRIX-UPS</code> ).
4- Reboot UPS	Cause a UPS to turn off and then turn power back on after a specified delay.

Use	To Do this
5- Reboot UPS Gracefully	Signal all servers using PowerChute <i>plus</i> , and communicating with the UPS, to shut down their operating systems. The UPS waits the amount of time defined by the Low-Battery Duration configuration value for servers to shut down before rebooting the load equipment (see How TO CONFIGURE A SMART-UPS OR MATRIX-UPS).
6- Put UPS to Sleep	Turns the UPS off for a defined period of time.
7- Put UPS to Sleep Gracefully	The UPS waits the amount of time defined by the Shutdown Delay configuration value for servers to shut down, then puts the UPS to sleep for the period of time defined by the Sleep Time configuration value (see HOW TO CONFIGURE A SMART-UPS OR MATRIX-UPS).
8- Simulate Power Failure	Test the ability of the UPS to respond to a power failure by simulating a power failure.
9- UPS Self-Test	Cause a UPS to perform a self-test.
10-Start/Stop Runtime Calibration	Start or stop a process which determines how long the UPS can support the attached equipment using battery power when a power failure occurs.
11-Test UPS Alarm	To verify the UPS alarm works properly.
12-Put UPS in/Take UPS out of Bypass	Control the use of software bypass.  <i>Note: This menu option appears when the Management Card connects with a Matrix-UPS.</i>



## How to Configure a Smart-UPS or Matrix-UPS

When you select the `Configuration` option in a **Smart-UPS** or **Matrix-UPS** menu, you access a **Configuration** menu screen that displays the current values for UPS parameters which you can change using five menu options.

**Note:** A UPS has other operational parameters that can be modified using either SNMP (see CHAPTER 5), PowerChute *plus* (see CHAPTER 4) or PowerNet SNMP Manager (see CHAPTER 6).

```

----- Configuration -----
UPS Name       : UPS_IDEN          Battery Date    : 03/21/98
-----
Output Voltage : 115 VAC           Shutdown Delay  : 020 sec
High Transfer  : 132 VAC           Return Delay    : 000 sec
Low Transfer   : 103 VAC           Low-Battery Duration : 002 min
Sensitivity    : High              Sleep Time      : 0.0 hrs
-----
Auto Self-Test : Every 14 Days     External Batteries : 000
Audible Alarm  : Power Fail        Return Batt Capacity : 000 %

1- Battery
2- Line Transfer
3- Shutdown Parameters
4- General
5- Reset UPS to Defaults

?- Help
<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

Use	To Do this
<p>1- Battery</p> <p><i>Note: See the BATTERY SCREEN description for more information.</i></p>	<p>Modify the Battery Date and Return Battery Capacity values.</p> <p><i>Note: The Battery screen also lists the External Batteries value. However, you cannot modify this value: The External Batteries value only changes when an external battery pack is added to, or removed from, a Matrix-UPS or Smart-UPS XL.</i></p>
<p>2- Line Transfer</p> <p><i>Note: See the LINE TRANSFER SCREEN description for more information.</i></p>	<p>Modify the following values:</p> <p>High Transfer Low Transfer Output Voltage Sensitivity</p>
<p>3- Shutdown Parameters</p> <p><i>Note: See the SHUTDOWN PARAMETERS SCREEN description for more information.</i></p>	<p>Modify the following values:</p> <p>Shutdown Delay Return Delay Low-Battery Duration Sleep Time</p>
<p>4- General</p> <p><i>Note: See the GENERAL SCREEN description for more information.</i></p>	<p>Modify the following values:</p> <p>UPS Name Self-Test Schedule Audible Alarm</p>
<p>5- Reset UPS to Defaults</p> <p><i>Note: No other information is provided about this option.</i></p>	<p>Reset all EEPROM-based UPS parameters to the values stored in the EEPROM at the factory.</p>

## Battery Screen

The 1- Battery option in the **Configuration** screen menu accesses the following screen:

```

----- Battery -----
      Battery Date      : 03/21/98      External Batteries : 000
      Return Batt Capacity : 000 %

      1- Battery Date      : 03/21/98
      2- Return Capacity (%) : 00
      3- Accept Changes      :

      ?- Help
      <ENTER> Redisplay Menu
      <ESC> Return To Previous Menu

      > █
  
```

**Note:** You cannot change the External Batteries value. This value changes only when a Matrix-UPS or Smart-UPS XL senses that a battery pack has been added or removed.

Use	To Do this
1- Battery Date:	Identify when the UPS battery was last replaced.
2- Return Battery Capacity (%):	Define what percentage of full capacity the UPS batteries must have available before the UPS can go back on line once a power failure shutdown occurs.  <i>Note: The UPS must must wait until the time defined by the Return Delay value expires before it can go back on-line.</i>

## Line Transfer Screen

The 2- Line Transfer option in the **Configuration** screen menu accesses the following screen:

```

----- Line Transfer -----
      High Transfer : 132 VAC          Output Voltage : 115 VAC
      Low Transfer  : 103 VAC          Sensitivity     : High

      1- High Transfer (U) : 132
      2- Low Transfer  (U) : 103
      3- Output Voltage (U) : 115
      4- Sensitivity   : High
      5- Accept Changes :

      ?- Help
      <ENTER> Redisplay Menu
      <ESC> Return To Previous Menu

      > █
  
```

Use	To Do this
1- High Transfer:	Define the voltage level the UPS uses to determine when it should switch to battery power, if the UPS does not have SmartTrim, or use SmartTrim to reduce the input voltage to a level the UPS can use for its output power.
2- Low Transfer:	Define the voltage level the UPS uses to determine when it should switch to battery power, if the UPS does not have SmartBoost, or use SmartBoost to increase the input voltage to a level the UPS can use for its output power.
3- Output Voltage:	Define the nominal (basic voltage range) value for UPS output voltage level.
4- Sensitivity:	Define UPS sensitivity to the input (utility) power's line noise.

## Shutdown Parameters Screen

The 3- Shutdown Parameters option in the **Configuration** screen menu displays the following screen:

```

----- Shutdown Parameters -----
Shutdown Delay      : 020 sec      Return Delay       : 000 sec
Low-Battery Duration : 002 min      Sleep Time         : 0.0 hrs

1- Shutdown Delay   (s) : 020
2- Return Delay     (s) : 000
3- Low-Battery Duration (m) : 02
4- Sleep Time       (h) : 0.0
5- Accept Changes   :

?- Help
<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

Use	To Do this
1- Shutdown Delay:	Define, in seconds, how long the UPS waits before it actually shuts down.
2- Return Delay:	Define, in seconds, how long a UPS that has shut down due to a power failure waits, after the power failure ends, before it goes back on line.  <i>Note: The UPS must also wait until the battery capacity equals the Return Battery Capacity value.</i>
3- Low-Battery Duration:	Define (in minutes) how long the UPS can continue to run on-battery once a low-battery condition occurs. Also, this value defines how long the UPS waits for servers to shut down in reponse to Reboot UPS Gracefully, Turn Off UPS Gracefully, and Put UPS to Sleep Gracefully commands (see HOW TO CONTROL A SMART-UPS OR MATRIX-UPS).
4- Sleep Time:	Define how long the UPS will sleep in response to the Put UPS to Sleep or Put UPS to Sleep Gracefully option in the <b>Command</b> screen Menu. The time is defined in hours and in 6-minute (one-tenth of an hour) increments.

## General Screen

The 4- General option in the **Configuration** screen menu accesses the following screen:

```

----- General -----
      UPS Name      : UPS_IDEN          Auto Self-Test : Every 14 Days
      Audible Alarm : Power Fail

      1- UPS Name      : UPS_IDEN
      2- Self-Test Schedule : 14 Days
      3- Audible Alarm : Pwr Fail
      4- Accept Changes :

      ?- Help
      <ENTER> Redisplay Menu
      <ESC> Return To Previous Menu

      > █
  
```

Use	To Do this
1- UPS Name:	Assign a name to the UPS.
2- Self-Test Schedule:	Define when the UPS will perform self-tests.
3- Audible Alarm:	Define when the UPS will generate an audible alarm.

## How to Manage A Symmetra Power Array

When the UPS is a *Symmetra Power Array*, and you select the 1 option in the **Device Manager** menu, a **Symmetra** menu screen appears. This screen, shown below, has the following major elements:

- The screen displays *Symmetra Power Array* status information in the top half of the screen. For more information, see *HOW TO MONITOR A SYMMETRA POWER ARRAY*.
- Four menu options allow access to more status information about the *Symmetra Power Array*:
  - 3- Detailed UPS Information
  - 4- Scheduled Tests
  - 5- Module Diagnostics & Information
  - 6- Faults & Alarms

For more information about the menu options listed above, see *HOW TO MONITOR A SYMMETRA POWER ARRAY*.

- The 1- *Control* option accesses a set of screens you can use to control the operation of the *Symmetra Power Array*. For more information, see *HOW TO CONTROL A SYMMETRA POWER ARRAY*.
- The 2- *Configuration* option accesses a set of screens you can use to modify how the *Symmetra Power Array* operates. For more information, see *HOW TO CONFIGURE A SYMMETRA POWER ARRAY*.

```

----- Symmetra -----
Status of UPS      : On, No Alarms Present
Last Transfer     : Due to software command or UPS's test control.
-----
Input Voltage     : 209.6 VAC           Load Power       : 000.0 %
Input Frequency   : 59.97 Hz          Battery Capacity  : 100.0 %
Output Voltage    : 202.8 VAC         Runtime Remaining : 0128 min
-----
Self-Test Result  : Passed             Calibration Result : Unknown
Self-Test Date    : 10/07/1998        Calibration Date  : Unknown

1- Control
2- Configuration
3- Detailed UPS Information
4- Scheduled Tests
5- Module Diagnostics & Information
6- Faults & Alarms

?- Help
<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

### How to Monitor a Symmetra Power Array

The **Symmetra** menu screen provides a status display and four menu options that allow you to view additional information about the *Symmetra Power Array*. For information about the **Symmetra** screen status display, see SYMMETRA SCREEN STATUS DISPLAY; for information about the four menu options you can use to access additional status information, see the sections identified in the following list:

- 3- Detailed UPS Information (See DETAILED STATUS SCREEN.)
- 4- Scheduled Tests (See SCHEDULED TESTS SCREEN.)
- 5- Module Diagnostics & Information (See MODULE DIAGNOSTICS & INFORMATION SCREEN.)
- 6- Faults & Alarms (See FAULTS & ALARMS SCREEN.)

### **Symmetra Screen Status Display**

The **Symmetra** screen reports the following information about the operational status, input and output voltages, battery status, self-test, and calibration results for the *Symmetra Power Array*:

<b>This Field</b>	<b>Identifies</b>
Status of UPS:	The current status of the UPS.
Last Transfer:	What most recently caused the UPS to switch to battery.
Input Voltage:	The utility voltage level.
Input Frequency:	The input line (utility) voltage's frequency, in Hertz (Hz, for cycles per second).
Output Voltage:	The UPS output voltage level.
Load Power:	The load the attached equipment is placing on the UPS, expressed as a percentage of the total UPS load capacity.
Battery Capacity:	How much capacity, as a percentage of full-capacity, the UPS has available.
Runtime Remaining:	How long the UPS can support its load equipment before performing a shut down.
Self-Test Result:	The result of the last self-test.
Calibration Result:	The result of the last runtime calibration.



## Detailed Status Screen

Selecting the 3- Detailed UPS Information option in the **Symmetra** screen menu accesses the following screen, which expands on the Status of UPS: information provided in the **Symmetra** screen. In the following example, Serial communication has been established. UPS is on. The screen provides information on a wide range of other *Symmetra Power Array* status values.

**Note:** When the UPS switches to battery, the amount of time that has elapsed appears in the Detailed Status screen.

```

----- Detailed Status of Symmetra named Mr_G -----
IM Status      : On & OK           Internal Temperature : 037.6 C
RIM Status     : On & OK
-----
Output Frequency : 59.83 Hz        Maximum Line Voltage : 209.6 VAC
Load Current    : 00.00 Amps       Minimum Line Voltage : 209.6 VAC
-----
Power Modules   : 03               Redundancy           : n+2
Number Bad     : 00               Alarm if Under       : n+0
Load Capacity  : 08.0 kVA         Load @ n+0 Redundancy : 007 %
Alarm if Over  : 00.0 kVA        Load @ n+0 Redundancy : 007 %
-----
Ext Batt Frames : 0               Battery Capacity     : 100.0 %
Batteries      : 002             Runtime Remaining    : 0128 min
Number Bad     : 000             Alarm if Under       : 0000 min
Voltage        : 137.3 UDC

Serial communication has been established.
UPS is on.

Press <ENTER> to continue...

```

This Field	Identifies
IM Status:	The Intelligence Module (IM) is on and operational (OK).
RIM Status:	The Redundant Intelligence Module (RIM) is on and operational (OK).
Internal Temperature:	The internal temperature of the <i>Symmetra Power Array</i> (in Celcius).
Output Frequency:	The frequency of the voltage the <i>Symmetra Power Array</i> is providing to its attached equipment.
Load Current:	The output voltage current (Amperage) being used by the attached equipment.
Maximum Line Voltage:	The highest input voltage sensed during the previous minute of operation.

This Field	Identifies
Minimum Line Voltage:	The lowest input voltage sensed during the previous minute of operation.
Power Modules:	How many power modules the <i>Symmetra Power Array</i> has.
Number Bad: (listed under Power Modules)	The number of faulty power modules.
Load Capacity:	The maximum load capacity for the <i>Symmetra Power Array</i> , in kiloVolts per Amp (kVA).
Alarm if Over:	The load threshold, in kiloVolts per Amp (kVA).  <i>Note: The Symmetra Power Array will generate an alarm if the attached equipment exceeds this threshold.</i>
Redundancy:	The number of Power Modules that can fail or be removed without causing the <i>Symmetra Power Array</i> to switch to bypass.
Alarm if Under: (listed under Redundancy)	The redundancy threshold for the <i>Symmetra Power Array</i> .  <i>Note: The Symmetra Power Array will generate an alarm if the redundancy level falls below this value.</i>
Load @ n+0 Redundancy:	The percentage of the load relative to the total number of working Power Modules.
Load @ n+r Redundancy:	The percentage of the load relative to the total number of working Power Modules, minus the redundancy alarm level (0, 1, or 2). A value of 100% equals the redundancy alarm point.
Batteries:	The total number of battery packs used by the <i>Symmetra Power Array</i> .
Number Bad: (listed under Batteries)	The number of faulty battery packs.
Voltage:	The voltage that the <i>Symmetra Power Array</i> batteries can supply, in volts DC (VDC).

This Field	Identifies
Battery Capacity:	The percentage of full battery capacity the <i>Symmetra Power Array</i> currently has available for supporting its attached equipment if a power failure occurs.
Runtime Remaining:	The amount of time the <i>Symmetra Power Array</i> can use battery power to keep its attached equipment powered during a power failure.
Alarm if Under: (listed under Runtime Remaining)	The minimum runtime the <i>Symmetra Power Array</i> can have available without generating an alarm.

### Scheduled Tests Screen

Selecting the 4- *Scheduled Tests* option in the **Symmetra** screen menu accesses the following screen that allows you to define how often you want the *Symmetra Power Array* to perform self-tests:

```

----- Scheduled Tests -----
      Auto Self-Test : Every 14 Days

      1- Auto Self-Test : 14 Days
      2- Accept Changes :

      ?- Help
<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

## Module Diagnostics & Information Screen

Selecting the 5- Module Diagnostics & Information option in the **Symmetra** screen menu accesses the following screen:

```

----- Module Diagnostics & Information -----
1- Intelligence Module
2- Redundant Intelligence Module
3- Power Modules
4- Batteries
5- Dump All Module Data

?- Help
<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

This screen has menu options that allow you to access status information about different *Symmetra Power Array* components, as follows:

### 1- Intelligence Module

This option displays a screen that provides status information and identification parameters for the Intelligence Module used by the *Symmetra Power Array*:

```

----- Intelligence Module -----
IM Status      : On & OK           Master Firmware Rev : A14
Serial Number   : ED9724461315    Slave Firmware Rev  : C09
Manufacture Date : 08/12/97       Hardware Rev        : NA
-----
Raw Status Data : State05 Fan0;100 10 00111101;Uint240.8 00000000
Press <ENTER> to continue...█

```

This Field	Identifies
IM Status:	The status of the Intelligence Module.
Serial Number:	The IM serial number.
Manufacture Date:	The date the IM was completed by the manufacturer.
Master Firmware Rev:	The version number for the IM master firmware.
Slave Firmware Rev:	The version number for the IM slave firmware.
Hardware Rev:	The version number for the IM hardware.
Raw Status Data:	Information used by APC Engineers to trouble-shoot <i>Symmetra Power Array</i> hardware problems.

## 2- Redundant Intelligence Module

This option accesses a screen that provides status and identification parameters information for the Redundant Intelligence Module (RIM) used by the *Symmetra Power Array*:

```

----- Redundant Intelligence Module -----
RIM Status      : On & OK
Serial Number   : NA           Firmware Rev    : C09
Manufacture Date : NA           Hardware Rev   : NA
-----
Raw Status Data : 011 0 0; ;
Press <ENTER> to continue...

```

This Field	Identifies
RIM Status:	The status of the Redundant Intelligence Module.
Serial Number:	The RIM serial number.
Manufacture Date:	The date the RIM was completed by the manufacturer.
Firmware Rev:	The version number for the RIM firmware.
Hardware Rev:	The version number for the RIM hardware.
Raw Status Data:	Information used by APC Engineers to trouble-shoot <i>Symmetra Power Array</i> hardware problems.

## 3- Power Modules

This option accesses a screen that has menu options you can use to view status and identification parameters information for each Power Module (PM) used by the *Symmetra Power Array*:

```

----- Power Modules -----
1- Power Module 1 : On & OK
2- Power Module 2 : On & OK
3- Power Module 3 : On & OK

<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

Each option displays a screen that provides a single menu option (1- Flash LED) and the same status and identification parameter information, in the same format, for each Power Module (PM).

```

----- Power Module 1 -----
PM Status      : On & OK
Serial Number  : NA           Firmware Rev   : ABC
Manufacture Date : NA           Hardware Rev  : NA
-----
Raw Status Data : 04 00 67 5B;00 00;87 02 09

1- Flash LED

?- Help
<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

The 1- Flash LED option will cause the Flash LED for the Power Module to blink on and off for several seconds.

This Field	Identifies
PM Status:	The status of the Power Module.
Serial Number:	The PM serial number.
Manufacture Date:	The date the PM completed the manufacturing process.
Firmware Rev:	The version number for the PM firmware.
Hardware Rev:	The version number for the PM hardware.
Raw Status Data:	Information used by APC Engineers to trouble-shoot <i>Symmetra Power Array</i> hardware problems.

## 4- Batteries

This option accesses a screen which provides `Raw Status Data` for the batteries, as a whole, and individual status reports for each *Symmetra Power Array* battery:

---

**Note:** The `Raw Status Data` provides information used by APC Engineers to troubleshoot *Symmetra Power Array* problems.

---

```

----- Main Frame -----
Raw Status Data   : 00.0  00.0;00.5  00.5  1;1.00 1.00 0.00 0.00
-----
Battery R2 Status : OK
Battery R3 Status : OK

Press <ENTER> to continue...

```

## 5- Dump All Module Data

This option displays the status information displayed for all of the other options.

### Faults & Alarms Screen

Selecting the 6-Faults & Alarms option in the **Symmetra** screen menu accesses the following screen:

```

----- Faults & Alarms of Symmetra named Mr_G -----
No alarms to report.

Press <ENTER> to continue...

```

## How to Control a Symmetra Power Array

When you select the 1- Control option in the **Symmetra** menu, the following **Control** menu screen is displayed:

```

----- Control -----
      Status of UPS : On, No Alarms Present

      1- Turn UPS On
      2- Turn UPS Off
      3- Turn UPS Off Gracefully
      4- Reboot UPS
      5- Reboot UPS Gracefully
      6- Put UPS To Sleep
      7- Put UPS To Sleep Gracefully
      8- Simulate Power Failure
      9- UPS Self-Test
     10- Start/Stop Runtime Calibration
     11- Put UPS in/Return UPS from Bypass

      ?- Help
    <ENTER> Redisplay Menu
    <ESC> Return To Previous Menu

    > █
  
```

Use	To Do this
1- Turn UPS On	Turn the UPS on.
2- Turn UPS Off	Cause a UPS to turn off immediately (stop supplying power to its load equipment).
3- Turn UPS Off Gracefully	Signal all servers using PowerChute <i>plus</i> and communicating with the UPS, to shut down their operating systems. The UPS waits the amount of time defined by the Low-Battery Duration configuration value for servers to shut down before turning power off. See <b>How to Configure a Symmetra Power Array</b> .



Use	To Do this
4- Reboot UPS	Cause a UPS to turn off and then turn power back on after a specified delay.
5- Reboot UPS Gracefully	Signal all servers using PowerChute <i>plus</i> and communicating with the UPS to shut down their operating systems. The UPS waits the amount of time defined by the Low-Battery Duration configuration value for servers to shut down before rebooting the load equipment. See HOW TO CONFIGURE A SYMMETRA POWER ARRAY.
6- Put UPS to Sleep	Turns the UPS off for a defined period of time.
7- Put UPS to Sleep Gracefully	The UPS waits the amount of time set as the Shutdown Delay value for servers to shut down, then puts the UPS to sleep for the period of time defined by the Sleep Time configuration value. See HOW TO CONFIGURE A SYMMETRA POWER ARRAY.
8- Simulate Power Failure	Test the ability of the UPS to respond to a power failure by simulating a power failure.
9- UPS Self-Test	Cause a UPS to perform a self-test.
10-Start/Stop Runtime Calibration	Start or stop a process which determines how long the UPS can support the attached equipment using battery power when a power failure occurs.
11-Put UPS in/Return UPS from Bypass	Control the use of software bypass.

## How to Configure a Symmetra Power Array

When you select the 2- Configuration option in the **Symmetra** menu, you access a **Configuration** menu screen that displays the current values for UPS parameters that you can change using five menu options.

**Note:** A UPS has other operational parameters which can be modified using either SNMP (see CHAPTER 5), PowerChute *plus* (see CHAPTER 4) or PowerNet SNMP Manager (see CHAPTER 6).

```

----- Configuration -----
Output Voltage      : 240 VAC          Alarm if Redundancy Under : n+0
Vout Reporting     : Auto             Alarm if Runtime Under   : 000 min
Output Freq Range  : Auto             Alarm if Load Over      : Never
-----
If UPS fails, and frequency or voltage is out of range : Goto Bypass
-----
Shutdown Delay     : 020 sec          Low-Battery Duration     : 002 min
Return Delay       : 060 sec          Sleep Time               : 0.0 hrs
Auto Self-Test     : Every 14 Days    Return Battery Capacity  : 000 %
UPS Name           : Mr_G             Last Battery Replacement : 01/01/97

1- Utility Line
2- Alarm Thresholds
3- Shutdown Parameters
4- General
5- Reset UPS to Defaults

?- Help
<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

Use	To Do this
1- Utility Line  <i>Note: See the UTILITY LINE SCREEN description for more information.</i>	Modify the following operational parameter values:  Output Voltage Vout Reporting Output Freq Range Freq/Volt Overload
2- Alarm Thresholds  <i>Note: See the ALARM THRESHOLDS SCREEN description for more information.</i>	Modify the following values:  Alarm if Redundancy Under Alarm if Runtime Under Alarm if Load Over

Use	To Do this
3- Shutdown Parameters  <i>Note: See the SHUTDOWN PARAMETERS SCREEN description for more information.</i>	Modify the following values:  Return Battery Capacity Low-Battery Duration Shutdown Delay Return Delay Sleep Time
4- General  <i>Note: See the GENERAL SCREEN description for more information.</i>	Modify the following values:  UPS Name Last Battery Replacement
5- Reset UPS to Defaults  <i>Note: No other information is provided about this option.</i>	Reset all EEPROM-based UPS parameters to the values stored in the EEPROM at the factory.

### Utility Line Screen

The 1- Utility Line option in the **Configuration** screen menu displays the following:

```

----- Utility Line -----
      IF UPS fails, and frequency or voltage is out of range : Goto Bypass
-----
Output Voltage : 240 VAC           Output Freq Range : Auto
Vout Reporting : Auto

1- Output Voltage      : 240
2- Vout Reporting     : Auto
3- Output Freq Range  : Auto
4- Freq/Volt Overload : Goto Byp
5- Accept Changes     :

?- Help
<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █
  
```

Use	To Do this
1- Output Voltage:	Define the nominal value for the <i>Symmetra Power Array</i> output voltage.
2- Vout Reporting:	Define how the <i>Symmetra Power Array</i> scales its output voltage readings.
3- Output Freq Range:	Define the nominal value for the frequency of the <i>Symmetra Power Array</i> output frequency range.
4- Freq/Volt Overload:	Define how the <i>Symmetra Power Array</i> will respond if it fails due to out-of-range frequency or voltage.

### Alarm Thresholds Screen

The 2- Alarm Thresholds option in the **Configuration** screen menu accesses the following screen:

```

----- Alarm Thresholds -----
      Alarm if Redundancy Under : n+0           Alarm if Load Over : Never
      Alarm if Runtime Under   : 000 min

      1- Alarm if Redundancy Under : 0
      2- Alarm if Runtime Under   : 000
      3- Alarm if Load Over      : Never
      4- Accept Changes          :

      ?- Help
      <ENTER> Redisplay Menu
      <ESC> Return To Previous Menu

      > █

```

Use	To Do this
1- Alarm if Redundancy Under:	Define the redundancy threshold. An alarm will occur if the redundancy value drops below this threshold.
2- Alarm if Runtime Under:	Define the runtime available threshold. An alarm will occur if the amount of available runtime, expressed in minutes, drops below this threshold.
3- Alarm if Load Over:	Define the load threshold. An alarm will occur if the load placed on the <i>Symmetra Power Array</i> by its attached equipment exceeds this threshold.

## Shutdown Parameters Screen

The 3- Shutdown Parameters option in the **Configuration** screen menu displays the following:

```

----- Shutdown Parameters -----
Shutdown Delay : 020 sec           Low-Battery Duration   : 002 min
Return Delay   : 060 sec           Return Battery Capacity : 000 %
Sleep Time     : 0.0 hrs

1- Return Batt Capacity : 00
2- Low-Battery Duration : 02
3- Shutdown Delay      : 020
4- Return Delay        : 060
5- Sleep Time          : 0.0
6- Accept Changes      :

?- Help
<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

Use	To Do this
1- Return Battery Capacity:	Define the percentage of full battery capacity the <i>Symmetra Power Array</i> must have available before it can go back on line after being turned off.  <i>Note: The UPS must also wait until the time set as the Return Delay value expires.</i>
2- Low-Battery Duration:	Define how long (in minutes) the <i>Symmetra Power Array</i> can continue to run on-battery once a low-battery condition occurs. Also, this value defines how long the UPS waits for servers to shut down in reponse to Reboot UPS Gracefully, Turn Off UPS Gracefully, and Put UPS to Sleep Gracefully commands. See How to CONTROL A SYMMETRA POWER ARRAY.
3- Shutdown Delay:	Define how long, in seconds, the UPS waits after it receives the shutdown command, before the UPS actually shuts down.

Use	To Do this
4- Return Delay:	Define, in seconds, how long a UPS waits before going back on-line when power is restored.  <i>Note: The UPS must also wait until the battery capacity equals the Return Battery Capacity value.</i>
5- Sleep Time:	Define how long the UPS will sleep in response to using either the Put UPS to Sleep or Put UPS to Sleep Gracefully options in the <b>Command</b> screen Menu. The time is defined in hours and in 6-minute (one-tenth of an hour) increments.

### General Screen

The 4- General option in the **Configuration** screen menu accesses the following screen:

```

----- General -----
      UPS Name : Mr_G                Last Battery Replacement : 01/01/97

      1- UPS Name           : Mr_G
      2- Last Battery Replacement : 01/01/97
      3- Accept Changes      :

      ?- Help
      <ENTER> Redisplay Menu
      <ESC> Return To Previous Menu

      > █

```

Use	To Do this
1- UPS Name :	Assign a name to the UPS.
2- Last Battery Replacement :	Identify the date of the last battery replacement for the <i>Symmetra Power Array</i> .

### Reset UPS to Defaults Screen

The 5- Reset UPS to Defaults option in the **Configuration** screen menu displays a screen that lets you reset the UPS to its default settings.

```

----- Reset UPS to Defaults -----

      This command will immediately reset UPS eeprom values.

      Enter 'YES' to continue or <ENTER> to cancel : █

```

## How to Manage a Measure-UPS

The **Measure-UPS** option in the **Device Manager** menu opens the **Measure-UPS** menu screen. You can use this screen to:

- View information about the humidity, temperature and contact switch conditions. See *How To Monitor the Measure-UPS*.
- Set contact switch settings and probe trap thresholds. See *How To Configure the Measure-UPS*).

```

----- Measure-UPS II -----
      Probe 1 : 23.87 C, 030.4 %RH          Probe 2 : NA    C, NA    %RH
      -----

      Current Status :
      Threshold Violation Present, Contact Alarms OK

      1- Trap Thresholds Probe 1
      2- Trap Thresholds Probe 2
      3- Contact Settings
      4- Threshold And Contact Details
      5- About Measure-UPS

      ?- Help
      <ENTER> Redisplay Menu
      <ESC> Return To Previous Menu

      > █
  
```

## How to Monitor a Measure-UPS

The **Measure-UPS** menu screen provides information about the Measure-UPS, and displays the menu options you can use to view more information about the Measure-UPS, temperature and humidity thresholds, and contacts.

### Measure-UPS Menu Screen's Status Information

The **Measure-UPS** menu screen reports information about the Measure-UPS operational status, and the temperature and humidity values sensed by two Measure-UPS probes.

This Field	Identifies
Probe 1 : and Probe 2 :	The temperature (in Celsius) and relative humidity (as a percentage) sensed by the Measure-UPS probes.
Current Status :	The current status of threshold and contact alarms.

## Measure-UPS Menu Status Options

The **Measure-UPS** menu provides two options you can use to view additional information about the UPS:

### 4- Threshold and Contact Details

This option accesses information about current temperature and humidity thresholds and contact alarms:

```

-----
Threshold And Alarm Details
-----
- Current Threshold Violations -----
Probe 1 : 23.87 C, 030.4 %RH          Probe 2 : NA    C, NA    %RH
Description          Violation      Description          Violation
-----
Temperature
  High 60 C          Disabled
  Low  0 C          Disabled
Humidity
  High 90 %RH       Disabled
  Low 10 %RH       Disabled
-----
- Current Contact Alarms -----
Description          Alarm      Description          Alarm
-----
Contact 1
  Device 1          Disabled
Contact 3
  Device 3          Disabled
Contact 2
  Device 2          Disabled
Contact 4
  Device 4          Disabled
-----
Press <ENTER> to continue...

```

A Measure-UPS can have up to four contact switches and two probes enabled. Though both probes can perform the same measurements, what is displayed in the probe fields depends on how they are configured: Temperature, humidity or both temperature and humidity.

In the following example, the Measure-UPS has one temperature and humidity probe.



This Field	Identifies
Probe 1 : 23.87 C, 30.4 %RH	The current temperature (in Celsius) and relative humidity (as a percentage).
High 60°C      Disabled	The high temperature threshold, 60°C in this example, and its status, enabled or disabled. When enabled, (Yes) or (No) is displayed to show whether the current temperature exceeds the threshold.
Low 0°C      Disabled	The low temperature threshold, 0°C in this example, and its status, enabled or disabled. When enabled, (Yes) or (No) is displayed to show whether the current temperature exceeds the threshold.
High 90 %RH      Disabled	The high humidity threshold, 90% in this example, and its status, enabled or disabled. When enabled, (Yes) or (No) is displayed to show whether the current humidity exceeds the threshold.
Low 10 %RH      Disabled	The low humidity threshold, 10% in this example, and its status, enabled or disabled. When enabled, (Yes) or (No) is displayed to show whether the current humidity exceeds the threshold.
Contact 1 through Contact 4	The contacts by number and name (Device 1 through Device 4, the default names, in this example), and whether a contact alarm is Disabled, or (when Enabled) if the contact senses an alarm condition (Yes) or not (No).

#### 5- About Measure-UPS

This option accesses a single value: The Firmware Version of the Measure-UPS.

## How to Configure a Measure-UPS

The **Measure-UPS** menu has three options you can use to configure trap threshold and contact settings.

- 1- Trap Thresholds Probe 1
- 2- Trap Thresholds Probe 2
- 3- Contact Settings

You use the first two options to access the **Trap Thresholds Probe 1** or **Trap Thresholds Probe 2** menu screens. These menu screens provide two sets of identical options.

```

----- Trap Thresholds Probe 1 -----
      Thresholds
      -----
      1- High Temperature   (0-60 C) : 60
      2- Low Temperature   (0-60 C) : 0
      3- High Humidity     (10-90 %RH) : 90
      4- Low Humidity      (10-90 %RH) : 10

      Send Traps On
      -----
      5- High Temperature           : Disabled
      6- Low Temperature            : Disabled
      7- High Humidity              : Disabled
      8- Low Humidity               : Disabled
      9- Accept Changes             :

      ?- Help
      <ENTER> Redisplay Menu
      <ESC> Return To Previous Menu

      > █
  
```

Use	To Do this
The Threshold options	Define the high and low temperature (in Celsius) and relative humidity (as a percentage) thresholds the Measure-UPS will use to identify a trap condition.
The Send Traps On options	Enable or disable sending traps for each threshold.

## 3- Contact Settings

You use this option to access the **Contact Settings** menu screen, which identifies the current alarm condition for each contact, and provides two sets of options.

```

----- Contact Settings -----
Description      Alarm      Description      Alarm
-----
Contact 1
  Device 1      Disabled
Contact 3
  Device 3      Disabled

Contact 2
  Device 2      Disabled
Contact 4
  Device 4      Disabled

1- Contact 1 Name : Device 1
2- Contact 2 Name : Device 2
3- Contact 3 Name : Device 3
4- Contact 4 Name : Device 4
5- Contact Zone 1 : Disabled
6- Contact Zone 2 : Disabled
7- Contact Zone 3 : Disabled
8- Contact Zone 4 : Disabled
9- Accept Changes :

?- Help
<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

Use	To Do this
Contact 1 Nam: through Contact 4 Name :	Define a name for each contact, with each name having up to sixteen (16) characters.
Contact Zone 1: through Contact Zone 4:	Enable or disable the contacts.

## How to Manage the Management Card's Network Connection

Selecting the **Control Console** menu's **Network** option displays a menu that allows you to select other menus you can use to manage the Management Card's network operation.

```

----- Network -----
  1- TCP/IP
  2- Ping Utility

      File Transfer
      -----
  3- TFTP Client
  4- FTP Client
  5- FTP Server

      Application Protocols
      -----
  6- Telnet
  7- Web
  8- SNMP

<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

Use	To Do this
1- TCP/IP	Enable or disable a BOOTP server. With BOOTP Disabled, you must use this option to access menu options you use to define basic network values the Management Card needs to run on the network (see HOW TO DEFINE THE MANAGEMENT CARD'S BASIC NETWORK VALUES).
2- Ping Utility	Use ping to test the Managment Card's ability to communicate over the network.
3- TFTP Client	Define the TFTP Client's IP address.
4- FTP Client	Define the FTP Client's IP address.
5- FTP Server	Define the FTP Server's IP address.
6- Telnet	Define the port on which the Telnet server for the Management Card resides. The default Telnet port is 23.

Use	To Do this
7- Web	Define the port on which the Web server for the Management Card resides. The default Web port is 80.
8 -SNMP	Use the SNMP menu to define values for the Management Card's SNMP access controls, trap receivers and system identifications (see How to Use the SNMP Menu).

**Note:** Because Ping Utility options are self-explanatory, this guide does not provide information on their use..

## How to Define the Management Card's Basic Network Values

When you select the **Network** menu's TCP/IP option, the **TCP/IP** menu's format depends on the BOOTP option setting:

- With **BOOTP: Enabled** (the default), the address values shown in the menu screen come from a BOOTP server, and the menu contains only one option, which you can use to disable BOOTP.

```

----- TCP/IP -----
The Network Service has started with the following settings :
-----

System IP       : 159.215.11.71
Subnet Mask     : 255.255.255.0
Default Gateway : 159.215.11.1
MAC Address     : 00 C0 B7 F1 FF 55

1- System IP       : 159.215.11.71
2- Subnet Mask     : 255.255.255.0
3- Default Gateway : 159.215.11.1
4- BOOTP          : Enabled
5- Accept Changes  :

<ENTER> Redisplay Menu
<ESC> Return To Previous Menu Without Accepting Changes

> █

```

- With BOOTP: Disabled, you must use the menu's three address options (System IP, Subnet Mask and Default Gateway) to define these required network values, when you first install the Management Card, or whenever you need to change these values.

```
----- TCP/IP -----  
  
The Network Service has started with the following settings :  
-----  
  
System IP       : 159.215.11.71  
Subnet Mask    : 255.255.255.0  
Default Gateway : 159.215.11.1  
MAC Address    : 00 C0 B7 F1 FF 55  
  
1- System IP       : 159.215.11.71  
2- Subnet Mask    : 255.255.255.0  
3- Default Gateway : 159.215.11.1  
4- BOOTP         : Disabled  
5- Accept Changes :  
  
?- Help  
<ENTER> Redisplay Menu  
<ESC> Return To Previous Menu  
  
> █
```

## How to Control File Transfers

### TFTP Client

When you select the **Network** menu's TFTP Client option, you access a screen that lets you define the Remote Server's IP address.

```
----- TFTP Client -----  
  
The result of the last file transfer is : Valid Code Image  
  
1- Remote Server IP : 0.0.0.0  
2- Accept Changes :  
  
?- Help  
<ENTER> Redisplay Menu  
<ESC> Return To Previous Menu  
  
> █
```

## FTP Client

When you select the **Network** menu's **FTP Client** option, you access the following screen:

```

----- FTP Client -----

The result of the last file transfer is : Valid Code Image

1- Remote Server IP : 0.0.0.0
2- User Name       : apc
3- Password        : apc
4- Accept Changes :

?- Help
<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

Use	To Do this
1- Remote Server IP	Define the Remote Server's IP address.
2- User Name	Define the User Name (up to 15 characters).
3- Password	Define the password (up to 15 characters).

## FTP Server

When you select the **Network** menu's **FTP Server** option, you access the following screen:

```

----- FTP Server -----

The result of the last file transfer is : Valid Code Image

1- Access          : Enabled
2- Port            : 21
3- Accept Changes :

?- Help
<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

Use	To Do this
1- Access	Enable or Disable FTP server access.
2- Port	Define the port on which the FTP server for the Management Card resides (default port is 21).

## How to Use the Telnet Menu

When you select the **Network** menu's Telnet option, you access the **Telnet** menu screen.

```

----- Telnet -----
1- Access          : Enabled
2- Port            : 23
3- Accept Changes  :

?- Help
<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

Use	To Do this
1- Access	Enable or Disable Telnet access.
2- Port	Define the port on which the Telnet server for the Management Card resides.

## How to Use the Web Menu

When you select the **Network** menu's Web option, you access the **Web** menu screen.

```

----- Web -----
1- Access          : Enabled
2- Port            : 80
3- Accept Changes  :

?- Help
<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

Use	To Do this
1- Access	Enable or Disable Web access.
2- Port	Define the port on which the Web server for the Management Card resides.



## How to Use the SNMP Menu

When you select the **Network** menu's SNMP option, you display the **SNMP** menu screen:

```

----- SNMP -----
  1- Settings
  2- Access Control 1
  3- Access Control 2
  4- Access Control 3
  5- Access Control 4
  6- Trap Receiver 1
  7- Trap Receiver 2
  8- Trap Receiver 3
  9- Trap Receiver 4
 10- Summary

   ?- Help
<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

Use	To Do this
Settings	Enable or disable SNMP access.
Access Control 1 through Access Control 4	Control access to each of the four SNMP channels.
Trap Receiver 1 through Trap Receiver 4	Define which, of up to four NMSs, will be sent traps.

Also, a **Summary** option allows you to view the current settings for all **SNMP** menu values.

```
-----  
SNMP Configuration Summary  
  
sysName          : Unknown  
sysLocation      : Unknown  
sysContact       : Unknown  
  
Access Control Summary  
# Community      Access      NMS IP  
-----  
1 public         Read       0.0.0.0  
2 private        Write      0.0.0.0  
3 public2        Disabled   0.0.0.0  
4 private2       Disabled   0.0.0.0  
  
Trap Receiver Summary  
# Community      Generation Authentication Receiver NMS IP  
-----  
1 public         Enabled    Enabled    0.0.0.0  
2 public         Enabled    Enabled    0.0.0.0  
3 public         Enabled    Enabled    0.0.0.0  
4 public         Enabled    Enabled    0.0.0.0  
  
Press <ENTER> to continue...█
```

## How to Control SNMP Channel Access

The **SNMP** menu's Access Control 1 through Access Control 4 options all access identical menu screens. Each screen:

- Identifies the current settings for all four SNMP channels.
- Provides menu options you can use to change the values for the selected channel.

```

----- Access Control 1 -----

Access Control Summary
# Community      Access      NMS IP
-----
1 public         Read       0.0.0.0
2 private        Write      0.0.0.0
3 public2        Disabled   0.0.0.0
4 private2       Disabled   0.0.0.0

1- Community      : public
2- Access Type    : Read
3- NMS IP         : 0.0.0.0
4- Accept Changes :

?- Help
<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

Use	To Do this
1- Community:	Define the password (up to 8 characters) the NMS (identified by the NMS IP option ) must use for SNMP access to the Management Card (with the allowed access defined by the Access Type option).
2- Access Type:	Define whether an NMS (identified by the NMS IP option ) can use <b>GETs</b> and <b>SETs</b> (Write), just <b>GETs</b> (Read), or cannot use <b>GETs</b> and <b>SETs</b> at all (Disabled).
3- NMS IP:	Configure the channel to allow only one NMS (using a specific NMS IP address), or all NMSs (using 0.0.0.0 for the NMS IP value), to have access to the channel.

## How to Define Trap Receivers

The **SNMP** menu's options, Trap Receiver 1 through Trap Receiver 4, display identical menu screens. Each screen:

- Identifies the current settings for all four trap receivers.
- Provides menu options you can use to change the values for a selected trap receiver.

```

----- Trap Receiver 1 -----
Trap Receiver Summary
# Community      Generation  Authentication  Receiver NMS IP
-----
1 public         Enabled    Enabled          0.0.0.0
2 public         Enabled    Enabled          0.0.0.0
3 public         Enabled    Enabled          0.0.0.0
4 public         Enabled    Enabled          0.0.0.0

1- Community Name      : public
2- Trap Generation     : Enabled
3- Authentication Traps: Enabled
4- Receiver NMS IP    : 0.0.0.0
5- Accept Changes      :

?- Help
<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

Use	To Do this
1- Community Name:	Define the password (up to 8 characters) the Management Card will use when it sends traps to the NMS identified by the Receiver NMS IP option.
2- Trap Generation:	Define whether (Enabled) or not (Disabled) the Management Card will send traps to the NMS identified by the Receiver NMS IP option.
3- Authentication Traps:	Define whether (Enabled) or not (Disabled) the Management Card will send authentication traps to the NMS identified by the Receiver NMS IP option.
4- Receiver NMS IP:	Define the specific NMS (using its IP address) that you want to receive traps sent by the Management Card (0.0.0.0 indicates no traps will be sent to any NMS for this Trap Receiver option).

## How to Manage the Management Card's System (Internal) Operation

Selecting the **Control Console** menu's `System` option displays a menu that allows you to select other menus to manage the Management Card.

```

----- System -----
  1- User Manager
  2- Identification
  3- Date/Time
  4- File Transfer
  5- Tools
  6- About Card

  ?- Help
<ENTER> Redisplay Menu
  <ESC> Return To Previous Menu

> █

```

Use	To Do this
1- User Manager	Control access to the Control Console.
2- Identification	Define the name of the system, the system contact and location.
3- Date/Time	Set the date/time for the system
4 - File Transfer	Control file transfers
5 - Tools	Affect the Management Card's SNMP Agent.
6 - About Card	View Management Card identification values.

## How to Determine Access to the Control Console

Use the **Management Card** menu's `User Manager` option to define the Control Console's Administrator and Device Manager User passwords, Auto Logout value, and to enable or disable Authentication.

```

----- User Manager -----
  1- Administrator
  2- Device Manager User
  3- Auto Logout      : 3 Minutes
  4- Authentication   : Disabled
  5- Accept Changes  :

  ?- Help
<ENTER> Redisplay Menu
  <ESC> Return To Previous Menu

> █

```

Use	To Do this
1- Administrator	Define the Administrator user name, password, and authentication phrase. The default Administrator user name is "apc". The default Administrator password is "apc". The default Administrator authentication phrase is "admin user phrase".
2- Device Manager User	Define the Device Manager User name, password, and authentication phrase. The default Device Manager User name is "device". The default Device Manager password is "apc". The default Device Manager authentication phrase is "device user phrase".
3- Auto Logout :	Choose the time (in minutes) it takes the system to automatically logout (default time is 3 minutes).
4- Authentication:	Basic causes the Web Interface to use HTTP 1.1 login; MD5 causes the Web Interface to use an MD5-based authenticated login. See Chapter 11 SECURITY for a detailed explanation.

## How to Define System Identification Values

You use the **System** menu's *Identification* option to define the Management Card's system identification values. Each option identifies its current value.

Use	To Do this
1- Name :	Define the system name used to identify the Management Card.
2- Contact :	Define the contact person for Management Card issues.
3- Location:	Identify the physical location of the management Card.

```

----- Identification -----
1- Name           : Unknown
2- Contact        : Unknown
3- Location       : Unknown
4- Accept Changes :

?- Help
<ENTER> Redisplay Menu
<ESC> Return To Previous Menu

> █

```

## How to Set Date and Time Values

Use the **System** menu's **Date/Time** option to define the Management Card's date and time values.

```

----- Date/Time -----
      1- Date (mm/dd/yyyy) : 02/09/1998
      2- Time  (hh:mm:ss)  : 09:43:40
      3- Accept Changes   :

      ?- Help
      <ENTER> Redisplay Menu
      <ESC> Return To Previous Menu

> █

```

Use	To Do this
1- Date:	Set the date for the system in dd / mm/ yyyy format
2- Time:	Set the time for the system in hh / mm/ ss format

## How to Manage File Transfers

Use the **Management Card** menu's **File Transfer** option to control file transfers.

```

----- File Transfer -----

      The result of the last file transfer is : Valid Code Image

      1- Settings
      2- XMODEM
      3- TFTP Client
      4- FTP Client

      ?- Help
      <ENTER> Redisplay Menu
      <ESC> Return To Previous Menu

> █

```

Use	To Do this
1- Settings	Define the file name.
2- XMODEM	Perform the transfer serially via XMODEM (not available via Telnet).
3- TFTP Client	Perform file transfer via TFTP
4- FTP Client	Perform file transfer via FTP

## How to Control File Transfer Settings

You use the **File Transfer** menu's 1- *Settings* option to define the name of the file to be transferred. The name of the file to be transferred may include path information.

```

----- Settings -----
      The result of the last file transfer is : Valid Code Image

      1- Filename      : Unknown
      2- Accept Changes :

      ?- Help
      <ENTER> Redisplay Menu
      <ESC> Return To Previous Menu

      > █

```

## How to Affect the Management Card's Operation

You use the **Management Card** menu's *Tools* option to affect the Management Card and its SNMP agent.

```

----- Tools -----

      1- Reboot Card
      2- Reset Card To Defaults
      3- Reset Card to Defaults Except TCP/IP

      ?- Help
      <ENTER> Redisplay Menu
      <ESC> Return To Previous Menu

      > █

```

Use	To Do This
1- Reboot Card	Reinitialize the Management Card's operation.
2- Reset Card to Defaults	Change Control Console values to the values currently stored in the Management Card's EEPROM.
3- Reset Card to Defaults Except TCP/IP	Change Control Console values to the values currently stored in the Management Card's EEPROM, except for the values designated for TCP/IP.



## How to View the Management Card's Identification Values

Use the **Management Card** menu's **About Management Card** option to view Management Card identification values.

```
-----  
About Management Card  
  
Model Number      : AP9606      Serial Number      : BL0000000055  
Manufacture Date  : 08/24/1998   Hardware Revision  : E7  
MAC Address       : 00 C0 B7 F1 FF 55  
  
Press <ENTER> to continue...  
  
-----  
Module Information  
  
Description : APC Web/SNMP Card App Layer  
-----  
Name        : appl100f.bin      Type              : StatApp  
Version     : v1.0.0.f         Sector            : 4  
Date       : 09/28/1998       Time              : 13:01:27  
CRC16      : 941E  
  
Press <ENTER> to continue...  
  
Description : APC Web/SNMP Card Platform Layer  
-----  
Name        : plat100f.bin     Type              : Platform  
Version     : v1.0.0.f         Sector            : 11  
Date       : 09/28/1998       Time              : 16:15:53  
CRC16      : A539  
  
Press <ENTER> to continue...
```

## Chapter 9:

### File Transfers (Firmware and Configuration Files)

---

#### Overview

---

The Management Card automatically recognizes two types of binary files: firmware and configuration. Both types of files contain a header and one or more CRCs (Cyclical Redundancy Checks) to ensure that the data contained in the files is not corrupted before or during the transfer operation.

When new firmware is transmitted to the Management Card, the program code is updated and new features become available. When a configuration file is transmitted to the Management Card, the configuration settings are updated accordingly. If any other type of file is transmitted to the Management Card it will be ignored.

There are several ways to transfer firmware and configuration files to the Management Card. The following sections describe the different options available for transferring files to the Management Card: **Upgrading the Management Card's Firmware** and **Updating the Management Card's Configuration Settings**.

#### Upgrading the Management Card's Firmware

---

##### What is Firmware?

Broadly defined, firmware is highly specialized, reliable software that runs on non-PC type computers. It is the firmware that allows the Management Card to perform useful work, like managing UPSs.

##### What are the Benefits of Upgrading the Firmware?

Upgrading the firmware on the Management Card has several benefits. First, new firmware will have the latest bug fixes and performance improvements. Second, any new features that have been added will become available for immediate use. Third, keeping the firmware versions consistent across your network simplifies the management task, since all of the Management Cards will support the same features in the same manner.

##### Where Do I Get the Latest Firmware?

To get the latest firmware contact APC Technical Support. The firmware upgrade consists of two files: the platform module and the application module. The platform module contains the OS and network stack. The application module provides the Management Card with several user interfaces and the ability to speak to UPSs and other accessories.

## How Much Does New Firmware Cost?

Depending on the type of upgrade, there may be a charge. Contact APC Technical Support for details.

## What Should I Know Before I Start the Firmware Upgrade?

Before you start a firmware upgrade, it is important that you understand some basic terminology, as well as the steps required. Once you do, it should take less than one minute to upgrade the firmware on a Management Card.

A firmware upgrade consists of two files; one of the files is the platform module, and the other is the application module.

The platform module contains the OS and network stack. The platform module file name has the following format:

```
plat101.bin
```

*plat* indicates that this is a platform module.

*101* indicates that the version is v1.0.1.

*bin* indicates that this is a binary file.

The application module provides the Management Card with several user interfaces and the ability to communicate with UPSs and other accessories. The application module file name will have the following format:

```
appl101.bin
```

*appl* indicates that this is an application module.

*101* indicates that the version is v1.0.1.

*bin* indicates that this is a binary file.

The platform module must be transmitted to the Management Card first. Once the new platform module has been successfully transferred, the application module must be transmitted to the Management Card. Refer to the section, [HOW TO UPGRADE THE FIRMWARE](#), for detailed instructions on how to transfer both modules to the Management Card.

## How to Upgrade the Firmware

There are several methods to upgrade the Management Card's firmware. These methods are listed in order of simplicity.

### Upgrading Using the Web/SNMP Management Card Wizard

### Upgrading Multiple Management Cards That are Available on the Network

See the *Using the Wizard to Upgrade Firmware* in *Chapter 10 Web/SNMP Management Card Wizard* for detailed instructions.

### Upgrading a Management Card That is Not Available on the Network.

If the Management Card is not available on the network and you prefer to upgrade the firmware locally via XMODEM, refer to the section, `UPGRADING USING XMODEM`.

## Upgrading Using a Command Prompt FTP Client

### Upgrading a Single Management Card That is Available on the Network

1. To perform an upgrade with this method, the Management Card must have been previously configured with a System IP, Subnet Mask, and Default Gateway and attached to the network. In addition, FTP Server must be enabled.
2. Open an MS-DOS command prompt window on a PC that is connected to the network. Change to the directory that contains the firmware upgrade files. The commands that need to be entered are shown in **bold**.

```
C:\>cd\apc
C:\apc>dir

Volume in drive C has no label
Volume Serial Number is 405F-1BD2
Directory of C:\apc

.                <DIR>          10-08-98  4:59p  .
..               <DIR>          10-08-98  4:59p  ..
PLAT101 BIN      327,680  10-08-98  1:02p  plat101.bin
APPL101 BIN      458,752  10-07-98  4:39p  appl101.bin
                2 file(s)      786,432 bytes
                2 dir(s)      763,691,008 bytes free

C:\apc>
```

3. Open an FTP client session.

```
C:\apc> ftp
ftp>
```

4. Connect to the Management Card.

- a. If the Management Card's FTP Server Port is 21, the default, use the following command:

```
ftp> open 150.250.6.10
```

- b. If you have changed the Management Card's default FTP Server Port to a value other than 21, then use the following command:

```
ftp> open 150.250.6.10 21000
```

5. Log in using the Administrator User Name and Password. Your passwords may be different than the defaults, "apc" and "apc". Typically, the password will appear on the screen as \*\*\*.

```
Connected to 150.250.6.10.
220- APC FTP server ready.
220
User (150.250.6.10:(none)): apc
331 User name okay, need password.
Password: apc
230 User logged in, proceed.
ftp>
```

6. Upgrade the platform first. (The platform module is the file with the *plat* prefix.)

```
ftp> bin
200 Command okay.
ftp>
ftp> put plat101.bin
200 Command okay.
150 Opening data connection for plat101.bin
250 Requested file action okay, completed. Management Card
Rebooting....
327680 bytes sent in 5.99 seconds (54.70 Kbytes/sec)
ftp>
```

7. Close the FTP client session.

```
ftp> quit
C:\apc>
```

8. Wait about 20 seconds.
9. Repeat Steps 3 - 8 for the application module. In Step 6, use the application module file name (the one with the *appl* prefix) in place of the platform module file name.

## Upgrading Multiple Management Cards That are Available on the Network

To upgrade multiple management cards using an FTP client, write a script which automatically performs the steps in the previous section.

### Upgrading Using XMODEM

1. Connect serially to the Management Card.
  - a. Connect the Management Card to an available serial port on the host computer using the supplied cable (PN: 940-0024C).
  - b. If PowerChute is running, stop that service.
  - c. Open a terminal session. Configure the terminal session to 2400bps, no parity, 8 data bits, 1 stop bit, and no flow control. If you are using HyperTerminal select `Call->Disconnect` and then `Call->Connect` to apply the changes to the serial port.
  - d. Press the `<Enter>` key several times, until a User Name prompt appears. If you do not see the prompt, make sure that you have the proper cable and that the communication settings are correct.
2. Log into the Management Card.
  - a. Enter the Administrator User Name and Password. The default for both is "apc". If you have changed the Administrator User Name and Password, use the new settings. The main Control Console menu will appear.
3. Start an XMODEM transfer.
  - a. Select option 3 - System.
  - b. Select option 4 - File Transfer.
  - c. Select option 2 - XMODEM.
  - d. Enter "YES" at the prompt to continue with the transfer.
4. Select the appropriate baud rate. The higher the baud rate, the faster the firmware upgrades.
5. Change the terminal program's baud rate to match the one you selected in step 4. If you are using HyperTerminal select `Call->Disconnect` and then `Call->Connect` to apply changes made to the serial port. Press `<ENTER>` to continue.
6. From the terminal program's menu, select the binary platform file (the file with the *plat* prefix) to transfer via XMODEM-CRC.
7. After the XMODEM transfer is complete set the baud rate back to 2400. The Management Card will automatically reboot itself.

---

**Note :** Never remove the Management Card before it completes the reboot cycle or the card will be damaged. The reboot cycle is complete when the status LED turns off, then turns solid green or slowly flashes red after 20 seconds.

---

8. Repeat Steps 1 - 7 to install the application module. In Step 6, substitute the application module file name (the one with the *appl* prefix) for the platform module file name.

## How Do I Know That the Firmware Upgrade Was Successful?

You can verify that the firmware upgrade was successful by looking at the Last Transfer Result message. This message is available in the Control Console and Web interface in the System->File Transfer menu and via SNMP using the `mfiletransferStatusLastTransferResult` OID.

Listed below are the possible Last Transfer Result codes.

<b>Code</b>	<b>Description</b>
Successful	The file transfer was successful.
Result not available	There are no recorded file transfers.
Failure unknown	The last file transfer failed for an unknown reason.
Server inaccessible	The TFTP or FTP server could not be found on the network.
Server access denied	The TFTP or FTP server denied access.
File not found	The TFTP or FTP server could not locate the requested file.
File type unknown	The file was downloaded but the contents were not recognized.
File corrupt	The file was downloaded but at least one CRC was bad.

Additionally, you can verify that the expected versions of the newly upgraded platform and application modules are displayed in the Web interface and Control Console System->About Card menu and via SNMP using the MIB II `sysDescr` OID.



---

## Updating the Management Card's Configuration Settings

---

### What are the Management Card's Configuration Settings?

The Management Card stores its configuration settings internally. These include TCP/IP, TFTP, FTP, Web, Measure-UPS, password, and system settings. Configuration settings do **not** include UPS settings.

There are several ways to edit the Management Card's configuration settings. One method is to log into either the Web interface or Control Console serially, or via Telnet. Any setting that can be edited can be changed in these interfaces. Another method is to perform Sets via SNMP. Only settings which have OIDs in the MIB defined as read-write can be edited.

### What is a Configuration File?

A configuration file provides another way to alter the settings of a Management Card. A configuration file is a binary-encoded file that includes a header, multiple CRCs, and configuration data, and is not editable in a text editor, since such changes would cause the CRCs to be incorrect.

After transferring a configuration file to the Management Card, the Card will assume all of the new settings specified in the configuration file. A configuration file will have a *cfg* extension.

### How Do I Create a Configuration File?

Configuration files can be created with the Web/SNMP Management Card Wizard. The Wizard operates under Windows 95, Windows 98, and NT 4.0. See *Chapter 10 Web/SNMP Management Card Wizard* for details on how to create a configuration file.

### How Do I Transfer a Configuration File to a Management Card?

There are several ways to transfer a configuration file to a Management Card.

1. Specify the configuration file as the Bootup Filename in a BOOTP response.
2. Use the Web/SNMP Management Card Wizard (included on CD-ROM) to transfer the configuration file to one or more Management Cards.
3. Upload the configuration file to the Management Card using FTP.
4. Initiate a TFTP or FTP download of a configuration file via Web, Control Console, or SNMP.

### Updating the Configuration Settings using a BOOTP Bootup Filename

1. Create a binary configuration file (.cfg extension). See *Chapter 10 WEB/SNMP MANAGEMENT CARD WIZARD* for details.
2. In the BOOTPTAB file of your BOOTP server, specify the Management Card's System IP, Subnet Mask, and Default Gateway. Specify the configuration file as the Bootup Filename. The Bootup Filename must be less than 33 characters, and may contain path information.

3. Install or reboot the Management Card, to initiate a BOOTP request. You can reboot the Management Card in the Control Console or Web Interface, under the `System->Tools` menu, or SNMP via the `mcontrolRestartAgent` OID. Alternatively, if you have physical access to the Management Card you may reboot it by pressing the white Reset button on the faceplate.
4. When the Management Card receives the BOOTP response it will assume the System IP, Subnet Mask, and Default Gateway. The Management Card will also automatically recognize that a configuration file has been specified in the Bootup Filename and will attempt to download that file.

First, the Management Card will make a TFTP request for the Bootup Filename from the same IP address which supplied the BOOTP response. If a TFTP server is present on that computer, and the configuration file is in the appropriate directory then the Management Card will download the configuration file and assume all of the specified settings.

If the TFTP request fails, the Management Card will make an FTP request for the Bootup Filename from the same computer that supplied the BOOTP response. The FTP request will use the FTP Client User Name and Password, previously configured in the Management Card, to log in to the FTP server. If the FTP server is present and the configuration file is in the appropriate directory, the Management Card will download the configuration file and assume all of that file's specified settings.

5. You can see whether the file transfer was successful by looking at the Web interface or Control Console `System->File Transfer` menu or SNMP via the `mfiletransferStatusLastTransferResult` OID.

## **Updating the Configuration Settings of One or More Management Cards Using the Web/SNMP Management Card Wizard**

---

**Note :** Please Refer to Chapter 10 Web/SNMP Management Card Wizard for a detailed description of how to update the configuration settings of one or more Management Cards. The following steps describe only the general process of updating the configuration settings and do not address many of the available options.

---

1. Install (if necessary) and run the Web/SNMP Management Card Wizard (included on CD-ROM). Details about installing the Wizard are in Chapter 10 Web/SNMP Management Card Wizard.
2. If you have a previously saved `csv` file, load it, changing any settings as needed. Otherwise you can create new settings and save them.
3. Click `Finish`. Select the settings you want to transmit to the Management Card. Click `Next >` to continue.
4. You can view, print, and save your new settings. When finished click `Next >` to continue.
5. Choose the Network (via FTP) and click `Next >` to continue.
6. If you have previously saved a list of Management Card IP addresses, load that list now. Otherwise enter the IP addresses of the Management Cards to which you want to send the configuration settings. Enter the FTP Server Port, Administrator User Name and Password of the Management Cards to which you are transmitting the settings. Now you can save the new IP address list. Click `Next >` to continue.
7. Click `Apply` to transmit the configuration settings to all of the specified Management Cards. A window containing the download results that can be saved, printed, or cleared will be displayed.

## Updating the Configuration Settings by Using an FTP Client

1. Create a configuration file by using the Web/SNMP Management Card Wizard (included on CD-ROM). See Chapter 10 Web/SNMP Management Card Wizard for Details.
2. Open an MS-DOS command prompt window on a PC that is connected to the network. Change to the directory containing the configuration file. The commands that need to be entered are shown in **bold**.

```
C:\>cd\apc
C:\apc>dir

Volume in drive C has no label
Volume Serial Number is 405F-1BD2
Directory of C:\apc

.                <DIR>                10-08-98  4:59p  .
..               <DIR>                10-08-98  4:59p  ..
MYCONFIG CFG     146 10-08-98  1:02p  myconfig.cfg
                1 file(s)                146 bytes
                2 dir(s)      763,691,008 bytes free

C:\apc>
```

3. Open an FTP client session.

```
C:\apc> ftp
ftp>
```

4. Connect to the Management Card.

- a. If the Management Card's FTP Server Port is 21, the default, use the following command:

```
ftp> open 150.250.6.10
```

- b. If you have changed the Management Card's default FTP Server Port to a value other than 21, use the following command:

```
ftp> open 150.250.6.10 21000
```

5. Log in using the Administrator User Name and Password. Your passwords may be different than the defaults of "apc", and typically will appear on the screen as \*\*\*.

```
Connected to 150.250.6.10.
220- APC FTP server ready.
220
User (150.250.6.10:(none)):apc
331 User name okay, need password.
Password:apc
230 User logged in, proceed.
ftp>
```

6. Upload the configuration file, identified by a *cfg* extension.

```
ftp> bin
200 Command okay.
ftp>ftp> put myconfig.cfg
200 Command okay.
150 Opening data connection for myconfig.cfg
250 Requested file action okay, completed. Management Card
Rebooting....
146 bytes sent in 0.00 seconds (146000.00 Kbytes/sec)
ftp>
```

7. Close the FTP client session.

```
ftp>quit
C:\apc>
```

8. You can verify that the file transfer was successful by looking at the Web interface or Control Console System->File Transfer menu or SNMP via the `mfiletransferStatusLastTransferResult` OID.

## Updating the Configuration Settings by Initiating a TFTP Download

1. Create a configuration file by using the Web/SNMP Management Card Wizard (included on CD-ROM). See Chapter 10 Web/SNMP Management Card Wizard for Details.
2. Configure the TFTP Remote Server IP to the address of the computer that is running the TFTP server.
  - a. Web Interface

Log in to the Web interface as the administrator, then access the `Network->TFTP/FTP` page. Configure the TFTP Client Remote Server IP to the address of the TFTP server.
  - b. Control Console

Log in to the Control Console as the administrator, then access the `Network->TFTP Client` menu. Configure the Remote Server IP to the address of the TFTP server.
  - c. SNMP

Set the `mfiletransferConfigTFTPServerAddress` OID to the address of the TFTP server.
3. Set the name of the configuration file.
  - a. Web Interface

Access the `System->File Transfer` page. Set the Filename to the name of the configuration file you want to download. The Filename may include path information if desired.
  - b. Control Console

Access the `System->File Transfer->Settings` menu. Set the Filename to the name of the configuration file you want to download. The Filename can include path information.
  - c. SNMP

Set the `mfiletransferConfigSettingsFilename` to the name of the configuration file you want to download. The Filename can include path information.
4. Initiate the TFTP download.
  - a. Web Interface

Access the `System->File Transfer` page. Select TFTP from the `Initiate File Transfer Via` drop down box. Click `Apply` to initiate the download.
  - b. Control Console

Access the `System->File Transfer->TFTP Client` menu. Enter "YES" to initiate the download.
  - c. SNMP

Set the `mfiletransferControlInitiateFileTransfer` OID to `initiateFileTransferDownloadViaTFTP`.
5. You can see if the file transfer was successful by checking the Web interface or Control Console `System->File Transfer` menu or SNMP via the `mfiletransferStatusLastTransferResult` OID.

## **Updating the Configuration Settings by Initiating a FTP Download**

1. Create a configuration file by using the Web/SNMP Management Card Wizard (included on CD-ROM). See Chapter 10 Web/SNMP Management Card Wizard for Details.
2. Configure the FTP Remote Server IP, User Name and Password.
  - a. Web Interface

Log in to the Web interface as the administrator, then access the `Network->TFTP/FTP` page. Configure the FTP Client Remote Server IP, User Name and Password to the address, user name and password of the FTP server.
  - b. Control Console

Log in to the Control Console as the administrator, then access the `Network->FTP Client` menu. Configure the Remote Server IP, User Name and Password to the address, user name and password of the FTP server.
  - c. SNMP

Set the `mfiletransferConfigFTPServerAddress`, `mfiletransferConfigFTPServerUser`, and `mfiletransferConfigFTPServerPassword` OIDs to the address, user name and password of the FTP server.
3. Set the name of the configuration file.
  - a. Web Interface

Access the `System->File Transfer` page. Set the Filename to the name of the configuration file you want to download. The Filename can include path information.
  - b. Control Console

Access the `System->File Transfer->Settings` menu. Set the Filename to the name of the configuration file you want to download. The Filename can include path information.
  - c. SNMP

Set the `mfiletransferConfigSettingsFilename` to the name of the configuration file you want to download. The Filename can include path information.

#### 4. Initiate the FTP download.

##### a. Web Interface

Access the System->File Transfer page, then select FTP from the Initiate File Transfer Via drop down box. Click Apply to initiate the download.

##### b. Control Console

Access the System->File Transfer->FTP Client menu. Enter "YES" to initiate the download.

##### c. SNMP

Set the mfiletransferControlInitiateFileTransfer OID to initiateFileTransferDownloadViaFTP.

#### 5. You can see if the file transfer was successful by checking the Web interface or Control Console System->File Transfer menu or at SNMP via the mfiletransferStatusLastTransferResult OID.

### How Do I Know That the Configuration File Transfer Was Successful?

You can verify that the configuration file transfer was successful by looking at the Last Transfer Result message. This message is available in the Control Console and Web interface in the System->File Transfer menu and via SNMP using the mfiletransferStatusLastTransferResult OID.

Listed below are the possible Last Transfer Result codes

Code	Description
Successful	The file transfer was successful.
Result not available	There are no recorded file transfers.
Failure unknown	The last file transfer failed for an unknown reason.
Server inaccessible	The TFTP or FTP server could not be found on the network.
Server access denied	The TFTP or FTP server denied access.
File not found	The TFTP or FTP server could not locate the requested file.
File type unknown	The file was downloaded but the contents were not recognized.
File corrupt	The file was downloaded but at least one CRC was bad.

## Chapter 10:

### Web/SNMP Management Card Wizard

---

#### Overview

---

The Web/SNMP Management Card Wizard, hereafter referred to as the Wizard, is a Windows application designed specifically to pre-configure, reconfigure, and upgrade multiple Web/SNMP Management Cards.

#### What Are the System Requirements for Running the Wizard?

The Wizard will run on Windows 95, Windows 98, and Windows NT 4.0 Intel-based workstations.

#### Where Can I Get an Updated Version of the Wizard?

Updated versions of the Wizard will be available as a free download from [ftp://apccorp.apcc.com/apc/ts\\_public/Management Card/Wizard](ftp://apccorp.apcc.com/apc/ts_public/Management Card/Wizard). Login as anonymous and supply your e-mail address. Updated Wizard software will be distributed without cost. However, access to some of the new features may require an upgrade to the Management Card's firmware for which there may be a charge. For details on how to upgrade the Management Card's firmware, see CHAPTER 9 FILE TRANSFERS.

#### What Management Card Settings Does the Wizard Allow Me to Configure?

Using the Wizard, all of the Management Card's settings, except URL names and links, can be configured locally (via the serial port) or remotely (over the network via FTP).

#### Does the v1.0.1 Version of the Wizard Have Any Limitations?

The main limitation of the Wizard is that you cannot configure any UPS settings either locally (via the serial port) or remotely (over the network via FTP).

#### How Do I Install the Wizard?

If you have enabled autorun for your CD-ROM drive the installation program will start automatically when the Utility CD is inserted. Otherwise run the `setup.exe` installation program found in the Wizard directory, then follow the on-screen instructions.

#### How Do I Run the Wizard?

During installation, a shortcut link is created in the Start menu. Use this link to launch the Wizard application.



## How Can I Quickly Configure Only the Required Settings?

You can quickly configure only the required settings using the Wizard. See *Using the Wizard to Configure Only the Required Settings* for instructions.

## How Can I Pre-configure Multiple Management Cards Before They are Deployed?

How you pre-configure multiple Management Cards before they are deployed depends on your organization's deployment strategy. The following describes the different ways to proceed:

1. Using the Wizard, you can pre-configure all of the Management Card's settings, or just the TCP/IP settings, locally (via the serial port) and then deploy them. See *Using the Wizard to Pre-configure the Management Card Locally* for instructions.
2. Deploy your Management Cards without any pre-configuration and let a BOOTP server assign the TCP/IP settings (System IP, Subnet Mask, and Default Gateway). Use the Wizard to reconfigure any of the Management Card's settings remotely (over the Network via FTP). See *How Can I Reconfigure Multiple Management Cards After They are Deployed?* for details.
3. Deploy your Management Cards without any pre-configuration and let a BOOTP server assign the TCP/IP settings (System IP, Subnet Mask, and Default Gateway) *and* specify a configuration file (.cfg extension). The Management Card will assume all settings specified in the configuration file. Configuration files are created using the Wizard. See *Using the Wizard to Create a Configuration File for BOOTP* for instructions.

## How Can I Reconfigure Multiple Management Cards After They are Deployed?

How you reconfigure multiple Management Cards after they are deployed depends on your organization's preferences. The following describes the different ways to proceed.


1. Use the Wizard to reconfigure any of the Management Card's settings remotely (over the network via FTP). See *Using the Wizard to Reconfigure Deployed Management Cards* for instructions.
2. Create a configuration file (.cfg extension) with the Wizard, then transmit it to the Management Card. See *Using the Wizard to Create a Configuration File* for instructions.

## How Can I Upgrade Firmware?


You can easily upgrade the firmware of many Management Cards simultaneously using the Wizard. See *Using the Wizard to Upgrade Firmware* for instructions.

## Using the Wizard to Configure Only the Required Settings


1. Use the link in the Start menu to launch the Wizard application.
2. The main screen displays the software version of the Wizard. Click Next > to continue.



3. Select the Express (Recommended) option. Click Next > to continue.




4. At a minimum, you must configure the TCP/IP settings (System IP, Subnet Mask, Default Gateway). Please contact your network administrator to obtain valid TCP/IP settings. As long as the Management Card's TCP/IP settings are configured before deployment, the Management Card can be reconfigured remotely at a later time.




5. Follow the on-screen instructions. For detailed instructions on how to install the Management Card, see the Web/SNMP Management Card Installation Guide (insguide.pdf on the CD-ROM).

Click Finish to transmit the new settings to the Management Card. You will be prompted when the transmission is complete or if there was a communications failure.




## Using the Wizard to Pre-configure the Management Card Locally


1. Use the link in the Start menu to launch the Wizard application.
2. The main screen displays the software version of the Wizard. Click Next > to continue.




3. Select the Custom (Advanced) option. Click Next > to continue.



4. Select the Define a New Configuration File (Typical) option. Click Next > to continue.



5. At a minimum, you must configure the TCP/IP settings (System IP, Subnet Mask, Default Gateway, and BOOTP). As long as the Management Card's TCP/IP settings are configured before deployment, the Management Card can be reconfigured remotely at a later time.



---

**Note: If you intend to use the Management Card Wizard to reconfigure Management Cards after deployment then do NOT disable FTP Server Access.**

---

Click Next > to continue through the Management Card's various settings. Any settings that you do not want to configure should be left alone.

6. When you reach the Customize the settings that will be transmitted to the Management Card screen, choose which settings to transmit to the Management Card. You should choose to transmit the TCP/IP settings (System IP, Subnet Mask, Default Gateway, and BOOTP), and only the options you wish to configure. This reduces the amount of time required to transmit the settings to the Management Card.

Click Next > to continue.

**Web/SNMP Management Card Wizard**

Customize the settings that will be transmitted to the Management Card:


Network | System | SNMP | Measure-UPS |

<input checked="" type="checkbox"/> System IP	Enable All On Tab	Enable All Tabs
<input checked="" type="checkbox"/> Subnet Mask		
<input checked="" type="checkbox"/> Default Gateway	Disable All On Tab	Disable All Tabs
<input checked="" type="checkbox"/> BOOTP		
<input checked="" type="checkbox"/> TFTP Remote Server IP		
<input checked="" type="checkbox"/> FTP Remote Server IP		
<input checked="" type="checkbox"/> FTP User Name		
<input checked="" type="checkbox"/> FTP Password		
<input checked="" type="checkbox"/> FTP Server Access		
<input checked="" type="checkbox"/> FTP Server Port		
<input checked="" type="checkbox"/> Telnet Access		
<input checked="" type="checkbox"/> Telnet Port		
<input checked="" type="checkbox"/> Web Access		
<input checked="" type="checkbox"/> Web Port		

Help | Close | << Rewind | < Back | Next > | Finish >>

- The Configuration Summary screen will be displayed. You can now verify the selections you have made, and Save and Print the summary text box by clicking the appropriate buttons. If you save these settings, you can load them into the Wizard at a later time.


Click Next > to continue.






8. Select the Locally (via serial port) option.

Click Next > to continue.



9. Follow the on-screen instructions. For detailed instructions on how to install the Management Card, see the Web/SNMP Management Card Installation Guide (insguide.pdf on the CD-ROM).


Click Apply to transmit the new settings to the Management Card. You will be prompted when the transmission is complete or if there was a communications failure.




10. Click the Rewind button. Define the TCP/IP settings for the next Management Card that you want to configure.

## Using the Wizard to Create a Configuration File for BOOTP


1. Use the link in the Start menu to launch the Wizard application.
2. The main screen displays the software version of the Wizard.
3. Click Next > to continue.



4. Select the Custom (Advanced) option. Click Next > to continue.



5. Select the Define a New Configuration File (Typical) option. Click Next > to continue.



6. Generally, when using a configuration file in conjunction with BOOTP, the configuration file will contain only settings that are generic across multiple Management Cards.

**Note:** If you intend to use the Management Card Wizard to reconfigure Management Cards after they are deployed, then do NOT disable FTP Server Access.

Click Next > to continue through the Management Card's various settings. Any settings that you do not want to configure should be left alone.

7. When you reach the *Customize the settings that will be transmitted to the Management Card* screen, choose the settings you want to transmit to the Management Card. At a minimum, you should **deselect** the TCP/IP settings (System IP, Subnet Mask, Default Gateway, and BOOTP) since those settings are specified by the BOOTP server. It is also recommended that FTP Server Access be deselected.

Click Next > to continue.

Web/SNMP Management Card Wizard

Customize the settings that will be transmitted to the Management Card:


Network | System | SNMP | Measure-UPS

<input type="checkbox"/> System IP	Enable All On Tab	Enable All Tabs
<input type="checkbox"/> Subnet Mask		
<input type="checkbox"/> Default Gateway	Disable All On Tab	Disable All Tabs
<input type="checkbox"/> BOOTP		
<input checked="" type="checkbox"/> TFTP Remote Server IP		
<input checked="" type="checkbox"/> FTP Remote Server IP		
<input checked="" type="checkbox"/> FTP User Name		
<input checked="" type="checkbox"/> FTP Password		
<input type="checkbox"/> FTP Server Access		
<input checked="" type="checkbox"/> FTP Server Port		
<input checked="" type="checkbox"/> Telnet Access		
<input checked="" type="checkbox"/> Telnet Port		
<input checked="" type="checkbox"/> Web Access		
<input checked="" type="checkbox"/> Web Port		

Help Close << Bwind < Back Next > Apply

8. The Configuration Summary screen will be displayed. You can now verify the selections you have made, and Print the summary text box by clicking the appropriate button.

Save your settings. Saving automatically produces two files. One of the files is a text-editable configuration file (.csv extension) that can be reloaded into the Wizard, the other is a **binary** configuration file (.cfg extension). The binary configuration file contains only the settings that were selected in the *Customize the settings that will be transmitted to the Management Card* screen



9. In the BOOTPTAB file of your BOOTP server, specify the Management Card's System IP, Subnet Mask, and Default Gateway. Specify the **binary** configuration file(.cfg extension) that was saved in the previous step as the Bootup Filename, which may be up to 32 characters in length and may contain path information.
10. Install or reboot the Management Card to make a BOOTP request. You can reboot the Management Card in the Control Console or Web Interface using the System->Tools menu, or in SNMP via the mcontrolRestartAgent OID. Alternatively, if you have physical access to the Management Card itself, you can reboot it by pressing the white Reset button on the faceplate.


11. When the Management Card receives the BOOTP response, it will assume the System IP, Subnet Mask, and Default Gateway. The Management Card will also automatically recognize that a configuration file has been specified in the Bootup Filename and it will attempt to download that file.

The Management Card will first make a TFTP request for the Bootup Filename from the same IP address that supplied the BOOTP response. If a TFTP server is present on that computer, and the configuration file is in the appropriate directory then the Management Card will download the configuration file and assume all of the specified settings.


If the TFTP request fails then the Management Card will make an FTP request for the Bootup Filename from the same computer which supplied the BOOTP response. The FTP request will use the FTP Client User Name and Password (defaults for both are apc) previously configured in the Management Card to login to the FTP server. If the FTP server is present and the configuration file is in the appropriate directory then the Management Card will download the configuration file and assume all of the specified settings.

## Using the Wizard to Reconfigure Deployed Management Cards


1. Use the link in the Start menu to launch the Wizard application.
2. The main screen displays the software version of the Wizard. Click Next > to continue.



3. Select the Custom (Advanced) option. Click Next > to continue.



4. Select the Define a New Configuration File (Typical) option. Click Next > to continue.





5. Click Next > to continue through the Management Card's various settings. Any settings that you do not want to reconfigure can be left alone.

---

**Note: If you intend to use the Management Card Wizard to reconfigure Management Cards after deployment then do NOT disable FTP Server Access.**

---

6. When you reach the *Customize the settings that will be transmitted to the Management Card* screen, select the settings you want to transmit to the deployed Management Cards. Typically, the TCP/IP (System IP, Subnet Mask, Default Gateway, and BOOTP) and FTP Server Access settings are not transmitted, so deselect them now. Finish selecting the options you want to reconfigure.

Click Next > to continue.


The screenshot shows a window titled "Web/SNMP Management Card Wizard" with a standard Windows-style title bar. The main content area is titled "Customize the settings that will be transmitted to the Management Card:" and features four tabs: "Network", "System", "SNMP", and "Measure-UPS". The "System" tab is currently selected. Below the tabs is a list of settings, each with a checkbox and a label. The "System IP" checkbox is highlighted with a mouse cursor. To the right of the list are two buttons: "Enable All On Tab" and "Disable All On Tab". At the bottom of the window, there is a row of navigation buttons: "Help", "Close", "<< Bewind", "< Back", "Next >", and "Apply".

Setting	Selected
System IP	<input type="checkbox"/>
Subnet Mask	<input type="checkbox"/>
Default Gateway	<input type="checkbox"/>
BOOTP	<input type="checkbox"/>
TFTP Remote Server IP	<input checked="" type="checkbox"/>
FTP Remote Server IP	<input checked="" type="checkbox"/>
FTP User Name	<input checked="" type="checkbox"/>
FTP Password	<input checked="" type="checkbox"/>
FTP Server Access	<input type="checkbox"/>
FTP Server Port	<input checked="" type="checkbox"/>
Telnet Access	<input checked="" type="checkbox"/>
Telnet Port	<input checked="" type="checkbox"/>
Web Access	<input checked="" type="checkbox"/>
Web Port	<input checked="" type="checkbox"/>


- The Configuration Summary screen will be displayed. At this point, you can verify the selections you have made, and Save and Print the summary text box by clicking the appropriate buttons. If you save these settings, you can load them into the Wizard at a later time.

**Note:** Make sure that you have selected **ONLY** the settings that you want to reconfigure. You can inadvertently overwrite the deployed Management Card settings if you have not properly deselected the settings that you do **NOT** want to reconfigure. All settings that have a **YES** in the Send column of the Configuration Summary screen will be transmitted.

Click Next > to continue.




8. Select the Remotely (over network via FTP Server) option, then click Next > to continue.



9. Add the IP addresses of the Management Cards that you want to reconfigure. If the deployed Management Cards have different settings for the Administrator User Name, Password, and FTP Server Port then change the values in the wizard to reflect those values.


If you have previously saved a list of Management Card IP addresses then you can load them by clicking the Load... button.

Click Next > to continue.




The screenshot shows a window titled "Web/SNMP Management Card Wizard" with a "Remote File Transfer" section. On the left, there is an APC logo with the website "www.apcc.com" and an image of a management card. The main area contains instructions: "Add the System IP addresses of the Management Cards that you want to update. You may save this list of System IP addresses and on subsequent occasions reload them." Below this, there is a list of IP addresses: "159.215.12.104" (highlighted), "159.215.12.100", "159.215.12.102", and "159.215.12.104". There are buttons for "Add I.P.", "Remove I.P.", "Save...", and "Load...". Below the IP list, it says "Specify the current Administrator User Name, Password and FTP Server Port of the Management Cards listed above." and has input fields for "Administrator User Name" (apc), "Administrator Password" (apc), and "FTP Server Port" (21). A note at the bottom states: "Note: The current Administrator User Name, Password and FTP Server Port of all the Management Cards must be identical otherwise some of the attempted file transfers will be unsuccessful." At the bottom of the window are buttons for "Help", "Close", "<< Rewind", "< Back", "Next >", and "Finish >>".

10. Click **Apply** to transmit the new settings to all of the Management Cards specified in the previous screen. After transmitting the settings to all of the Management Cards, a transmission log will be available. The log can be saved, printed, or cleared by clicking the appropriate button.




## Using the Wizard to Create a Configuration File


1. Use the link in the Start menu to launch the Wizard application.
2. The main screen displays the software version of the Wizard.
3. Click Next > to continue.



4. Select the Custom (Advanced) option. Click Next > to continue.



5. Select the Define a New Configuration File (Typical) option. Click Next > to continue.



- Click Next > to continue through the Management Card's settings, ignoring any settings that you do not want to reconfigure.

---

**Note: If you intend to use the Management Card Wizard to reconfigure Management Cards after deployment then do NOT disable FTP Server Access.**

---

- When you reach the *Customize the settings that will be transmitted to the Management Card* screen, choose which settings you want to transmit to the deployed Management Cards. Typically, the TCP/IP (System IP, Subnet Mask, Default Gateway, and BOOTP) and FTP Server Access settings are not transmitted, so deselect them now. Finish selecting only the options you want to reconfigure, then click Next > to continue.

The screenshot shows a window titled "Web/SNMP Management Card Wizard" with a tabbed interface. The "System" tab is selected. The main area contains a list of settings with checkboxes and two summary buttons: "Enable All On Tab" and "Disable All On Tab".

Setting	Selected
System IP	<input type="checkbox"/>
Subnet Mask	<input type="checkbox"/>
Default Gateway	<input type="checkbox"/>
BOOTP	<input type="checkbox"/>
TFTP Remote Server IP	<input checked="" type="checkbox"/>
FTP Remote Server IP	<input checked="" type="checkbox"/>
FTP User Name	<input checked="" type="checkbox"/>
FTP Password	<input checked="" type="checkbox"/>
FTP Server Access	<input type="checkbox"/>
FTP Server Port	<input checked="" type="checkbox"/>
Telnet Access	<input checked="" type="checkbox"/>
Telnet Port	<input checked="" type="checkbox"/>
Web Access	<input checked="" type="checkbox"/>
Web Port	<input checked="" type="checkbox"/>

Buttons at the bottom: Help, Close, << Rewind, < Back, Next >, Apply.




8. The Configuration Summary screen will be displayed. At this point, you can verify the selections you have made, and Print the summary text box by clicking the appropriate button.

---

**Note:** Make sure that you have selected **ONLY** the settings that you want to reconfigure. You can inadvertently overwrite the deployed Management Card settings if you have not properly deselected the settings that you do **NOT** want to reconfigure. All settings that have a YES in the Send column of the Configuration Summary screen will be transmitted.

---


Save your settings, which will automatically produce two files. One of the files is a text-editable configuration file (.csv extension) that can be reloaded into the Wizard, the other is a *binary* configuration file (.cfg extension) that contains only the settings chosen in the *Customize the settings that will be transmitted to the Management Card* screen.




9. Transmit the *binary* configuration file (.cfg extension) to the Management Card. See *Chapter 9 File Transfers* for detailed explanations of the various file transfer options available.

## Using the Wizard to Upgrade Firmware


1. Make sure that the Management Cards that you want to upgrade have had their TCP/IP settings configured and that they are connected to the network.
1. Use the link in the Start menu to launch the Wizard application.
2. The main screen displays the software version of the Wizard. Click Next > to continue.




3. Select the Custom (Advanced) option. Click Next > to continue.



4. Select the Upgrade Firmware option. Click Next > to continue.



5. Press the Browse buttons for both the Platform and Application Firmware Modules. Select the appropriate file. If the wrong file type is selected a warning will be displayed. See **Chapter 9 File Transfers (Firmware and Configuration)** for details about how to obtain new firmware modules from APC.



6. Add the IP addresses of the Management Cards that you want to upgrade. If the deployed Management Cards have different settings for the Administrator User Name, Password, and FTP Server Port then change the values in the wizard to reflect those values.

If you have previously saved a list of Management Card IP addresses then you can load them by clicking the Load... button.

Click Next > to continue.

7. Click Apply to transmit the new firmware to all of the Management Cards specified in the previous screen. After transmitting the firmware to all of the Management Cards, a transmission log will be available. The log can be saved, printed, or cleared by clicking the appropriate button.

## Chapter 11:

### Web/SNMP Management Card Security

---

#### Overview

---

The Web/SNMP Management Card provides several different security options, depending on the access interface used. Each of these individual elements is described below, and a summary table is given for each interface. In general, the security aspects of the Management Card should provide a reasonable level of access and authentication control. As a network device that passes information across the network, though, it is subject to the same exposure as other devices on the network. Protecting intranet networks that are connected to external networks (the Internet) with devices such as firewalls, is also an extremely important element in security.

#### Authentication versus Encryption

The Management Card does not currently use any type of encryption. This means that all the data and communication between the Management Card and any of the client interfaces, such as Telnet and the web server, is “readable” by capturing the network traffic going to and from the Management Card. For almost all applications this should not be a problem since sensitive data is not being transferred. The card does provide basic authentication via user names and passwords to control access as well as IP address verification. While these basic access modes are sufficient for most environments, the Management Card can also provide a greater level of security by enabling MD5 authentication for the web interface. For information on using MD5 see MD5 AUTHENTICATION.

#### User Names, Passwords and Community Names

The Administrator and Device Manager User user names and passwords are for logging into the Control Console and web interfaces. All user names, passwords and community names, for SNMP, are transferred over the network as plain-text. This means that someone capable of monitoring the network traffic can determine the user names and passwords required to access the Management Card. Any similar device with Telnet server, web server, or SNMPv1 agent will have the same constraints due to the limitations in the protocols themselves.

#### Port Assignments

It is possible to define the TCP ports that the Telnet, FTP and web servers utilize. These are initially set at the standard “well known port” for the particular protocol. To enable users to hide the interfaces, one can use arbitrary ports from 5000-65535. Once an interface uses a non-standard port, it is required to specify the port when using a client interface, such as a web browser. Hiding the servers provides a level of security in obscurity. In a sense, the non-standard ports are extra passwords.

## MD5 Authentication

The web interface option for MD5 authentication enables a higher level of access security than provided by the basic http authentication scheme. The MD5 scheme is very similar to the the CHAP and PAP remote access protocols. When enabled, the web server will request a user name and a *password phrase* (distinct from the passwords). As opposed to the basic scheme, the user name and password phrase are not transmitted over the network. The small Java login applet combines the user name, password phrase and session-unique challenge number and calculates an MD5 hash number. This number is then returned to the server so that it can verify that the user has the correct login information. By passing back only the hash number, the login information is not revealed. In addition to the login authentication, each form post for configuration or control operations is also authenticated with a unique challenge and hash response. The scheme does not involve any encryption, so pages are transmitted in their plain-text form. In addition, after the authentication login, subsequent page access is restricted by IP address and a hidden session cookie. Since the MD5 authentication scheme is available only for the web interface, it is important to disable the less secure interfaces including Telnet, FTP and SNMP. For SNMP, it is possible to disable write access only so that read and trap facilities are still available.

The MD5 authentication scheme provides a much higher level of security than the plain-text type access methods. Sophisticated attacks are, however, almost impossible to prevent. Well-configured firewalls are an essential element in an overall security scheme.

Each of the interfaces and access methods is described below.

Interface	Security Access	Notes
Serial Control Console	- User name & password	Always enabled.
Telnet Control Console	- User name & password - Selectable server port - Server Enable/Disable	The user name and password are transmitted plain-text.
SNMP	- Community Name - NMS IP filters - Agent Enable/Disable - Four access communities with read/write/disable capability	IP filters only allow access from designated IP addresses.
FTP Server	- User name & password - Selectable server port - Server Enable/Disable	Administrator access only.
Web Server	- User name & password - Selectable server port - Server Enable/Disable - MD5 Authentication option	In basic HTTP authentication. mode, the user name and password are transmitted base-64 encoded (no encryption). In MD5, authentication mode uses user name and password phrase.

## Chapter 12:

### How to Correct Management Card Problems

This chapter describes how to correct problems that can occur with your Management Card. If you cannot isolate and correct a problem using this chapter, see the **TECHNICAL SUPPORT** section.

#### Web/SNMP Management Card-Related Common Problems and Solutions

Problem	Solution
Unable to ping the Management Card	<p>Is the Management Card's Status LED green, indicating it is up and running its SNMP agent on the network? If yes, try to ping another node on the same network segment as the Management Card. If that fails, it is not a Management Card problem. If the Status LED is not green, or if the ping test succeeds, perform the following checks:</p> <ul style="list-style-type: none"> <li>- Verify that the Management Card is properly seated in the UPS or X-chassis.</li> <li>- Verify all network connections.</li> <li>- Verify IP addresses of the Management Card and the NMS, and make sure both are on the same network or sub-network.</li> <li>- Verify the default gateway (or router) IP address if the NMS is on a different physical network (or subnet) than the Management Card.</li> <li>- Verify the number of subnet bits for the Management Card's subnet mask.</li> </ul>
Unable to perform a <b>GET</b>	<ul style="list-style-type: none"> <li>- Verify the read (<b>GET</b>) community name.</li> <li>- Use the Management Card's Control Console to ensure that the NMS has access to the Management Card (see <b>CHAPTER 8</b>).</li> </ul>
Unable to perform a <b>SET</b>	<ul style="list-style-type: none"> <li>- Verify the read/write (<b>SET</b>) community name.</li> <li>- Use the Management Card's Control Console to ensure that the NMS has write (<b>SET</b>) access to the Management Card (see <b>CHAPTER 8</b>).</li> </ul>
Unable to receive traps at the management station	<ul style="list-style-type: none"> <li>- Query the PowerNet™ MIB <b>mconfigTrapReceiverTable</b> OID to see if the NMS IP address is listed correctly, and the community name defined for the NMS matches the community name in the table. If not, use <b>SETs</b> to the <b>mconfigTrapReceiverTable</b> OIDs, or the Management Card's Control Console to correct the trap receiver definition problem (see <b>CHAPTER 8</b>).</li> </ul>
Traps received at NMS are not identified	<ul style="list-style-type: none"> <li>- See your NMS-specific documentation to verify the traps are properly integrated in the NMS's alarm/trap database.</li> </ul>
Frequent Comm Lost messages from PowerChute <i>plus</i> when using the passthrough feature	<ul style="list-style-type: none"> <li>- See this chapter's separate section on <b>CORRECTING COMMUNICATION LOST PROBLEMS</b>.</li> </ul>

Problem	Solution
Terminal program reports that it cannot allocate the comm port when you try to configure the Management Card	- You must shutdown PowerChute <i>plus</i> before you can use a terminal to configure the Management Card.
Can't browse the Web Interface	- Verify that HTTP access is enabled. - Verify that you can ping the adapter. - Verify that you are using either Internet Explorer 3.01 or above, or Netscape 3.0 or above.

## How to Correct Communication Lost Problems

**Unable to Communicate with UPS** conditions can be reported by PowerChute *plus*. If this problem occurs after PowerChute *plus* and the Management Card have been installed together on a UPS:

- 1) If PowerChute *plus* cannot communicate with the UPS at all:
  - a) Ensure that the cable between the computer and the UPS (or the AP9600) is securely connected at both ends.
  - b) Ensure that the UPS (or AP9600) serial port is connected to the same computer port used to connect the computer to the UPS when PowerChute *plus* was installed.
  - c) Ensure that the black, smart-signalling cable (940-0024C) which came with the Management Card is being used for the connection between the computer and the UPS (or AP9600).
  - d) If steps a) through c) do not find the problem, reset the Management Card.
  - e) If the problem persists, disconnect (or remove) the Management Card from the UPS and restart PowerChute *plus*.
  - f) If the problem persists, see your PowerChute *plus* documentation to remove and then reinstall PowerChute *plus*. If the problem continues, contact Technical Support.
  - g) If step e) cleared the problem, reinstall the Management Card. If the problem returns, contact Technical Support.
- 2) If **Unable to Communicate with UPS** is an intermittent problem, an interrupt request (IRQ) conflict could be the cause. To eliminate the IRQ conflict, disconnect (or remove) the Management Card from the UPS and restart PowerChute *plus*:
  - a) If the problem persists, see your PowerChute *plus* documentation to remove, and then reinstall, PowerChute *plus*. If the problem continues, contact Technical Support.
  - b) If PowerChute *plus* works without the Management Card:
    1. Stop PowerChute *plus*.
    2. Use an ASCII text editor to edit the **[ups]** section of the PowerChute *plus* initialization file (**pwrchute.ini** or **powerchute.ini**, depending on the PowerChute *plus* operating system):
      - Add **TimeoutFactor=40** parameter to the file.
      - Add **UpsPollInterval=6** to the file (default value is **4**).

---

**Note:** See your *PowerChute plus User's Guide* for information on how to edit the pwrchute.ini file.

---

3. Restart PowerChute *plus*.
4. If the problem persists, contact Technical Support.



## APC Worldwide Product Support

If you have any questions concerning this or other APC products, contact the technical support center for your area. APC technical support is provided at no charge.

**APC Corporate Web Site (with links to international sites):** <http://www.apcc.com>  
**APC Japan Web Site:** <http://www.apc.co.jp>  
**APC North American Technical Support:** <http://support.apcc.com>

**North America** (US and Canada) Toll Free: +800 800-4272  
 Fax: +401 788-2743

**LAM (Latin America)** Email: [apctchla@apcc.com](mailto:apctchla@apcc.com)

**By Country:**

Argentina	0800-9-2722
Brazil	0800-127221
Colombia	980-15 39 47
Mexico	95 800 804 4283
Uruguay	000 413 598 2139
Venezuela	8001 2856

**EMEA (Europe, Middle East, Africa)**

Headquarters Telephone: +353 91 702020  
 Fax: +353 91 755275  
 Email: [apceurtech@apcc.com](mailto:apceurtech@apcc.com)

**By Country:**

Austria	Toll Free: 0660 6480
Belgium	Toll Free: 0800 15063
Denmark	Toll Free: 800 18 153
Finland	Toll Free: 9800 13 374
France	Toll Free: 0800 906 483
Germany	Toll Free: 0130 818907
Holland	Toll Free: 0800 0224655
Hungary	Toll Free: 00800 12221
Ireland	Toll Free: 1 800 702000 extension 2045
Israel	Toll Free: 177 353 2206
Italy	Toll Free: 1678 74731
Luxembourg	Toll Free: 0800 2091
Norway	Toll Free: 800 11 632
Poland	Toll Free: 00800 353 1202
Portugal	Toll Free: 050 553182
Russia	Telephone: +7 095 916 7166
South Africa	Toll Free: 0800 994206
Spain	Toll Free: 900 95 35 33
Sweden	Toll Free: 020 795 419
Switzerland	Toll Free: 0800 556177

Turkey Toll Free: 0800 35390275  
 United Kingdom Toll Free: 0800 132990

### JCAA (Japan, Asia, Australia) by Regional Center:

**ANZ (Australia, New Zealand)**  
 Toll Free: +1800 652 725  
 Telephone: +61 2 9955 9366  
 E-mail: [anztech@apcc.com](mailto:anztech@apcc.com)  
 Fax: +61 2 9955 2844

**ASEAN**  
 E-mail: [asetech@apcc.com](mailto:asetech@apcc.com)  
 Singapore, Thailand, Vietnam  
 Telephone: +65 337 4462  
 Fax: +65 337 2774

Malaysia Telephone: +60 3 756 8786  
 Fax: +60 3 756 8780

Indonesia Telephone: +62 21 6500813  
 Fax: +62 21 6507427

**GCN**  
 China Telephone: +86 10 6201 6688  
 Fax: +86 10 6201 7658

Hong Kong, Taiwan  
 Telephone: +88 622 755 1945  
 Fax: +88 622 755 1946

**ISB (India, Nepal, Sri Lanka, Bangladesh, Maldives)**  
 Telephone: +91 44 433-1124  
 Fax: +91 44 434-1464

**JPN (Japan)**  
 Telephone: +81 3 5434 2021  
 Fax: +81 3 5434 2022  
 Email: [jsupport@apcc.com](mailto:jsupport@apcc.com)

**NAS**  
 Korea Telephone: +82 2 501-6492  
 Fax: +82 2 501-6369

Philippines Telephone: +63 2 813 2662  
 Fax: +63 2 892 2448

## Appendix A

### Acronyms & Abbreviations

---

APC	American Power Conversion
BOOTP	bootstrap protocol
Comm	communication
EEPROM	electrically erasable programmable read-only memory
FTP	file transfer protocol
HP	Hewlett Packard Corporation
HTTP	Hypertext Transport Protocol
IP	Internet Protocol
LED	light emitting diode
MIB	management information base
NMS	network management system
OID	object identification
RMA	returned material authorization
SNMP	simple network management protocol
TCP/IP	Transport Control Protocol/Internet Protocol
TFTP	trivial file transfer protocol
UPS	uninterruptible power supply

# Index

## A

- About Management Card Screen 121
- Access
  - Changing values 18
  - Channels 17, 62, 115
    - Controlling 62, 115
    - SNMP, Defining access to 61–62, 113
    - SNMP screen 115
    - SNMP, Using to define 109, 113
  - FTP Server, enable or disable 111
  - SNMP channel, Allowing to 18
- Action
  - Initiate
    - Simulate Power Failure 34
    - Start Runtime Calibration 34
    - Test UPS Alarm 34
    - UPS Self-Test 34
  - Put UPS to Sleep 36
  - Put UPS to Sleep Gracefully 36
  - Reboot UPS 36
  - Reboot UPS Gracefully 36
  - Reset UPS to Defaults 36
  - Turn UPS Off Gracefully 36
  - Turn UPS On/Off 36
- Administrator settings, defining 64, 118
- Alarms
  - Defining Thresholds 53, 98, 100
    - Alarm if Load Over 53, 90, 100
    - Alarm if Redundancy Under 53, 90, 100
    - Alarm if Runtime Over 53
    - Alarm if Runtime Under 100
    - Alarm if Under 91
  - Displaying information about 26, 73
  - Faults and 87, 95
  - Measure-UPS contacts, Viewing 56, 104
  - Measure-UPS details, Viewing 104
  - Testing UPS 34, 46, 80
  - UPS, Audible 40, 54, 86
- AP9606 Web/SNMP Management Card. *See* Management Card
- apcmgmt 19
- application module
  - and Firmware upgrade 122, 123
    - User Interface 122
  - File Name format 123
- Assistant Online 25
- Authentication 64, 118, 165
  - IP address verification 165
  - MD5 165, 166
  - Password 165

- Traps 62
  - User Name 165
- Auto Logout 64, 117–118, 118
- Auto Self-Test
  - Configure 34

## B

- Battery
  - Actual Bus Voltage Status Field 44
  - Capacity Status Field 20, 32, 43, 77, 83, 88, 91
  - Configuring UPS Values 82
  - External Frame Parameters 48
  - Low Duration 101
  - Main Frame Parameters 48
  - Nominal Voltage status field 44
  - Number of Bad Battery Packs Status Field 33, 43, 90
  - Number of Battery Packs Status Field 32, 43, 90
  - Replacement date 40, 54, 83, 102
  - Return Capacity 101
  - Screen, Symmetra 95
  - Screen, UPS 83
  - UPS Menu 83
  - Viewing UPS values 20
  - Voltage status field 32, 43, 77
- BOOTP 139, 142, 143, 149, 150, 153, 160, 170
  - and Configuration File transfer 129
    - Using the Wizard 147
  - Bootup Filename 129–130, 150, 151
  - Enabled or Disabled 109, 110
  - Network Communication, Using to Provide 15, 109
  - Network Values, Using to Define 14
  - Providing network values using 11
  - Request 130, 150
  - Response 130, 151
  - TCP/IP, Using to enable or disable 58, 108
  - Using a terminal instead of 14
    - Verifying if enabled 19
- Bootstrap protocol 170. *See also* BOOTP
- Bypass
  - Put UPS in/out 80, 97

## C

- Calibration Test
  - Date Status Field 32, 33, 43, 45
  - Result Status Field 32, 33, 43, 45, 88
- cfg file 137, 150, 161
- Channel Access, SNMP 115
- Communication
  - Established 16
  - PowerChute plus and Management Card 15
  - Settings for using a terminal 71
  - Settings for using Telnet 71

- Troubleshooting 167–168
  - Using BOOTP to provide network 15
- Communications Lost problems
  - Troubleshooting 168
- Community Name 165
  - Defining 61–62
- Community strings
  - Changing 18
  - NMS and 17
- Concentrator 13
- Configuration
  - Files 122, 137
    - Creating for BOOTP 147–151
    - Creating using the Wizard 158
    - Defined 129
    - How to create 129
    - Management Card, Updating 135
    - Verifying update 135
  - Files, Transferring to a Management Card 129–135
    - Using a BOOTP Bootup Filename 129–130
  - Management Card
    - How to Update 129
  - Settings 129
    - FTP 129
    - Measure-UPS 129
    - Password 129
    - Pre-Configuring for Management Card 137
    - Pre-Configuring the Management Card Locally 138, 140–146, 162
    - Reconfiguring Deployed Management Cards 151–157
    - Reconfiguring for Management Card 137
    - System 129
    - TCP/IP 129
    - TFTP 129
    - Updating by initiating FTP Download 134–135
    - Updating by initiating TFTP Download 133
    - Updating using FTP Client 131–132
    - Updating using the Wizard 130
    - Web 129
  - Summary Screen 144
- Configuring
  - Client name 14
  - Management Card
    - Defining Requirements 14
  - Measure-UPS 57, 106
  - UPS 37, 81, 98
    - Configuration Menu 81
    - Configuration Screen 37, 81
- Connect dialog box 71
- Connecting PowerChute plus 16
- Contact
  - Defining name 57, 105, 107
  - Defining system 65
  - Settings 104, 105, 107
    - Configuring Closures 19
    - Measure-UPS, Defining Switches for 55, 103
    - Measure-UPS, Disabling and Enabling for 105, 107
    - Measure-UPS, Viewing 56, 104
- Control Console
  - Accessing the 63, 71, 117
  - Accessing via Telnet 71
  - Basic Network Values 109
  - Battery Menu 83
  - Battery Screen 83
  - Configuration Menu 81
  - Configuration Screen 81
  - Control Menu 79
  - Control Screen 79
  - Date/Time screen 119
  - Device Manager Menu 74, 76
  - File Transfer screen 119
  - File Transfer Settings screen 120
  - File Transfer values
    - FTP Client 119
    - Settings 119
    - TFTP Client 119
    - XMODEM 119
  - File Transfers 122
  - General Menu 86
  - General Screen 86
  - How to Use 73
  - Line Transfer Menu 84
  - Line Transfer Screen 84
  - Logging on to the 72
  - Logging Out 73
  - Main screen 72
  - Management Card
    - Accessing 14
    - Managing 70
    - Managing Locally 70
    - Managing Remotely 70, 117
    - Network Connection, Using to Manage 108
  - Measure-UPS
    - Using to Manage 103
  - Menu Options, using 70
  - Network Menu 74
  - Security Access 166
  - Shutdown Menu 85
  - Shutdown Screen 85
  - Structure of the 70
  - System Identification Values
    - Contact 118
    - Date 119
    - Location 118
    - Name 118
    - Time 119
  - System Menu 75, 117
  - System Screen 117
  - Tools Menu 120
    - Reboot Card 120
    - Reset Card to Defaults 120
    - Reset Card to Defaults Except TCP/IP 120
  - Tools Screen 120
  - UPS, Managing 76
  - UPS Status Menu 77, 78
    - About UPS 78

- User Manager
  - Administrator 118
  - Authentication 118
  - Auto Logout 118
  - Device Manager User 118
  - Screen 117
  - Using a Terminal with the 71
- CRC (Cyclical Redundancy Check) 122
- csv file 130, 150, 161
- Current Password 117–118
- Cyclical Redundancy Check (CRC) 122
- D**
- Data packets 13
- Date and Time values 65, 119
- Default Gateway
  - 125, 130, 139, 142, 143, 149, 150, 153, 160. *See also* Gateway
  - Defining 58
- Detailed Information
  - Symmetra 87
- Detailed Status
  - Viewing UPS 78
  - Symmetra 89
- Device Manager Menu 64, 74, 76
- Device Manager User 118, 165
- DNS Name 24
- Downloading
  - New code 15, 23
- E**
- EEPROM 170
  - Changing Control Console values 67
  - Resetting to factory-defaults 20, 82
- Encryption 165
- External Frame Battery Parameters 48
- F**
- File Name 66, 120
- File Transfers
  - Controlling 59, 66, 110
    - Initiate File Transfer Via 66
    - Result of Last File Transfer 66
  - FTP Client 119
  - Screen 66, 119
  - Settings 119, 120
  - Settings Screen 120
  - TFTP Client 119
  - To Management Card 122, 129–135
  - XMODEM 119
- Firmware
  - Defined 122
  - Files 122
  - Management Card, Updating 122
    - application module 122, 123
    - application module file name format 123
    - Before Starting, What to Know 123
    - How To 124–128
    - Last Transfer Result codes 128
    - platform module 122, 123
    - platform module file name format 123
  - Updating using Command Prompt FTP Client 125
    - Multiple Management Cards on the Network 127
    - Single Management Card on the Network 125–126
  - Updating using the Wizard 124
    - Management Card not available on the Network 124
    - Using Multiple Management Cards from the Network 124
  - Updating using XMODEM 127
  - Verifying update 128
- Firmware revision, Viewing 20, 78, 93, 94
- Frequency/Voltage Overload 100
- FTP
  - Configuration Files 129
  - Configuration Settings 129
  - Remote Server IP, Defining 66
  - Remote Server Password, Defining 66
  - Remote Server User Name, Defining 66
  - Request 151
- FTP Client 59, 108, 111
  - Command Prompt, Updating Firmware Using 125
    - Multiple Management Cards on the Network 127
    - Single Management Card on the Network 125–126
  - Updating the Configuration Settings using 131–132
- FTP Download
  - Using to update Configuration Settings 134–135
- FTP Server 108, 111, 125, 155
  - Access 111
  - Port 111, 156, 164
  - Security Access 166
- G**
- Gateway
  - Defining Values for Management Card 14. *See also* Default Gateway
- General Parameters, UPS 82
- General Settings
  - Menu 86, 99
  - Screen 86
- GET commands
  - Defining NMS's use of 62, 115
  - Management Card, Using to Manage a 17
  - Measure-UPS, Using to Manage a 17
  - NMS and 19
  - Troubleshooting 167
  - UPS, Using to Manage a 17
- Graceful
  - Put UPS to Sleep 80, 97
  - Reboot 80, 97
  - UPS turn off 79, 96
- Green LED indicator 13
- H**
- Hardware revision, Viewing 93, 94
- Hardware, Status LED 13
- Help 25. *See* Assistant Online; Web Interface: Help
- Hub 13

- Humidity
  - Monitoring Measure-UPS values 19, 105
  - Viewing Measure-UPS values 56, 104
- I**
- Identification, System 117, 121
- Input Current
  - Status Field 44
- Input Frequency
  - Status Field 32, 42, 88
- Input power, Viewing values 20
- Input Voltage 77, 88
  - Status Field 32, 42, 44
- Intelligence Module (IM) 48, 89, 92
  - Status 93
- Internal Temperature Status Field 32, 42, 89
- IP address
  - Defining Management Card's 58
  - Defining TFTP server's 108
  - Management Card, Defining Values for 14
  - Management Card's Access Channels and 17 verification 165
- L**
- Last calibration status field 77, 88
- Last Self-Test status field 77, 88
- Last Transfer 77, 88
  - Result Codes 128, 135
- LEDs
  - Link-RX/TX 13
  - Status 13
- Line Transfer
  - and UPS 82
  - Menu 84
  - Screen 84
- Line Voltage
  - Maximum, Status Field 32, 42, 89
  - Minimum, Status Field 32, 42, 90
- Links, Defining 68
  - Screen 68
- Load Capacity 90
- Load Current
  - Status Field 42, 89
- Load equipment
  - Turning UPS on and off 36, 79, 96
- Load Power 77, 88
  - and Power Modules 90
  - Status Field 32, 42
- Local Management of the Management Card 70, 140
- Location
  - Defining system 65
  - Modifying Management Card's 73
  - System 18
- Log in 71
  - To the Control Console 72
- Log Out
  - Of the Control Console 73
- Low Battery Duration, Setting 54, 85, 101
- M**
- Main Frame Battery Parameters 48
- Management Card
  - About 121
  - Access channels 17
- BOOTP
  - Enable or Disable 58, 108, 109, 110
- Changing the contact fields 73
- Changing the location of the 73
- Changing the name of the 73
- Command Prompt FTP Client
  - Upgrading Firmware using 125
- Configuration Files
  - Last Transfer Result Codes 135
  - Using Wizard to Create 158
  - Using Wizard to Create for BOOTP 147–151
  - Verifying 135
- Configuration Settings
  - Pre-configuring 137
  - Pre-configuring Locally 138, 140–146, 162
  - Reconfiguring 137
  - Reconfiguring deployed 151–157
- Configuration Settings, updating
  - Using FTP Client 131–132
  - Using FTP Download 134–135
  - Using TFTP Download 133
  - Using the Wizard 130, 136
- Configuration, updating
  - How to 129
  - Using BOOTP Bootup Filename 129–130
- Connecting with PowerChute plus 16
- Control Console
  - Accessing 14, 63, 71
  - Accessing via a Terminal 71
  - Accessing via Telnet 71
  - Control Menu Menu 79
  - Control Screen 79
  - Device Manager Menu 74, 76
  - How to Use 73
  - Logging In 72
  - Main Screen 72
  - Managing a UPS 76
  - Managing the System 117
  - Network Menu 74, 108
  - Network Screen 108
  - System Menu 75
  - Tools Screen 120
  - UPS Status Menu 77, 78
  - Using menu options 70
- Control Console Structure 70

- Defining basic network values 14, 109
- Defining IP address 109
- Defining system identification values 63, 65
  - About Card 117
  - Contact 65
  - Date 65
  - Date/Time 117
  - File Transfer 117, 119, 120
  - Identification 117
  - Location 65
  - Name 65
  - Time 65
  - Tools 117
  - User Manager 117, 118
- Defining trap receivers 22, 115
- Downloading new code 15
- File Transfers 122
- File Transfers, Controlling 59, 66, 110
  - FTP Client 119
  - Settings 119, 120
  - TFTP Client 119
  - XMODEM 119
- Firmware, updating 122
  - application module 122, 123
  - Before Starting, What to Know 123
  - How to 124–128
  - Last Transfer Result Codes 128
  - platform module 122, 123
  - Using Command Prompt FTP Client 125
  - Using the Wizard 124
  - Using XMODEM 127
  - Verifying 128–129
- FTP Client 108, 111
  - Password 111
  - Remote Server IP 111
  - Upgrading Configuration Settings using 131–132
  - User Name 111
- FTP Download
  - Upgrading the Configuration Settings 134–135
- FTP Server 108, 111
  - Access 111
  - Port 111
- Identification Values, Viewing 65, 69, 121
- Information about, Viewing 73
- Limitations of PowerChute plus with 15
- Links, Defining 68
- Local Management 70
- Managing 11
  - Network Connection 108
  - Remotely 70
  - Remotely with SNMP Agent 11
  - Trap Receiver Values 15
  - Using Telnet 70
  - with Control Console 70, 117
- Ping Utility
  - Using to test communication 108
- Resetting 168
- Screens
  - About Card 69
  - File Transfer 66
  - Identification 65
  - Links 68
  - Network 58
  - SNMP Menu 113
  - SNMP Summary 114
  - System 63, 117
  - TCP/IP, BOOTP Disabled 110
  - TCP/IP, BOOTP Enabled 109
  - Telnet/Web 60, 112
  - Tools 67
  - User Manager 117
- Security 165
  - Authentication 165
- SET commands
  - Using to manage 17
- SNMP Agent, Affecting 67
  - Reboot Card 67, 120
  - Reset Card to Defaults 67, 120
  - Reset Card to Defaults Except TCP/IP 67, 120
- SNMP Settings 113
- System Identification Values
  - Contact 118
  - Date 119
  - Location 118
  - Name 118
  - Time 119
- System Identification Values, Viewing 65
- TCP/IP Settings, configure 58
  - Default Gateway 58
  - Subnet Mask 58
- Telnet access
  - Disabling or enabling 60, 112
- Telnet Port, defining 108, 112
- TFTP Client 108, 110
- TFTP Download
  - Upgrading the Configuration Settings 133
- Troubleshooting 167
- User Manager Settings
  - Administrator 64, 118
  - Authentication 64, 118
  - Auto Logout 64, 118
  - Device Manager User 64, 118
- Web access
  - Disabling or enabling 60, 112
- Web Port, defining 109, 112
- Wizard 136
  - Configuration Summary Screen 144
  - Defined 136
  - Installing 136
  - Running 136
  - System Requirements 136
  - Upgrading Configuration Settings using 130, 136
  - Upgrading Firmware using 124

- XMODEM
  - Upgrading Firmware using 127
- Management Information Base. *See* MIB
- Manufacture date, Viewing 20, 78, 93
- Matrix-UPS, managing 76
- Max Line Voltage 44, 77
- mconfig 19
- mconfig TrapReceiverTable 167
- mcontrol 19
- MD5
  - Authentication 166
- Measure-UPS 19
  - Configuring 55, 57, 103, 106, 129
    - Contacts 57, 104, 105, 107
    - Trap Thresholds 106
  - Control Console, Using to manage 103
  - Firmware Version 56, 105
  - GET commands, Using to manage 17
  - Managing locally with PowerChute plus 15
  - Monitoring 19, 55, 103
    - High Humidity 105
    - High Humidity Violation 56
    - High Temperature 105
    - High Temperature Violation 56
    - Humidity 56
    - Low Humidity 105
    - Low Humidity Violation 56
    - Low Temperature 105
    - Low Temperature Violation 56
    - Probes 103, 105
    - Temperature 56
  - Screens
    - Configuration 57
    - Contact Settings 107
    - Main 55, 103
    - Status 55
    - Threshold and Alarm Details 104
    - Trap Thresholds 106
  - SET commands, Using to manage 17
  - Status Information 56
    - Contact Settings 56
  - Trap Thresholds
    - Defining 57
    - Send Traps On option 106
  - Viewing alarm and threshold details 104
  - Web Interface, using to manage 55
- Media Access Control. *See* MAC
- Menus
  - Control Console, Using 70
  - Refreshing 70
  - SNMP, Using 61–62, 113
  - Telnet, Using 112
- Messages
  - Communications established 16
  - Unable to Communicate with UPS 16, 168
- MIB 170
- MIB-II System OIDs 129
  - sysDescr 128
  - Using 18
- Min Line Voltage 44, 77
- Model, Viewing UPS 20
- Module Diagnostics and Information 87, 92
- Module Dump 95
- N**
- Name
  - Changing the UPS 40, 54, 86
  - Contact, Defining 65
  - Defining system 65
  - Location, Defining 65
  - UPS, Viewing 20
- Network
  - BOOTP Server, Using to Define Values 14
  - BOOTP, Using to Provide Communication values 15
  - Communication and the PowerNet MIB 19
  - Link-RX/TX LED 13
  - Management Card, Defining Values for 14
  - Managing a Management Card's connection 108
  - Menu 74, 108
  - Security 17
  - Stack
    - and Firmware upgrade 122, 123
  - Telnet Menu, Using 112
  - Telnet, Using to Manage a Management Card 70
- New Password 117–118
- New User Name 117–118
- NMS 170
  - Access channels 17
  - Community strings and 17
  - Configuring access to the channel 62, 115
  - GET and SET commands and 19
  - GET and SET commands, Defining use of 62, 115
  - IP, Defining 61–62
  - PowerNet communication with 19
  - Receiver IP, Defining 61–62
  - SNMP Access
    - Defining IP for 115
    - Defining Password for 62
  - SNMP Channel, Allowing Access to 18
  - Trap Receiver, Defined as 19, 61
  - Traps
    - Defining for 61, 113
    - Defining Receipt 62, 115–116
    - Troubleshooting 167
- O**
- Object Identifications. *See* MIB-II System OIDs; OIDs
- OIDs 129, 130, 170
  - sysDescr 128
- OIDs, PowerNet MIB 19–21
- Operating frequency status field 77, 88
- Operating System
  - and Firmware upgrade 122, 123
- Options, Using Control Console 70
- Output Frequency
  - Status Screen 32, 42, 89
- Output Frequency Range



- Define 53, 100
  - Output Voltage 53, 77, 88
    - Status Screen 32, 42
  - Output voltage
    - Nominal setting parameter 84, 100
  - P**
  - passthrough mode 15
  - Password 165
    - Configuration Settings 129
    - Control Console, Defining access to 117–118
    - Front-panel, Defining 20
    - FTP Client 111
    - Traps, Defining for Management Card to send 62
  - Password phrase 166
  - Ping utility
    - Troubleshooting 167
    - Using to test communication 108
  - platform module
    - and Firmware upgrade 122, 123
      - Network Stack 122, 123
      - Operating System 122, 123
    - file name format 123
  - PM Status 94
  - Power failure
    - Shutdown delay and 20, 37
    - Simulate 34, 46, 97
    - Testing UPS's ability to respond to 80, 97
  - Power Module (PM) 48, 90, 94
    - Number Bad 90
  - PowerChute plus
    - Connecting 16
    - Management Card 15
      - Limitations of with 15
    - Measure-UPS, Using to Manage 11
    - Restarting 168
    - Troubleshooting 167
    - UPS, Using to Manage 15
  - PowerNet MIB
    - Network communication and 19
    - Traps, Using to Interpret 22
  - PowerNet MIB OIDs 19–21
    - Capabilities of 19
    - Limitations of 21
  - PowerNet SNMP Manager 23
  - Present kVA Capacity 44
  - Probes
    - Monitoring with Measure-UPS 103, 105
  - Put UPS to Sleep 80, 97
  - Put UPS to Sleep gracefully 80, 97
  - R**
  - Raw Status Data 93, 94, 95
  - Reason for Last Transfer to Battery Status Field 32, 42
  - Reboot Card 67
  - Reboot UPS 79, 97
    - Gracefully 80, 97
  - Receiver NMS IP 62, 115–116
  - Red Status LED indicator 13
  - Redundancy 44, 90
  - Redundant Intelligence Module (RIM) 48, 89, 93
  - Registering Your Product 8–10
  - Remote Management of the Management Card 70
  - Remote Server IP 111
  - Reset Card to Defaults 13, 67
  - Reset Card to Defaults Except TCP/IP 67
  - Reset UPS to Defaults 82, 99, 102
  - Return Battery Capacity 54, 101
  - Return delay, Setting 54, 85, 102
  - RIM Status 93
  - RMA 170
  - Router, Defining values for Management Card 14
  - Runtime
    - Calibration
      - Starting/Stopping 34, 46, 80, 97
    - Remaining status field 32, 42, 77, 88, 91
  - S**
  - Scheduled Tests 87, 91
  - Security, Management Card 165
    - and FTP Server 166
    - and Serial Control Console 166
    - and SNMP 166
    - and Telnet Control Console 166
    - and Web Server 166
  - Authentication 165
    - MD5 166
  - Community Name 165
  - Password 165
  - Port Assignments 165
    - FTP server 165
    - Telnet server 165
    - Web server 165
  - SNMP Agent 165
  - Telnet Server 165
  - User Name 165
  - Web Server 165
- Self-test
  - Causing a UPS to perform a 34, 46, 80, 97
  - Date Status Field 32, 33, 43, 45
  - Results Status Field 32, 33, 43, 45, 88
  - Scheduling UPS 86
- Sensitivity 53, 84
- Serial Number
  - Intelligence Module, Viewing 93
  - RIM, Viewing 93
  - UPS, Viewing 20, 78
- Serial port
  - Communication settings for terminal 71
  - Selecting 145
- SET commands
  - Defining NMS's use of 62, 115
  - Management Card, Using to Manage 17, 129
  - NMS and 19
  - Troubleshooting 167
- Shutdown Delay
  - Setting 20, 54, 101

- UPS 85
- Shutdown Parameters 82, 99, 101
  - Menu 85, 101
  - Screen 85, 101
- Simple Network Management Protocol. *See* SNMP
- Sleep Time 35, 54, 85, 102
- Smart-UPS, managing 76
- SNMP 170
  - Access Channels, Defining values for 109, 113
  - Access Control
    - Access Type 115
    - Community Name 61–62, 115
    - Enable or Disable 61
    - NMS IP 61–62, 115
  - Channel Access Screen 115
  - Channels, Controlling access to 61–62, 113, 115
  - Disabling or enabling access 18, 61
  - Menu Screen 113
  - Security Access 166
  - Summary Screen 114
  - System IDs, Defining Values for 109
  - Trap Receivers
    - Defining values for 61, 109, 113, 115
    - Screen 116
  - Trap Receivers, Defining
    - Authentication Traps 61–62, 116
    - Community Name 61–62, 116
    - Receiver NMS IP 61–62, 116
    - Trap Generation 61–62, 116
  - Using 17, 61–62, 113
- SNMP Agent 165
  - Managing the Management Card with 11, 67
  - Restarting, continuing, or loading a new 19
- Status
  - Options in the UPS menu
    - 77, 84, 85, 86, 88, 99, 100, 101, 102
  - Viewing
    - Battery 20, 95
    - Current UPS 20
    - Detailed UPS 78, 89
- Status fields 77, 83, 84, 85, 86, 88, 99, 100, 101, 102
- Status Indicators 13
- Status LED 13
- Status of UPS 77, 88
- Subnet Mask
  - 125, 130, 139, 142, 143, 149, 150, 153, 160
  - Defining Values 14, 58
- Symmetra Power Array
  - Actions
    - Put UPS in Bypass 51, 97
    - Put UPS to Sleep 51, 97
    - Put UPS to Sleep Gracefully 51, 97
    - Reboot UPS 51, 97
    - Reboot UPS Gracefully 51, 97
    - Reset UPS to Defaults 51, 99, 102
    - Runtime Calibration 97
    - Simulate Power Failure 97
    - Turn UPS Off Gracefully 51, 96
    - Turn UPS On/Off 51, 96
    - UPS Self-Test 97
  - Alarm Thresholds
    - Defining 53, 90, 98, 100
  - Configuring 52, 86, 98
    - General Settings 54, 99
    - Shutdown Parameters 54, 99, 101
    - Utility Line Settings 53, 98
  - Controlling 50, 86, 96
  - Detailed Status 44, 87
  - Diagnostics 45
  - Faults and Alarms 87, 95
  - Managing 40, 86
  - Module Diagnostics & Information 87, 92
  - Module Dump 49, 95
  - Module Status 47
  - Monitoring 87
  - Scheduled Tests 87, 91
  - Screens
    - Alarm Thresholds 100
    - Batteries 95
    - Configuration 52, 98
    - Control 50, 96
    - Detailed Status 44, 89
    - Device Status Summary 40
    - Diagnostics 45
    - General 102
    - Intelligence Module (IM) 92
    - Main 40, 87
    - Module Diagnostics & Information 92
    - Module Dump 49
    - Module Status 47
    - Power Module 94
    - Redundant Intelligence Module (IM) 93
    - Reset UPS to Defaults 102
    - Scheduled Tests 91
    - Shutdown Parameters 101
    - Status 41
    - Utility Line 99
  - Status Fields 88
    - About UPS 43
    - Action 46
    - Actual Battery Bus Voltage 44
    - Alarm if Load Over 53, 90, 100
    - Alarm if Redundancy Under 53, 90, 100
    - Alarm if Runtime Over 53
    - Alarm if Under 91, 100
    - Audible Alarm 54
    - Auto Self-Test 46
    - Batteries 90
    - Battery Capacity 43, 88, 91
    - Battery Voltage 43
    - Calibration Date 43, 45
    - Calibration Result 43, 45, 88
    - External Frame Battery Parameters 48
    - Firmware Revision 93, 94
    - Frequency/Voltage Overload 100
    - Hardware Revision 93, 94

- High Transfer Voltage 53
- If UPS Fails 53
- Input Current 44
- Input Frequency 42, 88
- Input Voltage 42, 44, 88
- Intelligence Module (IM) 48, 89, 93
- Internal Temperature 42, 89
- Last Battery Replacement 54, 102
- Last Transfer 88
- Load Capacity 90
- Load Current 42, 89
- Load Power 42, 88
- Load Power and Redundancy 90
- Low Battery Duration 54, 101
- Low Transfer Voltage 53
- Main Frame Battery Parameters 48
- Manufacture Date, IM 93
- Manufacture Date, RIM 93
- Maximum Line Voltage 42, 44, 89
- Minimum Line Voltage 42, 44, 90
- Nominal Battery Voltage 44
- Number of Bad Battery Packs 43, 90
- Number of Battery Packs 43
- On/Off 50
- Output Frequency 42, 53, 89, 100
- Output Voltage 42, 53, 88, 100
- Power Module (PM) 48, 90, 94
- Power Module (PM), Number bad 90
- Present kVA Capacity 44
- Raw Status Data 93, 94, 95
- Reason for Last Transfer to Battery 42
- Redundancy 44, 90
- Redundant Intelligence Module (RIM) 48, 89, 93
- Return Battery Capacity 54, 101
- Return Delay 54, 102
- Runtime Remaining 42, 88, 91
- Self-Test Date 43, 45
- Self-Test Result 43, 45, 88
- Sensitivity 53
- Serial Number, IM 93
- Serial Number, RIM 93
- Shutdown Delay 54, 101
- Sleep Time 50, 54, 102
- Status of UPS 88
- UPS Name 54, 102
- Voltage 90
- Vout Reporting 53, 100
- Status Information 86
- System
  - Configuration Settings 129
  - Contact 18
  - Date and Time
    - Defining 65
    - Screen 119
  - File Transfer Screen 119
  - Identification Values, Defining 63, 65, 117, 118
  - About Card 117
  - Contact 65, 118
  - Date 65, 117, 119
  - File Transfer 117
  - Location 65, 118
  - Name 18, 65, 118
  - Time 65, 117, 119
  - Tools 117
  - User Manager 117
  - Using SNMP to 109
  - IP 125, 130, 139, 142, 143, 149, 150, 153, 160
  - Location 18
  - Menu 75, 117
  - Screen, Identification 65, 118
- T
  - TCP/IP 170
    - BOOTP server and 108, 109
    - Configuration Settings
      - 129, 139, 142, 143, 149, 153, 160
    - Port assignments 165
  - Telnet
    - Communications Settings for 71
    - Control Console 70
      - Accessing 71
      - Accessing via a Terminal 71
      - Accessing via Telnet 71
    - Battery Menu 83
    - Battery Screen 83
    - Configuration Menu 81
    - Configuration Screen 81
    - Control Menu 79
    - Control Screen 79
    - Device Manager Menu 74, 76
    - General Menu 86
    - General Screen 86
    - How to Use 73
    - Line Transfer Menu 84
    - Line Transfer Screen 84
    - Logging In 72
    - Logging Out 73
    - Main Screen 72
    - Managing a UPS 76
    - Network Menu 74, 108
    - Network Screen 108
    - Shutdown Menu 85
    - Shutdown Screen 85
    - Structure 70
    - System Menu 75, 117
    - UPS Status Menu 77, 78
    - Using menu options 70
  - Disabling or enabling access 60, 112
  - Management Card
    - Managing Locally using 70
    - Managing Remotely using 70
    - Managing using 11

- Measure-UPS
  - Configuring 106
  - Managing 103
  - Monitoring 103
- Measure-UPS Screens
  - Contact Settings 107
  - Main 103
  - Threshold and Alarm Details 104
  - Trap Thresholds 106
- Menu
  - Screen 112
  - Using 112
- Port, defining 60, 108, 112
- Server 165
- Symmetra
  - Configuring 86, 98
  - Configuring Shutdown Parameters 101
  - Controlling 86
  - Faults & Alarms 87, 95
  - Intelligence Modules 92
  - Managing 86
  - Module Diagnostics & Information 87
  - Monitoring 87
  - Power Modules 94
  - Redundant Intelligence Module 93
  - Scheduled Tests 87
  - Status Information 86, 87, 88
- Symmetra Screens
  - Alarm Thresholds 100
  - Configuration 98
  - Control 96
  - General 102
  - Main 87, 95
  - Reset UPS to Defaults 102
  - Shutdown Parameters 101
  - Utility Line 99
- Using to Manage UPS and Measure-UPS 70
- Telnet/Web Screen 60
- Temperature
  - Defining high and low for Measure-UPS 105
  - Viewing battery 20
  - Viewing Measure-UPS values 19, 56, 104
- Terminal
  - Communication settings for 71
  - Managing a Management Card using a 70
  - Using to define network values 14
  - Using with the Control Console 71
- Terminal-emulator. *See* Terminal
- Testing
  - Communications 108
  - Serial port 19
- TFTP 170
  - Code, Downloading New 11
  - Configuration Files, Transferring 129
  - Configuration Settings 129
  - Remote Server IP, Defining 66
  - Request 151
  - Server's IP Address, Using to Define 108
  - TFTP Client 59, 110
  - TFTP Download
    - Using to update Configuration Settings 133
  - TFTP server
    - Address, changing 19
    - Address, Identifying 19
  - Threshold
    - Probing trap 103
    - Viewing Measure-UPS 104
  - Time
    - Set Date and Time Values 65
  - Tools 120
  - Transfers
    - Selecting high and low 20, 53, 84
  - Traps
    - Disabling or enabling sending for each threshold 106
    - Generation 62, 115–116
    - Management Card Password, Defining 62
    - PowerNet MIB, Using to interpret 22
    - Receivers
      - Defining 22, 62–64, 115–121
      - Modifying Values 19
      - NMS Defined as 19, 113
      - Using SNMP to Define Values 61–62, 109, 113
      - Viewing defined 19
    - SNMP, Defining 115–116
    - Thresholds
      - Defining 57, 106
      - Probing 55, 103
    - Troubleshooting 167
  - Trivial File Transfer Protocol. *See* TFTP
  - Troubleshooting
    - Communication 167
    - Communication lost problems 168
    - GET and SET performance 167
    - Pinging the Management Card 167
    - PowerChute plus 167
    - Traps, not received 167
    - Unable to Communicate with UPS 168
    - Unidentified traps 167
    - Web Interface, can't browse 168

## U

  - Unable to Communicate with UPS 16, 168
  - Upgrades
    - Configuration
      - How To 129
    - Configuration Files
      - Last Transfer Result Codes 135
    - Configuration Settings
      - Using FTP Client 131–132
      - Using FTP Download 134–135
      - Using TFTP Download 133
      - Using the Wizard 130
      - Verifying 135

- Firmware
  - Before Starting, What to Know 123
  - How To 124–128
  - Last Transfer Result Codes 128
  - Verifying 128
- Firmware, Using Command Prompt FTP Client 125
  - Multiple Management Cards on the Network 127
  - Single Management Card on the Network 125–126
- Firmware, Using the Wizard 124
  - and Management Card not available on the Network 124
  - and Multiple Management Cards from the Network 124
- Firmware, Using XMODEM 127
- UPS
  - About, Status Field 32, 43, 78
  - Battery Menu 83
    - Battery Capacity 83
    - Battery Date 83
  - Battery Screen 83
  - Battery Values, Viewing 20
  - Configuring 20, 37, 52, 75, 81, 98
    - Audible Alarm 86
    - Battery Values 82
    - Configuration Menu 81
    - Configuration Screen 37, 81
    - General Parameters 82
    - High Transfer Voltage 38, 53, 84
    - Line Transfer 82
    - Low Transfer Voltage 38, 53, 84
    - Output Frequency Range 53
    - Output Voltage 38, 53, 84
    - Reset to Defaults 82
    - Sensitivity 38, 53, 84
  - Controlling 35, 79, 96
    - Alarm, Testing 80
    - Put UPS in Bypass 51
    - Put UPS in/out of Bypass 80
    - Reboot UPS 36, 51, 79
    - Reboot UPS Gracefully 36, 51, 80
    - Reset UPS to Defaults 36, 51
    - Runtime Calibration, Start/Stop 80
    - Self-Test 80
    - Simulate Power Failure 80
    - Sleep Gracefully, Put UPS to 36, 51, 80
    - Sleep, Put UPS to 36, 51, 80
    - Sleep Time 35, 50
  - Firmware Revision, viewing 78
  - General Menu 86
  - General Screen 86
  - General Settings 40, 54
    - Audible Alarm 40, 54
    - Last Battery Replacement 40, 54
    - UPS Name 40, 54
  - Graceful Turn Off 36, 51, 79, 96
  - Identification Values, Viewing 20
  - Information About, Viewing 75
  - Line Transfer Menu 84
  - Line Transfer Screen 84
  - Managing 15, 31, 75, 76, 86
  - Manufacture Date, viewing 78
  - Name parameter 73, 86, 102
  - Self-Test 86
  - Serial Number, viewing 78
  - SET Commands, Using to manage 17
  - Shutdown Menu 85
  - Shutdown Parameters 39, 54, 82
    - Low Battery Duration 39, 54, 85
    - Return Battery Capacity 39, 54
    - Return Delay 39, 54, 85
    - Shutdown Delay 39, 54, 85
    - Sleep Time 39, 54, 85
  - Shutdown Screen 85
  - Status Menu 77
    - About UPS 78
    - Battery Capacity 77
    - Battery Voltage 77
    - Calibration Results 77
    - Detailed Status 78
    - Input Voltage 77
    - Last Transfer 77
    - Load Power 77
    - Max Line Voltage 77
    - Min Line Voltage 77
    - Operating Frequency 77
    - Output Voltage 77
    - Runtime Remaining 77
    - Self-Test Results 77
    - Status of UPS 77
    - UPS Internal Temperature 77
  - Status Screens
    - Device Summary 26
    - Diagnostics 33
    - Matrix-UPS 31
    - Measure-UPS 28
    - Network 29
    - Smart-UPS 27, 31
    - System 30
  - Turning on and off 21, 36, 50, 51, 79
  - Unable to Communicate with 168
  - Utility Line Settings 38
- upsAdvBattery 20
- upsAdvConfig 20
- upsAdvControl 21
- upsAdvIdent 20
- upsAdvInput 20
- upsAdvOutput 20
- upsAdvTest 21
- upsBasicBattery 20
- upsBasicConfig 20
- upsBasicControl 21
- upsBasicIdent 20
- upsBasicInput 20
- upsBasicOutput 20
- upsBasicTest 21
- upsCommStatus 21
- upsConfig 20

- upsControl 21
- upsIdent 20
- upsInput 20
- upsOutput 20
- upsTest 21
- User Interface
  - and application module 122
- User Manager
  - Management Card Parameters 64, 117, 117–118
    - Administrator values, defining 64, 118
    - Authentication 64, 118
    - Auto Logout 64, 118
    - Device Manager User values 64, 118
  - Screen 117
- User Name 165, 166
  - FTP Client 111
- Utility Line Settings 53, 98
- Utility voltage. *See* Input power
- V**
- Values
  - APC Management 19
  - Battery 20
  - BOOTP, Providing network with 11
  - Input Power 20
  - Management Card, Defining basic network 14, 63
  - Management Card's Identification 63, 65, 121
  - Measure-UPS 19
  - System Identification, Defining 65
  - Trap Receiver, Managing 15
  - UPS 20
  - UPS menu screen's status information
    - 77, 84, 85, 86, 88, 99, 100, 101, 102
  - Voltage status field 77, 88, 90
  - Vout Reporting 53, 100
- W**
- Web Configuration Settings 129
- Web Interface
  - Accessing the Management Card Using 24, 25
  - Action Fields
    - Put UPS in Bypass 51
    - Put UPS to Sleep 36, 51
    - Put UPS to Sleep Gracefully 36, 51
    - Reboot UPS 36, 51
    - Reboot UPS Gracefully 36, 51
    - Reset UPS to Defaults 36, 51
    - Turn UPS Off Gracefully 36, 51
    - Turn UPS On/Off 36, 51
  - Help 25
  - Logging In 25
  - Management Card
    - BOOTP, enable or disable 58
    - Contact, Defining 65
    - Control Console, Accessing 63
    - Date, Defining 65
    - Default Gateway 58
    - File Transfers, Controlling 59, 66
    - Identification Values, View 69
    - Links, Defining 68
    - Location, Defining 65
    - Name, Defining 65
    - SNMP Agent 67
    - Subnet Mask 58
    - System Identification Values, Defining 63
    - TCP/IP Settings 58
    - Telnet, Configuring 60
    - Time, Defining 65
    - Web, Configuring 60
  - Management Card APC Links
    - Name, Viewing 68
    - URL, Defining 68
  - Management Card Screens
    - About Card 69
    - File Transfer 66
    - Identification 65
    - Links 68
    - Network 58
    - System 63
    - Telnet/Web 60
    - Tools 67
  - Management Card User Links
    - Name, Defining 68
    - URL, Defining 68
  - Measure-UPS
    - Configuring 57
    - Contact Settings, viewing 56
    - Contact Switches, viewing 57
    - Contacts, naming 57
    - Firmware Version 56
    - Managing 55
    - Status Information 56
    - Trap Thresholds, Defining 57
  - Measure-UPS Fields
    - High Humidity Violation 56
    - High Temperature Violation 56
    - Humidity 56
    - Low Humidity Violation 56
    - Low Temperature Violation 56
    - Temperature 56
  - Measure-UPS Screens
    - Configuration 57
    - Main 55
    - Status 55
  - Menu Screen 112
    - Access 112
    - Port 112
  - SNMP Access
    - Enable or Disable 61
  - SNMP Access Control 62
    - Community Name 61–62
    - Enable or Disable 61
    - NMS IP 61–62
  - SNMP Trap Receiver

- Authentication Traps 61–62
- Community Name 61–62
- Receiver NMS IP 61–62
- Trap Generation 61–62
- Status Screens
  - Diagnostics 33
  - Matrix-UPS 31
  - Network 29
  - Smart-UPS 31
  - System 30
- Supported Web Browsers 24
- Symmetra Power Array
  - Alarm Thresholds, Defining 53
  - Configuring 52
  - Controlling 50
  - Detailed Status 44
  - Diagnostics 45
  - General Settings, Defining 54
  - Managing 40
  - Module Dump 49
  - Module Status 47
  - Shutdown Parameters 54
- Symmetra Power Array Fields
  - About UPS 43
  - Action 46
  - Actual Battery Bus Voltage 44
  - Alarm if Load Over 53
  - Alarm if Redundancy Under 53
  - Alarm if Runtime Under 53
  - Audible Alarm 54
  - Auto Self-Test 46
  - Battery Capacity 43
  - Battery Voltage 43
  - Calibration Date 43, 45
  - Calibration Result 43, 45
  - External Frame Battery Parameters 48
  - High Transfer Voltage 53
  - If UPS Fails 53
  - Input Current 44
  - Input Frequency 42
  - Input Voltage 42, 44
  - Intelligence Module (IM) Status 48
  - Internal Temperature 42
  - Last Battery Replacement 54
  - Load Current 42
  - Load Power 42
  - Low Battery Duration 54
  - Low Transfer Voltage 53
  - Main Frame Battery Parameters 48
  - Maximum Line Voltage 42, 44
  - Minimum Line Voltage 42, 44
  - Nominal Battery Voltage 44
  - Number of Bad Battery Packs 43
  - Number of Battery Packs 43
  - On/Off Status 50
  - Output Frequency 42, 53
  - Output Voltage 42, 53
  - Power Module (PM) Status 48
  - Present kVA Capacity 44
  - Reason for Last Transfer to Battery 42
  - Redundancy 44
  - Redundant Intelligence Module (RIM) Status 48
  - Return Battery Capacity 54
  - Return Delay 54
  - Runtime Remaining 42
  - Self-Test Date 43, 45
  - Self-Test Result 43, 45
  - Sensitivity 53
  - Shutdown Delay 54
  - Sleep Time 50, 54
  - UPS Name 54
  - Utility Line Settings 53
  - Vout Reporting 53
- Symmetra Power Array Screens
  - Configuration 52
  - Control 50
  - Detailed Status 44
  - Device Status Summary 40
  - Diagnostics 45
  - Main 40
  - Module Dump 49
  - Module Status 47
  - Status 41
- UPS
  - Configuration Screen 37
  - Configuring 37
  - UPS General Settings 40
    - Audible Alarm 40
    - Last Battery Replacement 40
    - UPS Name 40
  - UPS Shutdown Parameters
    - Return Battery Capacity 39
    - Return Delay 39
    - Shutdown Delay 39
    - Sleep Time 39
  - UPS Status Fields
    - About UPS 32
    - Action 34
    - Auto Self-Test 34
    - Battery Capacity 32
    - Battery Voltage 32
    - Calibration Date 32, 33
    - Calibration Result 32, 33
    - High Transfer Voltage 38
    - Input Frequency 32
    - Input Voltage 32
    - Internal Temperature 32
    - Load Power 32
    - Low Transfer Voltage 38
    - Maximum Line Voltage 32
    - Minimum Line Voltage 32
    - Number of Bad Battery Packs 33
    - Number of Battery Packs 32
    - Output Frequency 32
    - Output Voltage 32, 38
    - Reason for Last Transfer to Battery 32

- Runtime Remaining 32
- Self-Test Date 32, 33
- Self-Test Result 32, 33
- Sensitivity 38
- UPS Status Screens
  - Device Summary 26
  - Measure-UPS 28
  - Smart-UPS 27
- User-Definable Links 25
- Web Port 24, 109
- Web Server 165
  - Security Access 166
- Wizard, Web/SNMP Management Card 136
  - Configuration File, Creating 158
  - Configuration File, Creating for BOOTP 147–151
  - Defined 136
  - Installing 136
  - Pre-Configuring for Multiple Management Cards 137
  - Pre-Configuring the Management Card Locally 138, 140–146, 162
  - Reconfiguring Deployed Management Cards 151–157
  - Reconfiguring for Multiple Management Cards 137
  - Running 136
  - Screens
    - Configuration Summary 144, 154
    - Configure FTP Transfer 156
    - Main 138, 140, 147, 158, 162
    - Network 142
    - Select Which Settings to Transmit 143, 149, 153, 160
    - Settings
      - 138, 139, 141, 148, 152, 159, 162, 163, 164
      - Transmit Current Settings 145, 155
  - System Requirements 136
  - Transferring Configuration Files using 129
  - Upgrading Configuration Settings using 130, 136
  - Upgrading Firmware using 124
    - Management Card not available on the Network 124
    - Multiple Management Cards from the Network 124
- X**
- XMODEM
  - Downloading New Code 11
  - Updating Firmware using 127